



**Model no.: GMT-P1**

# **User's Manual**

110611010005  
V10.02.01\_01

©2015, Shenzhen General Measure Technology Co., Ltd reserves all copyright.

Without permission from Shenzhen General Measure Technology Co., Ltd.,

Any corporations or person must not copy, spread, record or translate into other language by any forms.

Our company reserved the right to update user's manual without additional notice to customers by reason of update, so please visit our website or contact with our service person to get update information.

Website: <http://www.szgmt.com.cn>

# CONTENTS

1 General Description.....	1
1.1 Functions and Characteristics.....	1
1.2 Front Panel.....	2
1.3 Technical Specifications.....	4
1.3.1 Common:.....	4
1.3.2 Analog:.....	4
1.3.3 Digital:.....	5
2 Installation and Wiring.....	6
2.1 Connection of Power Supply.....	6
2.2 Connection of Load Cell.....	6
2.2.1 6 wires connection.....	7
2.3 I/O terminals.....	8
2.4 Optional Expansion Board Output.....	9
2.4.1 Analog Output (Optional).....	9
2.4.2 Serial Interface RS485 Output.....	12
2.4.3 Serial Interface RS232 output (Optional).....	13
3 Calibration.....	14
3.1 Instruction.....	14
3.2 Flow Chart of Calibration.....	15
3.3 Millivolt Value Display.....	20
3.4 Calibration with Weights.....	21
3.5 No weight calibration.....	21

3.5.1 No weight zero Calibration.....	21
3.5.2 No weight gain Calibration.....	23
Historical gain calibration.....	23
Sensitivity and gain calibration range.....	25
3.6 Calibration Switch for Communication Interface.....	26
3.7 Explanation for Calibration Parameters.....	26
4 Working Parameters Setting.....	28
4.1 Flow Chart of Working Parameters Setting.....	28
4.2 Parameter Setting Method.....	30
4.3 Descriptions of Operation Parameters.....	31
4.4 Set point parameters.....	34
5 I/O Definition.....	38
5.1 I/O Definition.....	38
5.2 I/O testing.....	40
6 Serial Communication.....	42
6.1 r-Cont.....	42
6.2 r-SP1.....	43
6.2.1 Parameters Code Chart.....	43
6.2.2 Error Code Explanation.....	44
6.2.3 Command.....	45
6.3 tt TOLEDO Protocol.....	53
6.4 Cb920.....	54
6.5 rECont.....	55

6.6 rEREAD.....	56
6.7 Modbus.....	57
6.7.1 Modbus communication address.....	58
7 Password Input and Setting, Reset.....	66
7.1 Password Input.....	66
7.2 Password Setting.....	66
7.3 Factory Reset.....	68
8 Display Testing.....	70
9 Errors and Alarm Messages.....	71
10 Indicator model user-defined function.....	72
11 Dimension of Indicator.....	74

## 1 General Description


GMT-P1 weighing indicator is specially designed for weight transmitting in industrial fields.

This indicator has the features of small volume, plenty communicating commands, stable performance, easy operation and practicability. It can be widely applied to concrete and bitumen mixing equipment, metallurgy furnace and converter, chemical industry and feed, etc. .

### 1.1 Functions and Characteristics

- Small volume, unique design, easy operation
- Applicable to all kinds of resistance strain gauge bridge load cell
- Front panel numerical calibration
- Multilevel of digital filter
- Automatic zero -tracking
- Automatically zero when powered on
- 4 set points
- 1 input and 2 outputs
- Serial communication interface:RS232 or RS485
- Calibration via serial interface
- Optional interfaces: Analog output, serial interface

## 1.2 Front Panel



**Main Display:** 6 digits, for displaying weight and the information of parameters.

**Status Indicator Lamp:**

- **ZERO:** Light on when present weight is within  $0 \pm 1/4d$ .
- **STAB:** Light on when changes of weight values are within the range of motion detecting during motion detecting time.
- **NET:** The indicator light of gross and net weight and communication status is displayed according to the requirements of working parameter F1.8

**Keypad:****ZERO**  


: Zero/Esc, Used to exit from current operation or go previous. Long press this key for zero calibration (limited by zero clearing range, not limited by calibration lock).

**TARE**  


: Used to scroll optional values of parameter and to make flashing digit increase 1 while data inputting.

**MODE**  


: Function Selecting Key, to make flashing position move to the right digit when data inputting. Long-press the key will start to transmit data and it will flicker.

**W/A**  
**ENTER**  


: Confirming Key. Used to confirm present operation.

Note: Under the status of gross weight, user could remove tare by pressing OPTION key, and if press Esc key in net weight mode, it will add tare weight, while it is zeroing under the status of net weight. It will show net weight value after tare, meanwhile the NET light is on.

## 1.3 Technical Specifications

### 1.3.1 Common:

Power supply: **DC24V±5%**

Working temperature: **-10~40°C**

Max humidity: **90%R.H without dew**

Power consumption: **About 10W**

Dimension: **105×89×57 (mm)**

### 1.3.2 Analog:

Load cell power: **DC5V 200mA (MAX)**

Input impedance: **10MΩ**

Zero steady range: **0.00~12mV(Load cell 3mV/V)**

Input sensitivity: **0.01uV/d**

Input range: **0.00~15mV(Load cell 3mV/V)**

Transfer mode: **Sigma - Delta**

A/D conversion speed: **15, 30, 60, 120, 480, 960 times/sec**

Non-linearity: **0.01% F.S**

Gain drift: **10PPM/°C**

Display Precision: **1,000,000d**

### 1.3.3 Digital:

Weight display: **6 digits red high-brightness LED**

Minus display: “-”

Overload display: “**OFL**”


Decimal point: **5 kinds (optional)**

Function keys: **4 keys soniferous keypad**

## 2 Installation and Wiring

### 2.1 Connection of Power Supply

GMT-P1 weighing indicator connects DC24V power supply as follows:



Power supply connection

### 2.2 Connection of Load Cell


GMT-P1 weighing indicator connects bridge type resistance strain gauge load cells by 6 wires or 4 wires as follows. When you use 4-wired load cells, you must bridge the SN+ with EX+ and bridge the SN- with EX-.

The signal definition of each port of the load cell connector is as follows:

**EX+:** Excitation+   **EX-:** Excitation-   **SN+:** Sense+   **SN-:** Sense-   **SIG+:** Signal+   **SIG-:** Signal-

6 wires	EX+	SN+	EX-	SN-	SIG+	SIG-	Shield
4 wires	EX+		EX-		SIG+	SIG-	Shield


### 2.2.1 6 wires connection



#### Note:

1. As load cell output sensitive analog signal, please use shield cable to separate with other cables, especially AC power.
2. 4 wires connection is suitable for short distance and stable temperature or low precision field, otherwise use 6 wires connection.
3. For more load cells parallel connection, their sensitivity (mV/V) should be same.


## 2.3 I/O terminals




I/O tolerant definition as follows:

Output		Input	
OUT1	Stable	IN1	Reset all
OUT2	OFL		

Indicator input terminal connection:



Indicator input terminal connection:




## 2.4 Optional Expansion Board Output

GMT-P1 weighing indicator supports analog output, RS232 or RS485 as optional output function, please confirm it when place orders.

### 2.4.1 Analog Output (Optional)

At normal displaying status, press **W/A** **ENTER** to check the analog output.

The definition of analog output as below:



The definition of analog output:  
**V+**: voltage-output+, **V-**: voltage-output-  
**I+**: current-output +, **I-**: current-output -

#### Analog output two types:

- 1) Voltage output: 0-5V/0-10V is optional .
- 2) Electric current output: 4-20mA/0-20mA/0-24mA is optional.
- 3) User-define function, users can define analog output type and output range.


The analog output has been calibrated before the delivery of the indicators, so users do not need to make calibration. If analog output is abnormal, users can calibrate by themselves as follows: (Suggestion: please calibrate under the instruction of professionals)


Normal display status



SET UP

Note: only support calibration under current mode. 4 points must be finished for current calibration.





This interface is the highest point calibration of analog output.

In the interface of highest point calibration, press to enter into analog display value interface, the display will be 5 digits (initial value is 24000, means


24.000mA), press to input the value measured by the multimeter.


Note: Analog output calibration, highest point must be calibrated.

## 2.4.2 Serial Interface RS485 Output

Serial Interface RS485 output is optional, please refer to chapter 6.0 for communication protocol.


### RS485 serial interface connection:





### 2.4.3 Serial Interface RS232 output (Optional)

**RS232 serial interface connection:**



## 3 Calibration

### 3.1 Instruction

(1) Calibration procedure must be executed when a GMT-P1 indicator is put in use at the first time, the preset parameters may no longer meet the user's needs, and any part of the weighing system was changed. Position of decimal point, minimum division, maximum capacity, zero, and gain can be set and confirmed through calibration.


(2) If you want to set only one parameter, please press   
 to save

parameter's value and then press   
 to exit.

(3) Please see section **3.7** for parameters' instruction.

- (4) Please record each value in the blank table in section 3.4 during calibration for the emergency use in future.
- (5) See chapter 9 for error alarm message that may be displayed during calibration.

### 3.2 Flow Chart of Calibration



1. Under this status, press

**MODE** ► (twice), indicator will display

**CAL**, then press **ENTER** to enter

2. After password is input, the indicator will

display **CALON** for one second, then go to

next step.

88888



Decimal point

888888



Min. divistion

TARE  
OPTION

3. Press **TARE  
OPTION**  to select a desired value for decimal point among **0, 0.0, 0.00, 0.000** and **0.0000**, and then

W/A  
ENTER

press **W/A  
ENTER**  to save it and enter next step.  
If there's no need to change the value,

W/A  
ENTER

press **W/A  
ENTER**  directly to enter next step.

TARE  
OPTION

4. Press **TARE  
OPTION**  to select a desired value for min. division among **1,2, 5,10,20** and **50**, and then to save it and enter next step.

If there's no need to change the Min.division, then

W/A  
ENTER

press **W/A  
ENTER**  directly to enter next step.

000000



Max. capacity

888.268



Millivolt value display

088.268



Zero calibration

5. Input max. capacity( $\leq$ min. division $\times$ 100000),  
 $\frac{W/A}{ENTER}$  ● to save it and enter Millivolt value display interface..

If there's no need to change the max. capacity,

then press  $\frac{W/A}{ENTER}$  ● directly to enter Millivolt display interface.

$\frac{W/A}{ENTER}$  ●

6. Under this status, press  $\frac{W/A}{ENTER}$  ● to enter zero calibration.

Display value near the output value in millivolt between SIG+/SIG- of load cell.

See section 3.3 for details about this function.

7. Unloaded scale first, when STAB lamp is on,

$\frac{W/A}{ENTER}$  ● to finish zero calibration.

If there's no need to calibrate zero,

$\frac{ZERO}{ESC}$  ■


directly to enter gain calibration.

8. The process of gain calibration is as follows. If there's no need to do gain calibration, press

**ZERO** ■  
**ESC**

directly to enter serial ports calibration switch setting.

Gain Calibration



Serial ports  
calibration switch



58808L

Password setting



888888

Normal status

888200

9. Press  $\frac{\text{W/A}}{\text{ENTER}}$  ● to enter setting interface,  
press  $\frac{\text{TARE}}{\text{OPTION}}$  ▲ to choose the switch position,  
press  $\frac{\text{W/A}}{\text{ENTER}}$  ● to set password. If don't need to  
set switch position, then press  $\frac{\text{ZERO}}{\text{ESC}}$  ■ to enter  
password setting.

10. See section 7.2 for reference to set  
password. If there's no need to set  
password, press  $\frac{\text{ZERO}}{\text{ESC}}$  ■ directly to go  
back to normal status.

### 3.3 Millivolt Value Display

This function is mainly used for system test, position-error test for weighing mechanism and linearity test for load cell.

#### 1. System Test

(1) If display data changes with loaded weight changes, it shows that connection of load cell is correct and weighing mechanism works well.

(2) If display value is OFL (or -OFL), it means that loaded weight on load cells is too large (or too small). Please unload the weight (or load more), if display value is still OFL (or -OFL), the possible reasons are as follows:

- a. There is something wrong with weighing mechanism, please check and clear.
- b. The connection of load cell is incorrect, please check and clear.
- c. Load cells may be damaged, please replace.

#### 2. Position-error Test for Weighing Mechanism

Load a same weight on each corner of weighing mechanism and record displayed millivolt value respectively. If differences among these values are obvious, please adjust weighing mechanism.

#### 3. Linearity Test for Load Cell

Load same weight for several times, and record displayed value every time. If one or two values are obviously much larger or smaller than any others, it means that the linearity of load cell is bad.

**\*NOTE: You must use to zero display data before weight is loaded for each time.**

### 3.4 Calibration with Weights

In Chapter 3.2, steps 7 and 8 in the calibration flow chart are operation instructions of calibration zero point and calibration gain with weights


During calibration with weight, please record the zero millivolt value, gain millivolt value and the loaded weight value in the blank table below. If it is not convenient to load a weight to calibrate, these values can be used for calibration without weights.

	Zero millivolt value(mV)	Gain millivolt value(mV)	Loaded Weight	Date	Remarks
1					
2					
3					
4					
5					

### 3.5 No weight calibration

#### 3.5.1 No weight zero Calibration

No weight calibration zero point, it is necessary to record the millivolt value corresponding to the empty balance when the mechanism is calibrated with weight. Zero calibration is accomplished by manually entering historical values.




### 3.5.2 No weight gain Calibration

There are two methods for weighting - free calibration gain

- 1) Historical calibration: Gain calibration by entering historical record values
- 2) Theoretical calibration: Calibrate through sensor sensitivity and maximum range value of input mechanism (the sum of the average value of input sensitivity and maximum range when multiple sensors are connected)


#### Historical gain calibration



- 1) In gain calibration interface, press  $\frac{\text{TARE}}{\text{OPTION}} \blacktriangle$ , and the interface displays 1.

- W/A  
ENTER ● Press ENTER to enter the manual gain millivolt input interface and enter the historical millivolt value.
- W/A  
ENTER ● 2) Press ENTER save to enter the weight input interface and enter the weight value corresponding to the millivolt number.
- W/A  
ENTER ● 3) Press ENTER save to complete gain calibration and enter the serial port calibration switch.

## Sensitivity and gain calibration range



- 1) In gain calibration interface, press twice **TARE OPTION ▲** to enter and choose "2" press enter interface for manual input of sensor sensitivity and input the sensitivity of the actual sensor.
- 2) Press **W/A ENTER**, enter the maximum range input interface and input sensor range.
- 3) Press **W/A ENTER**, complete gain calibration and enter serial port calibration switch.

### 3.6 Calibration Switch for Communication Interface

When calibrate the transmitter through serial port( Rs、SP1 or Modbus), must set to “ON” status for the calibration switch for communication interface.

### 3.7 Explanation for Calibration Parameters


Symbol	Parameter	Types	Value of parameter	Default
Pt	Decimal Point	5	0 0.0 0.00 0.000 0.0000	0
1d	Min. Division	6	1 2 5 10 20 50	1
CP	Max. Capacity		≤Min. Division×100000	10000
t	Millivolt Value			
o	Zero			
C	Gain			
SIOCAL	Switch for Calibration via serial interface			OFF
PASS	Password Setting			000000


## Log Table for Calibration Parameters

Parameter	Calibrated Value	Date	Remarks
Decimal Point			
Min. Division			
Max. Capacity			
Load cell sensitivity			
Password			

## 4 Working Parameters Setting

### 4.1 Flow Chart of Working Parameters Setting






2 .Press **W/A  
ENTER** ● to enter into sub-selection,  
press **ZERO  
ESC** ● to return back to previous menu.

When it displays **F2**, press **W/A  
ENTER** ● to enter into **F2.1**.

## 4.2 Parameter Setting Method

GMT-P1 has 2 kinds of working parameters: Selection type and data type. For selection type parameters, press to choose. For data type parameter in parameter interface, press to choose digit position, press to choose value.



### 4.3 Descriptions of Operation Parameters

Code	Default	Description
F1	Null	<b>The first major term of working parameter.</b>
F1.1	OFF	Switch for Auto-Zeroing when power-on, OFF: disabled ON: enabled
F1.2	0	Zero-tracking Range (0~9d optional). This parameter is for automatic calibration, disabled when is set "0".
F1.3	1	Motion Detecting Range (1~9d optional)
F1.4	50	Zeroing Range (00%~99% of Maximum capacity)
F1.5	5	Digital filtering parameter: (1-9 as optional) 0: without filtering 9: strongest digital filtering
F1.6	0	VF-Filter: 0: without filtering 9: strongest digital filtering
F1.7	0	A/D conversion rate: 120,480,960,15,30,60 as optional
F1.8	0	NET Indicator function switch

		0: NET Indicator light is the function of gross/net weight. Net weight is on, gross weight is off. 1: NET Indicator light has communication indicator function. When there is communication, indicator light flashes
<b>F2</b>	<b>Null</b>	<b>The second major term of working parameter.</b>
<b>F2.1</b>	<b>01</b>	Scale no., indicator no.
<b>F2.2</b>	<b>38400</b>	Baud rate of serial port:1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600
<b>F2.3</b>	<b>Modbus-RTU</b>	Serial ports communication mode: <b>Modbus-RTU: MODBUS RTU mode;</b> <b>r-Cont:SP1 continuous mode;</b> <b>r-SP1: SP1 command mode;</b> <b>tt:TOLEDOcontinuous mode;</b> <b>Cb920: Cb920 continuous mode.</b> <b>rE-Cont:rE continuous mode;</b> <b>rE- rEAd:rEcommand mode;</b>
<b>F2.4</b>	<b>8-E-1</b>	<b>Data format:</b> 7-E-1: 7 data bits, even parity check, 1 stop bit; 7-O-1: 7data bits, odd parity check, 1 stop bit;

		<b>8-E-1:</b> 8 data bits, even parity check, 1 stop bit; <b>8-O-1:</b> 8 data bits, odd parity check, 1 stop bit; <b>8-n-1:</b> 8 data bits, no parity check, 1 stop bit; <b>8-n-2:</b> 8 data bits, no parity check, 2 stop bit;
F2.5	HiLo	<b>MODBUS dual-byte register storage turn.</b> <b>Hi Lo:</b> High byte in the front, low byte at the back; <b>Lo Hi:</b> Low byte in the front, high byte at the back
F2.6	nonE	Cont mode automatic sending time interval
F2.7	0	<b>tt(TOLEDOcontinuous mode)</b> If send the checksum. 0: not send, 1: send. <b>yH: (Cont. mode)</b> 0: send actual weight. 1: send if stable, not send if unstable.
F3	Null	<b>The third major term of working parameter.</b> (For analog output only)
F3.1	0-5	<b>Analog output:</b> 4-20: 4-20mA 0-20: 0-20mA 0-24: 0-24mA 0-5: 0-5V

		<b>0-10: 0-10V</b> <b>I_out:</b> Current customized <b>V_out:</b> Voltage customized In customized mode, <b>F3.2-F3.5</b> parameters available
<b>F3.2</b>	<b>3920</b>	Minimum output
<b>F3.3</b>	<b>4000</b>	Zero point output
<b>F3.4</b>	<b>20000</b>	Maximum capacity output
<b>F3.5</b>	<b>20020</b>	Maximum output
<b>F4</b>	<b>Null</b>	<b>The fourth major term of working parameter.</b>
<b>F4.1</b>	<b>OFF</b>	Parameters password setting switch.
<b>F4.2</b>	<b>000000</b>	Parameters password setting: <b>Valid when F4.1 is ON</b>
<b>F5</b>	<b>Null</b>	Parameter setting refer the 5 <sup>th</sup> term
<b>F5.1</b>	<b>1.00000</b>	Weight correction factor K, weight correction factor K = Expected weight/current weight range: 0-9.99999 <b>When the calibration weight (gain) calibration parameters reset. The value reverts to the default value of 1.00000</b>

#### 4.4 Set point parameters

Code	Default	Description
<b>P1-P4</b>	<b>Null</b>	<b>The first term of working parameters</b>

PX.1	OFF	Change of state if need stable
PX.2	0.0	Change of state minimum duration
PX.3	P1.3=1 P2.3=5 P3.3=0 P4.3=0	<p>Comparing conditions:</p> <p>0: forbid; No Comparing</p> <p>1: &lt; Less than; If the weight displayed by the indicator is less than PX.4, I/O Module is effective when it outputs the set point X, otherwise the output is invalid</p> <p>2: &lt;= Less than or equal to; The weight displayed by the indicator is less than or equal to PX.4, the output of I/O Module output set point X is valid, otherwise the output is invalid.</p> <p>3: == Equal; The weight displayed by the indicator is equal to PX.4 items. The output of I/O Module output set point X is valid, otherwise the output is invalid.</p> <p>4: &gt;= Bigger than or equal to; If the weight displayed by the indicator is bigger than or equal to PX.4, the output of the I/O Module is effective and the output of the set point X is invalid</p> <p>5: &gt; Bigger than; If the weight displayed by the indicator is</p>

		<p>bigger than PX.4, the output of the I/O Module is effective, and the output of the set point X is invalid</p> <p>6: != not equal to; The weight displayed by the indicator is not equal to PX.4 items, the output of I/O Module output set point X is valid, otherwise the output is invalid</p> <p>7: _&lt;&gt;_ Outside the interval, if the weight displayed by the indicator is less than or greater than PARx.4 or parx.5, the output of set point X of the I/O Module is effective, otherwise the output is invalid</p> <p>8: =&lt;_ &gt;= Within the interval, when the weight displayed by the indicator is bigger than or equal to PARx.4 and less than or equal to Parx.5, the output of the I/O Module at set point X is effective, otherwise, the output is invalid.</p> <p>9: external trigger. If it's IO, do 1 state change for 1 trigger, if it's command, then decide according to valid or invalid command.</p>
PX.4	0	Set value 1; 0 ~ 999999 can be set
PX.5	0	Set value 2; 0 ~ 999999 can be set

Set point has **4** major terms which are user defined.

## 5 I/O Definition

### 5.1 I/O Definition

Output/Input code table:

Output		
Code	Definition	Description
00	None	No definition
01	Stable	Effective output in stable status.
02	Overflow	Effective output when overflow.
03	Sp1	Effective output when set point <b>1</b> status output.
04	Sp2	Effective output when set point <b>2</b> status output.
05	Sp3	Effective output when set point <b>3</b> status output.
06	Sp4	Effective output when set point <b>4</b> status output.

Input		
Code	Definition	Description
I0	None	No definition
I1	Zeroing	Effective input for zeroing, pulse input signals
I2	Sp1	If this signal is valid, Sp1 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I3	Sp2	If this signal is valid, Sp2 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I4	Sp3	If this signal is valid, Sp3 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I5	Sp4	If this signal is valid, Sp4 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.

I6	Reset all	Reset all parameter value when this signal is valid.
I7	Clear/Add tare	Clear tare when this signal is valid at first time, and add tare at the second time.
I8	Clear tare	Clear tare when this signal is valid.
I9	Add tare	Add tare when this signal is valid.
I10	Calibration lock	After the function is defined, the signal is valid (level signal), and then the password input state of the first item in the calibration step can be entered; otherwise, it cannot be entered, and an alarm Error7 is prompted. If this function is defined, MODBUS cannot perform serial port calibration.

## 5.2 I/O testing

8.8.8.8.18



Normal Status



Under weighing status, press  
display TESTIo, press interface.



(5 times)



enter into I/O testing

8.8.8.8.8.

↔ Press TARE  
OPTION ▲

OUT1 status flash,

press MODE → OUT2 status flash

0.8.8.8.8.

↔

This interface shows: IN1 input valid, OUT1 output valid.

## 6 Serial Communication

GMT-P1 has RS232 or RS485 as optional to realize communication with upper computer. Support r-Cont, r-SP1, Modbus(bus), tt TOLEDO, Cb920, rECont protocols and rErEAD protocol.

Serial communication terminal please refer to chapter 2.4.2、2.4.3. Baud rate and communication format setting please refer to F2.2、F2.3 and F2.4.

※Under main display(display weight value), long press  to enter into serial communication checking interface, it will display '-----' if no communication, and '-----' will flash if there's communication.

### 6.1 r-Cont

Indicator will send weighing data to host computer without command.

Data Format:

STX	Scale no.	Channel no.	Status	Value	CRC	CR	LF
-----	-----------	-------------	--------	-------	-----	----	----

Here:

**STX** —— 1byte, start character **02H**

**Scale no.** —— 2bytes, **00~99**

**Status** —— 2bytes, high byte:**40H**; low byte definition as follows:

D6	D5	D4	D3	D2	D1	D0
Null	Null	G./N. weight	+/-	Zero point	OFL	Stable
1	0	0: G 1: N	0: + 1: -	0: non/zero 1: zero	0: normal 1: OFL	0: not stable 1: stable

Weight Value —— 6 bytes; when weight is+(-)overflow,return to“space space **OFL** space”

**CRC** —— 2 bytes,check sum

**CR** —— 1 byte, **0DH**

**LF** —— 1 byte, **0AH**

For example:

**02 30 31 31 40 41 20 20 20 37 30 30** (present weight) **32 34 0D 0A**

Means: stable,positive data,present weight 700

## 6.2 r-SP1

Code : **ASCII**

Operation code supported: **W**, write; **R**, read; **C**, calibrate; **O**, zero

### 6.2.1 Parameters Code Chart

Operation code	Para code	Para. Name	number of character
<b>R</b>	<b>WT</b>	Read current status	<b>8</b>

		and weight	
C	ZY	Zero calibration with weight	
C	ZN	Zero calibration without weight	6
C	GY	Gain calibration with weight	6
C	GN	Gain calibration without weight	12
R	AM	Absolute millivolt	7: D6D5D4D3D2D1D0; D6:+;D5-D0: corresponding ASCII for 6 digits millivolt, Decimal point is fixed to 3 digits
R	RM	Relative zero point on millivolt	7: D6D5D4D3D2D1D0 D6: +/-;D5-D0: corresponding ASCII for 6 digits , Decimal point is fixed to 3
O	CZ	Zero clearing command	

### 6.2.2 Error Code Explanation

- 1: CRC check error
- 2: Operation code error

- 3:** Parameters code error
- 4:** Write data error
- 5:** Operation invalid
- 6:** Channel no. error

Note : Default channel no. of this indicator : **1 (31H)**

### **6.2.3 Command**

Indicator will send weighing data to host computer after received command.

#### **6.2.3.1 Host computer read present status**

Send command:

<b>STX</b>	Scale no.	Channel No.	<b>R</b>	<b>WT</b>	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	------------	-----------	-----------

Correct response:

<b>STX</b>	Scale no.	Channel No.	<b>R</b>	<b>WT</b>	Status	Value	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	--------	-------	------------	-----------	-----------

Wrong response:

<b>STX</b>	Scale no.	Channel No.	<b>R</b>	<b>WT</b>	<b>E</b>	Error code	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here :

**STX** —— 1byte, start character, **02H**

**R**——1 byte, **52H**

**WT**——2 byte, **57H 54H**

**E——1 byte, 45H**Status —— 2bytes, high byte: **40H**; low byte definition as follows:

D6	D5	D4	D3	D2	D1	D0
Null	Null	G./N. weight	+/-	Zero point	OFL	Stable
1	0	0: G 1: N	0: + 1: -	0: non/zero 1: zero	0: normal 1: OFL	0: not stable 1: stable

Weight Value —— 6 bytes; when weight is+ (-) overflow,return to“space space **OFL** space”

For example:

**02 30 31 31 52 57 54 30 31 0D 0A**Correct response : **02 30 31 31 52 57 54 40 4130 30 33 37 35 33 33 36 0D 0A**  
**(stable present value 3753)**Wrong response: **02 30 31 31 52 57 54 45 31 31 39 0D 0A** (CRC check error)**6.2.3.2 Read other parameters**

Send command:

<b>STX</b>	Scale no.	Channel No.	R	Para. code	CRC	CR	LF
------------	-----------	-------------	---	------------	-----	----	----

Correct response:

<b>STX</b>	Scale no.	Channel No.	R	Para. code	Value	CRC	CR	LF
------------	-----------	-------------	---	------------	-------	-----	----	----

Wrong response:

<b>STX</b>	Scale no.	Channel No.	<b>R</b>	<b>Para. code</b>	<b>E</b>	Error code	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-------------------	----------	------------	------------	-----------	-----------

Here:

**Para. Value**—1byte

**Para. code**—2 bytes,

For example:

**02 30 31 31 524D52 3839 0D 0A**

Correct response: **02 30 31 31 52 4D 52 36 34 33 0D 0A** (stable range: 6)

Wrong response:**02 30 31 31 53 4D 52 45 32 30 39 0D 0A** (Operation code error)

### 6.2.3.3 Write max. Capacity and min. Division

Send command:

<b>STX</b>	Scale no.	Channel No.	<b>W</b>	<b>DC</b>	Division value	Max. capacity	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------------	---------------	------------	-----------	-----------

Correct response:

<b>STX</b>	Scale no.	Channel No.	<b>W</b>	<b>DC</b>	<b>O</b>	<b>K</b>	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

<b>STX</b>	Scale no.	Channel No.	<b>W</b>	<b>DC</b>	<b>E</b>	Error code	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

**DC**—2 bytes, **44H 43H**

O—1 byte, 4FH

K—1 byte, 4BH

Division value—2 bytes, 1/2/5/10/20/50

Max. capacity—6 bytes

For example:

02 30 31 3157 44 43 30 35 30 31 30 30 30 30 36 30 0D 0A (division value 5, Max capacity 10000)

Correct response: 02 30 31 31 57 44 43 4F 4B 32 34 0D 0A

Wrong response: 02 30 31 31 57 44 43 45 35 39 32 0D 0A (Operation can't execute)

#### 6.2.3.4 Write other parameters

Send command:

STX	Scale no.	Channel No.	W	Para. code	Para. value	CRC	CR	LF
-----	-----------	-------------	---	------------	-------------	-----	----	----

Correct response:

STX	Scale no.	Channel No.	W	Para. code	O	K	CRC	CR	LF
-----	-----------	-------------	---	------------	---	---	-----	----	----

Wrong response:

STX	Scale no.	Channel No.	W	Para. code	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	------------	---	------------	-----	----	----

For example:

02 30 31 3157 5A 52 35 30 30 38 0D 0A (Write zeroing range to 50)

Correct response: **02 30 31 31 57 5A 52 4F 4B 36 31 0D 0A**

Wrong response: **02 30 31 31 57 5A 53 45 33 32 38 0D 0A** (Para. Code error)

### 6.2.3.5 Calibration Zero

#### 1) Calibrate zero as per current weight (with weight)

Send command:

<b>STX</b>	Scale no.	Channel No.	<b>C</b>	<b>ZY</b>	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	------------	-----------	-----------

Correct response:

<b>STX</b>	Scale no.	Channel No.	<b>C</b>	<b>ZY</b>	<b>O</b>	<b>K</b>	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

<b>STX</b>	Scale no.	Channel No.	<b>C</b>	<b>ZY</b>	<b>E</b>	Error code	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

**Z**—1 byte, 5AH

**Y**—1 byte, 59H

For example:

**02 30 31 31 43 5A 59 39 34 0D 0A**

Correct response:**02 30 31 31 43 5A 59 4F 4B 34 38 0D 0A**

Wrong response:**02 30 31 34 43 5A 59 45 36 32 30 0D 0A** (channel no. error)

#### 2) Input millivolt calibration zero in the chart (without weight)

Send command:

<b>STX</b>	Scale no.	Channel No.	<b>C</b>	<b>ZN</b>	Zero millivolt value	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------------------	------------	-----------	-----------

Correct response:

<b>STX</b>	Scale no.	Channel No.	C	ZN	O	K	<b>CRC</b>	CR	LF
------------	-----------	-------------	---	----	---	---	------------	----	----

Wrong response:

<b>STX</b>	Scale no.	Channel No.	C	ZN	E	Error code	<b>CRC</b>	CR	LF
------------	-----------	-------------	---	----	---	------------	------------	----	----

Here:

**ZN**—2 bytes, 5AH4EH

Zero millivolt value—6 bytes

For example:

**02 30 31 31 43 5A 4E 30 31 32 36 31 30 38 31 0D 0A**

Correct response: 02 30 31 31 43 5A 4E 4F 4B 33 37 0D 0A

Wrong response: 02 30 31 31 43 5A 4E 45 34 30 34 0D 0A (Write data error)

### 6.2.3.6 Gain calibration

#### 1) With weights

Send command:

<b>STX</b>	Scale no.	Channel No.	C	GY	Weight value	<b>CRC</b>	CR	LF
------------	-----------	-------------	---	----	--------------	------------	----	----

Correct response:

<b>STX</b>	Scale no.	Channel No.	C	GY	O	K	<b>CRC</b>	CR	LF
------------	-----------	-------------	---	----	---	---	------------	----	----

Wrong response:

<b>STX</b>	Scale no.	Channel No.	C	GY	E	Error code	<b>CRC</b>	CR	LF
------------	-----------	-------------	---	----	---	------------	------------	----	----

Here:

**GY**—2 bytes, 47H 59H

Weight value—6 bytes: Write in weight value

For example:

**02 30 31 3143 47 59 30 30 30 32 30 30 36 35 0D 0A** (Write in: weight value **200**)

Correct response: **02 30 31 31 43 47 59 4F 4B 32 39 0D 0A**

Wrong response: **02 30 31 35 43 47 59 45 36 30 32 0D 0A** (Channel no. error)

## 2) Without weights

Send command:

STX	Scale no.	Channel No.	C	GN	Gain millivolt	Weight value	CRC	CR	LF
-----	-----------	-------------	---	----	----------------	--------------	-----	----	----

Correct response:

STX	Scale no.	Channel No.	C	GN	O	K	CRC	CR	LF
-----	-----------	-------------	---	----	---	---	-----	----	----

Wrong response:

STX	Scale no.	Channel No.	C	GN	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	----	---	------------	-----	----	----

Here:

Gain millivolt—**6 bytes**

Weight value—**6bytes**

For example:

**02 30 31 3143 47 4E 30 30 31 39 34 30 30 30 30 32 30 30 35 36 0D 0A** (Write in:

weight value **200**, corresponding gain millivolt **0.194**)

Correct response: **02 30 31 31 43 47 4E 4F 4B 31 38 0D 0A**

Wrong response: **02 30 31 31 43 48 4E 45 33 38 35 0D 0A** (Para. Code error)

## 6.2.3.7 Zeroing

Send command:

<b>STX</b>	Scale no.	Channel No.	<b>O</b>	<b>CZ</b>	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	------------	-----------	-----------

Correct response:

<b>STX</b>	Scale no.	Channel No.	<b>O</b>	<b>CZ</b>	<b>O</b>	<b>K</b>	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

<b>STX</b>	Scale no.	Channel No.	<b>O</b>	<b>CZ</b>	<b>E</b>	Error code	<b>CRC</b>	<b>CR</b>	<b>LF</b>
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

For example:

**02 30 31 31 4F 43 5A 38 34 0D 0A**

Correct response: **02 30 31 31 4F 43 5A 4F 4B 33 38 0D 0A**

Wrong response: **02 30 31 31 4F 43 5A 45 35 30 36 0D 0A** (Operation can't execute)

### 6.2.3.8 CRC computation

All the values in front of the parity byte add together and convert to decimal data, then convert the last 2 bytes to **ASCII** code (decade in front and the unit at the back).

For example

The following is a frame of data:

<b>02</b>	<b>30</b>	<b>31</b>	<b>31</b>	<b>4F</b>	<b>43</b>	<b>5A</b>	<b>38</b>	<b>34</b>	<b>0D</b>	<b>0A</b>
-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------

Add **02~5A**: **180**(Hex), convert to decimal data: **384**. We can calculate from this that the check code is **38,34** for the data frame.

## 6.3 tt TOLEDO Protocol

When choose "tt" protocol in working parameter F2.3, indicator will send datas in continuous mode with TOLEDO protocol.

Continuous sending mode format as below:

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
STX															0D		

~ A B C display weight(6 bytes: is synchronized with display ) 6个 30H

Checksum

Here: start character is standard **ASCII** start character **02(STX)**

status byte **A** definition as below:

D0	0	1	0	1	0
D1	1	1	0	0	1
D2	0	0	1	1	0
Decimal point	x	.x	.xx	.xxx	.xxxx

D3 D4 D6 为 0(not change) D5 is 1(not change)

status byte **B** definition as below:

D6	D5	D4	D3	D2	D1	D0
Status			Stable	Overflow	symbol	G.W.
Is 0 (not change)	Is 1 (not change)	Is 1 (not change)	1-unstable 0-stable	1-overflow 0-normal	1-negative 0-positive	0-G 1-N

status byte **C** is reserved, output 20H.

#### 6.4 Cb920

When **F2.3=Cb920** in working parameter, indicator will send weighing data continuously without command under **Cb920** protocol.

Data format:

Status	,	G.W.	0/1	Symbol	Display	Unit	CR	LF
--------	---	------	-----	--------	---------	------	----	----

Here :

**Status** —— 2 bytes, **OL**: ( 4FH 4CH ) OFL; **ST**: ( 53H 54H )Stable; **US**: ( 55H

**53H** )unstable

, —— 1 byte, separator **2CH**

**G.W.** —— 2 bytes, **GS:** gross weight **47H 53H.** **NT:** net weight **4EH 54H**

**0/1** —— 1 byte, (30H/31H) interleaved transmission

**Symbol** —— 1 byte, **2BH (+)** , **2DH (-)**

**Display** —— 7 bytes, including decimal point: display weight value.

**Unit** —— 2 bytes, blank space (**20H 20H**)

**CR** —— 1 byte, **0DH**

**LF** —— 1 byte, **0AH**

For example: When indicator send the following automatically:

**53 54 2C 47 53 31 2B 20 20 31 39 30 2E 31 20 20 0D 0A**

Means: Stable、G.W.、Data value is positive、current weight is **190.1**

## **6.5 rECont**

Indicator will send weighing data to the upper computer continuously without any command.

Return data frame format specification :

Status	,	GS/ NT	,	+/-	Display	Unit	CR	LF
2bytes	2C	47 53/4E 54	2C	2B/2D	7bytes	6B 67	0D	0A

Here:

Status —— **2 bytes**, OL(OFL):**4FH 4CH**; ST(stable):**53H 54H**; US(unstable):**55H 53H**

Display value —— **7bytes**, including decimal point, high byte is blank if no decimal point.

For example: When indicator send the following automatically:

**53 54 2C 47 53 2C 2B 30 31 31 2E 31 32 30 6B 67 0D 0A**

Means: Stable, Data value is positive, display value is **11.120kg**

## 6.6 rEREAD

Indicator will send weighing data to the upper computer under command.

Data format:

Data	R	E	A	D	CR	LF
explain	<b>52H</b>	<b>45H</b>	<b>41H</b>	<b>44H</b>	<b>0DH</b>	<b>0AH</b>

The return data frame is the same with that of **rECont** protocol, please refer to **rECont**.

- 1) Zero clearing command: ZERO ON<CR><LF> : **5A 45 52 4F 20 4F 4E 0D 0A**  
Return YES<CR><LF> or NO? <CR><LF>
- 2) Calibration zeroing command: TARE ON<CR><LF> : **54 41 52 45 20 4F 4E 0D 0A**  
Return YES<CR><LF> or NO? <CR><LF>
- 3) Read ID no.: GET ID<CR><LF> : **47 45 54 20 49 44 0D 0A**  
Return ASCII code with 6 digits ID no.

## 6.7 Modbus

Indicator uses **RTU mode** to communicate, every 8-bit byte of the message are divided into 2pcs of 4-bit hexadecimal characters to transmit at binary code.

**Code: Binary**

**Function code:**

Function code	Definition	Description
03	read the register	
06	preset single register	

<b>16</b>	preset several registers	Command only support preset double registers.
<b>01</b>	read coil	
<b>05</b>	<b>write coil</b>	The length unit is bit.

**Exception code response**

<b>Code</b>	<b>Definition</b>	<b>Description</b>
<b>02</b>	Illegal data address	Data address received from error code is not allowed
<b>03</b>	Illegal data value	Data wrote in is not in permissible range
<b>04</b>	machine fault	When indicator is trying to execute operation required, unrecoverable error is produced.
<b>07</b>	Unsuccessful programming request	Command received can't be executed under current condition.

**6.7.1 Modbus communication address**

<b>PLC addr.</b>	<b>Display addr.</b>	<b>Description</b>
<b>The following items are only-read register(code 0x03)</b>		
<b>40001</b>	<b>0000</b>	Present weight value(4bytes including sign characters, the high byte is in the front)
<b>40002</b>	<b>0001</b>	



		,1: For communication indication
40017~ 40018	0016~ 0017	Reserved
40019	0018	Decimal point place (0:0,1:0.0,2:0.00,3:0.000,4:0.0000)
40020	0019	Minimum division (1/ 2/ 5/ 10/ 20/ 50)
<b>The following items are available to read and write (writing code 0x10, read code 0x03)</b>		
40021	0020	Maximum capacity (max.capacity≤mini.division×1000000)
40022	0021	
40023	0022	Zero calibration with weights: write in 1 and calibrate zero with the current weight. Read: Absolute millivolt of current load cell
40024	0023	
40025	0024	Zero calibration without weights: Write millivolt value at zero; Write in range (load cell 3mV/V:millivolt value range within 0.02-12.000mV) millivolt value at zero when read.
40026	0025	
40027	0026	Gain calibration with weights. Write weight value(≤max. capacity). Return millivolt at present weight value when read
40028	0027	
40029	0028	Gain calibration without weights ; input gain millivolt(load cell 3mV/V:0.000 < millivolt<15.000mV — zero
40030	0029	

		millivolt).Read: millivolt value for gain calibration.
<b>40031</b>	<b>0030</b>	Gain calibration weight without weights. input gain millivolt( $\leq$ max. capacity) Read: weight value for gain calibration.
<b>40032</b>	<b>0031</b>	Gross weight, with symbol
<b>40033</b>	<b>0032</b>	Net weight
<b>40034</b>	<b>0033</b>	
<b>40035</b>	<b>0034</b>	
<b>40036</b>	<b>0035</b>	
<b>40037</b>	<b>0036</b>	Tare weight
<b>40038</b>	<b>0037</b>	
<b>40039~40040</b>	<b>0038~0039</b>	Reserved
<b>40041</b>	<b>0040</b>	Set point <b>1 stable or not (0: no; 1: yes)</b>
<b>40042</b>	<b>0041</b>	Set point <b>1 min. duration time (0-999 : 0-99.9sec.)</b>
<b>40043</b>	<b>0042</b>	Set point <b>1 valid condition</b>
<b>40044~40045</b>	<b>0043~0044</b>	Set point <b>1 set value 1</b>
<b>40046~40047</b>	<b>0045~0046</b>	Set point <b>1 set value2</b>
<b>40048</b>	<b>0047</b>	Set point <b>2 stable or not (0: no; 1: yes)</b>
<b>40049</b>	<b>0048</b>	Set point <b>2 min. duration time (0-999 : 0-99.9sec.)</b>
<b>40050</b>	<b>0049</b>	Set point <b>2 valid condition</b>

40051~40052	0050~0051	Set point <b>2</b> set value1
40053~40054	0052~0053	Set point <b>2</b> set value2
40055	0054	Set point <b>3 stable or not</b> (0: no; 1: yes)
40056	0055	Set point <b>3</b> min. duration time ( <b>0-999 : 0-99.9sec.</b> )
40057	0056	Set point <b>3 valid condition</b>
40058~40059	0057~0058	Set point <b>3</b> set value 1
40060~40061	0059~0060	Set point <b>3</b> set value 2
40062	0061	Set point <b>4 stable or not</b> (0: no; 1: yes)
40063	0062	Set point <b>4</b> min. duration time ( <b>0-999 : 0-99.9sec.</b> )
40064	0063	Set point <b>4 valid condition</b>
40065~40066	0064~0065	Set point <b>4</b> set value 1
40067~40068	0066~0067	Set point <b>4</b> set value 2
40069	0068	Output 1 user-defined
40070	0069	Output 2 user-defined
40071	0070	Input 1 user-defined
40072	0071	I/O output value  Note: available only when coil address 00016 is valid.  Input write 1 valid, 0 invalid. Read 1 valid, 0 invalid
40073	0072	I/O input value

<b>Reserved</b>			
<b>40401</b>	<b>0400</b>	Current weight value( 4 bytes with symbolic number, high digit in front)	
<b>40402</b>	<b>0401</b>		
<b>40403</b>	<b>0402</b>	D15—D14.....D4 0 D3 0:+ 1:- D2 0:non-zero 1:zero D1 0:normal 1:OFL D0 0:Stable 1:Unstable	
<b>40404</b>	<b>0403</b>	0	
<b>40405</b>	<b>0404</b>		
<b>40406</b>	<b>0405</b>	6 digits without symbolic number, user ID no.	
<b>The following items are byte read only. (read code: 0x03)</b>			
<b>49001</b>	<b>9000</b>	Version no.	If display 10024, format XX XXXX, main version no., hardware no., software no.. So main version no. 01, hardware no. 00, software no. 24
<b>49002</b>	<b>9001</b>		
<b>49003</b>	<b>9002</b>	Develop time	If display 141024, means 24 <sup>th</sup> Oct., 2014
<b>49004</b>	<b>9003</b>		
<b>The following items are byte read only. (read code: 0 x 0 1)</b>			

<b>00001</b>	<b>0000</b>	0: unstable; 1: stable
<b>00002</b>	<b>0001</b>	0: normal; 1: OFL
<b>00003</b>	<b>0002</b>	0: non-zero; 1: zero
<b>00004</b>	<b>0003</b>	0: +; 1: -
<b>00005</b>	<b>0004</b>	<b>Reserved</b>
<b>00006</b>	<b>0005</b>	<b>Reserved</b>
<b>The following item are available to read and write (read code: 0x01, writing code: 0x05)</b>		
<b>00007</b>	<b>0006</b>	Automatically zeroing when power on (0: OFF; 1: ON)
<b>00008</b>	<b>0007</b>	<b>Reserved</b>
<b>00009</b>	<b>0008</b>	<b>Reserved</b>
<b>00010</b>	<b>0009</b>	Reset all
<b>00011</b>	<b>0010</b>	Reset calibration
<b>00012</b>	<b>0011</b>	Reset parameters
<b>00013</b>	<b>0012</b>	Reset I/O
<b>00014</b>	<b>0013</b>	<b>Reserved</b>
<b>00015</b>	<b>0014</b>	<b>Reserved</b>
<b>00016</b>	<b>0015</b>	I/O testing switch
<b>00017</b>	<b>0016</b>	Set point 1 status
		Only read:

<b>00018</b>	<b>0017</b>	Set point 2 status	0:invalid, 1:valid	
<b>00019</b>	<b>0018</b>	Set point 3 status		
<b>00020</b>	<b>0019</b>	Set point 4 status		
<b>00021</b>	<b>0020</b>	Zero calibration (Set on, and then write ON to start calibration.)		
<b>00022</b>	<b>0021</b>	Zero (Zeroing when write ON)		
<b>00023</b>	<b>0022</b>	Clear tare (Clearing tare when write ON)		
<b>00024</b>	<b>0023</b>	Add tare (Adding tare when write ON)		
<b>00025</b>	<b>0024</b>	Gross/Net change (Only read 0: gross weight; 1: net weight)		
<b>00026~ 00032</b>	<b>0025~ 0031</b>	<b>Reserved</b>		

## 7 Password Input and Setting, Reset

### 7.1 Password Input

- (1) Indicator calibration and working paraters setting default password: **000000**.
- (2) User can set password in parameters when **F4.1** is“ON”.
- (3) When display is “PASS”, need to input correct password to enter parameters.


Note:

- (1) When input password, if first time wrong, it will go to the second chance for password input(display from **0 - - - -** turn to **0 - - - - -**).
- (2) If second input wrong, it will enter into interface for inputting password the third time  
(Display change from **0 - - - -** to **0 E E E E**).
- (3) If Input wrong for three times, main display show “Error4” and self-lock, but user can operate when power on again.

### 7.2 Password Setting

- (1) User can set password in parameters when **F4.1** is“ON”.


- (2) User must input same new password twice in setting password, If not same, main display show "Error" one second and return to **PASS** again.




## 7.3 Factory Reset

Note: Factory reset is only for special technicians, which will reset all of parameters and will maybe cause not working.

Take reset all for example:





1) In **F SET** interface, press to reset working parameters, enter into reset calibration parameters interface.

2) In **F SET** interface, press , not to make working parameter reset, enter into calibration para. Reset interface.

1) In **F CAL** interface, press to reset calibration para., enter into reset all interface.


2) In **F CAL** interface, press , not to make calibration para. reset, enter into reset all interface.

1) In **F ALL** interface, press to make reset all of the parameters (including working para., calibration para., I/O etc..).

Note: In all reset interfaces, press to exit and return to weighing interface.

## 8 Display Testing

The following flow chart is to test lights on main-display and status lights.



## 9 Errors and Alarm Messages

**Error ①** Input error.

② wrong data beyond parameter range.

**Error 2** The present weight value is out of zeroing range.

**Error 3** Scale platform is not stable when zeroing.

**Error 4** Input wrong password more than 3 times.

**Error 5** The present weight value is overlimit when clearing tare.

**Error 6** The present weight value showed is unstable when clearing tare.

**OFL** Weighing value is positive overflow.

**-OFL** Weighing value is negative overflow.

## 10 Indicator model user-defined function

The custom model of the indicator displayed after the indicator is powered on. Through the relevant operation of the indicator, you can customize the model content displayed on the indicator. Steps are as follows:

1. When power on,

Flash twice 8 after power on, and then display model, display model 3s turn to main display interface, long press MODE key under the menu interface display after the "LOGO" press Enter into custom Settings interface model, under the current interface, press MODE key to choose, the OPTION button to adjust a particular character values, save the change, indicator boot will show the changed model; If no changes are made to the indicator model, the indicator will default to GMT-P1.(note: reset out of position indicator model)

2. After entering the model user-defined interface, the 6-bit main display character can be defined. MODE key can be used to adjust and select a certain character. Characters can be adjusted by using the OPTION key. The sequence of character changes is space, -, 0~9, A~Z (according to the display character comparison table, as



shown in the appendix), and press Enter to save the current modified value.

### Displays character comparison table

a <sup>v</sup>	b <sup>v</sup>	c <sup>v</sup>	d <sup>v</sup>	e <sup>v</sup>	f <sup>v</sup>	g <sup>v</sup>	h <sup>v</sup>	i <sup>v</sup>	j <sup>v</sup>	k <sup>v</sup>	l <sup>v</sup>	m <sup>v</sup>
A <sup>v</sup>	b <sup>v</sup>	C <sup>v</sup>	d <sup>v</sup>	E <sup>v</sup>	F <sup>v</sup>	G <sup>v</sup>	H <sup>v</sup>	I <sup>v</sup>	J <sup>v</sup>	K <sup>v</sup>	L <sup>v</sup>	M <sup>v</sup>
n <sup>v</sup>	o <sup>v</sup>	p <sup>v</sup>	q <sup>v</sup>	r <sup>v</sup>	s <sup>v</sup>	t <sup>v</sup>	u <sup>v</sup>	v <sup>v</sup>	w <sup>v</sup>	x <sup>v</sup>	y <sup>v</sup>	z <sup>v</sup>
N <sup>v</sup>	O <sup>v</sup>	P <sup>v</sup>	Q <sup>v</sup>	R <sup>v</sup>	S <sup>v</sup>	T <sup>v</sup>	U <sup>v</sup>	V <sup>v</sup>	W <sup>v</sup>	X <sup>v</sup>	Y <sup>v</sup>	Z <sup>v</sup>

## 11 Dimension of Indicator

Dimension of rear panel: **92×45(mm)**



Dimension of front panel: **105×57(mm)**

Panel cutout dimension: **93×46(mm)**

