



**AF-25K II -103B /AF-50 K II -103B**

**Auto filler**

# Operating instruction

杰·曼·科·技

531701020018 Ver A0

## Content

1. overview.....	1
1.1 Product parameters, functions and features .....	1
1.1.1 Product parameters .....	1
1.1.2 Product features.....	1
1.1.3 Product features.....	2
1.2 Working principle .....	2
1.3 Main purpose and scope of application .....	2
2. Precautions for safe use.....	3
2.1 Safe operation .....	3
2.1.1 Basic Safety Instructions.....	3
2.1.2 Operation safety instructions .....	3
3. Product installation and transportation protection .....	5
3.1 The overall appearance and mechanism of the product are introduced .....	5
3.2 The installation conditions.....	6
3.2.1 Equipment installation basis and installation conditions.....	6
3.3 Unpacking and inspection.....	6
3.3.1 The crates .....	6
3.3.2 Spare parts .....	7
3.4 Product packaging and transportation protection .....	7

3.4.1	Packaging requirements .....	7
3.4.2	Transport protection .....	8
3.4.3	Remove transport limit protection .....	8
3.4.4	Requirements for equipment installation and maintenance ....	9
4.	Product size .....	10
4.1	AF-25KII-103B Overall dimensions .....	11
4.2	AF-50KII-103B Overall dimensions .....	13
5.	Electrical connections .....	15
5.1	Air supply connection .....	15
5.2	Electrical connections.....	15
5.2.1	External interface definition.....	16
5.2.2	Switching value interface wiring description .....	17
6.	The Modbus address table .....	19
7.	Touch screen Operation Instructions (optional) .....	49
7.1	Login screen.....	49
7.2	Touch screen login permission description.....	51
7.3	Main Interface description.....	52
7.4	The parameter setting page is described .....	53
7.5	Description of working parameters .....	55
7.6	Description of formula parameters.....	58
7.7	Calibration interface description .....	61

7.8	Step of weight calibration.....	62
7.9	Material calibration steps .....	62
7.10	Description of switch quantity interface .....	64
7.11	Control Parameters screen Description.....	69
7.12	Communication Parameters screen description.....	70
7.13	Historical data page description.....	72
7.14	Description of automatic balance adjustment interface.....	73
7.15	Describes the user management interface .....	74
7.16	System information interface description.....	75
8.	Basic Function description.....	78
8.1	Basic running process .....	78
8.2	Overage and underage detection function.....	78
8.3	Overage and underage detection function.....	79
9.	Common failure analysis and troubleshooting .....	81
10.	Maintenance and warranty.....	82

Shenzhen General Measure Technology Co., Ltd. All rights reserved.

Without the permission of Shenzhen General Measure Technology Co., Ltd., no unit or individual shall reproduce, disseminate, transcribe or translate into any other language version in any form or means.

As our products are constantly improving and updating, we reserve the right to modify this manual at any time without prior notice. To this end, please visit the company website frequently for timely information.

Company website: <http://www.gmweighing.com>

## 1. overview

AF-25KII-103B / AF-50KII-1036B automatic quantification unit is a weighing component for automatic quantification of granular materials. The feeding mechanism adopts the mode of "motor + vibration feeder" to realize multi-stage feeding, and the unloading is driven by cylinder to realize fast unloading. The product has the characteristics of high speed, high precision and wide range, which can be widely used in the quantitative packaging machinery of grain, feed, chemical, rubber and plastic industries.

### 1.1 Product parameters, functions and features

#### 1.1.1 Product parameters

model	AF-25KII-103B	AF-50KII-103B
Electrical source	AC220V±10%, 50/60Hz, 2000W	AC220V±10%, 50/60Hz, 2000W
The quantitative range	5~25kg	10~50kg
The weighing accuracy	±10g	±20g
Weighing speed	≥1600pcs/hour	≥1500pcs/hour
Metering bucket volume	55L*2	86L*2
Working temperature	0~40°C	0~40°C
Maximum humidity	90% OF R.H is not dewy	90% OF R.H is not dewy
Gas source	0.4 ~ 0.6 MPa after 2 m/h	0.4 ~ 0.6 MPa after 2 m/h

Note: packaging accuracy and speed may fluctuate due to material, feed and other environmental factors. The precision and speed are the test data of using round grain rice in our company's test line.

#### 1.1.2 Product features

1. Automatic weighing function.
2. Three material speed (free blanking + vibration feeding) feeding control.
3. Automatic zero clearing function.
4. Automatic correction function of process control parameters.

5. Accumulative and statistical functions.

### 1.1.3 Product features

1. Intelligent: only set the target value, and automatically adjust the optimal quantitative speed under the condition of ensuring the accuracy.
2. Simple installation: standard external interface flange, quick installation.
3. Data export: with USB interface, data record export is more convenient.
4. Simple operation: 7 inch /10 inch touch screen, Chinese and English display (optional).
5. Material: 304 stainless steel for contact material.
6. High speed, high precision: the combination of feeding (free feeding + vibration feeding), both fast and accurate.

## 1.2 Working principle

The equipment starts the three-material fast feeding process, namely: fast, medium and slow feeding. The switch of each speed feeding takes the corresponding advance quantity in the formula as the control cut-off point. In order to avoid the influence of overshoot on measurement, the corresponding prohibition discriminant time is set. After feeding, enter the value setting process, the value setting time can be set, after the end of the value, the equipment through the switch output "feeding complete" signal; The equipment receives the external "unloading" effective switching signal, the equipment will drive the cylinder to open the unloading door of the metering bucket, when the weight of the material in the metering bucket is lower than the zero zone value set before, the equipment drives the cylinder to close the unloading door, complete a quantitative process; Before starting the next quantification process, the equipment carries out a pre-feeding delay, and then the next feeding, and so on.

## 1.3 Main purpose and scope of application

The AF-25KII-103B / AF-50KII-103B equipment is mainly designed for quantitative packaging of granular materials of 25kg/50kg and below. It can be used together with vacuum shaping packaging machine. Measurable materials are mainly rice and grains of small size (such as millet, soybean, mung bean, etc.)

## 2. Precautions for safe use

### 2.1 Safe operation

Before installing and using the product, read the product instruction carefully and have the equipment tested by professional personnel

#### 2.1.1 Basic Safety Instructions

1. The power supply meets the requirements of this manual, and the equipment grounding meets the requirements.
2. Power and air should be turned off before starting cleaning, maintenance and repair.
3. Only use cleaners that do not damage mechanical and electrical equipment.
4. The mounting frame connected with the product should be stable and reliable.
5. Please cut off the power supply and air source when installing the metering bucket.
6. metering bucket, sensor connected parts and sensors are not allowed to knock, overload and other damage to the sensor behavior.
7. During the use of the equipment, no part of the body is allowed to extend into the equipment, and the weigher door has been firmly installed before use.
8. Machines that pack materials harmful to human body should be cleaned after using special protective tools according to the existing regulations of the country where the machines are operated. For details, please contact the relevant local authorities.

#### 2.1.2 Operation safety instructions


1. In order to avoid dangerous accidents, only one person is allowed to operate the machine.
2. The machine should only be operated by properly trained personnel.
3. Operating instructions, especially safety instructions and regulations, must be read and fully understood by the operator (or anyone responsible for operating the machine) before the machine is run.
4. Before the machine runs, the operator must check whether the scale works normally, whether the machine is fixed and the appearance is normal.



5. In case of any danger, click the "emergency stop" button on the main interface or disconnect the main power supply immediately.
6. For the electrical and electronic system, it is not allowed to modify, replace or carry out any other non-standard operation; Any updates or modifications must be made by General Measure technologies.
7. Wear safety helmets and other protective devices when maintaining equipment, especially when entering the packaging area.
8. Be careful to step on or off the maintenance platform.

### 3. Product installation and transportation protection

3.1 The overall appearance and mechanism of the product are introduced



Material by the materials into the mouth, including three quantitative process speed feeding control (motor control of the coarse/fine + vibrating feeder feeding material), quantitative weighing type and discharging control, equipment control system can automatically according to the different of material and range correction process parameters, reducing the complexity of equipment debugging and maintenance, convenient supporting customers to use. When using, 0.4~ 0.5mpa, 2m<sup>3</sup>/h compressed air is needed to access the air source inlet, and the power supply, signal communication and control ports

(such as serial port connection end, USB connection and I/O control port) of the equipment are located in the electrical control box.

The double scales are arranged symmetrically according to the direction shown. Scale A is on the left and scale B is on the right. Contains the following parts:

Feeding port: the material to be weighed enters the scale body.

Photoelectric code plate: motor in position signal feedback.

Discharge solenoid valve: Control the action of the unloading cylinder.

Feeding motor: The main function of weighing is to control the feeding amount.

Electric control panel: The built-in circuit board is connected to external signals, I/O control connections, and power wiring.

## 3.2 The installation conditions

### 3.2.1 Equipment installation basis and installation conditions

1. Temperature:  $-10\sim 40^{\circ}\text{C}$
2. Humidity: not more than 90% R.H.
3. Power supply: AC110~260V, 50Hz/60Hz, about 500W.
4. Air source: 0.4~ 0.5mpa 1.2m<sup>3</sup>/h.
5. Installation plane: horizontal solid steel support frame.
6. Static electricity: Ensure that the device is reliably grounded.
7. Harmful radio waves: keep away from powerful sources of harmful radio waves such as wireless devices.
8. Electrical and gas technical parameters meet and are in place

## 3.3 Unpacking and inspection

### 3.3.1 The crates



Please read this operation manual carefully before unpacking for

1. Pay attention to the words and warning signs on the containers before unpacking them.

2. Before unpacking the box, check whether the box is seriously squeezed and deformed during transportation. If the damage is serious, consider whether the equipment is damaged.
3. Read the packing list before unpacking and proofread it after unpacking to avoid omission.
4. After unpacking the device, check whether the screws connecting the device are loose.
5. Check whether the metal hose is in good condition before unpacking the device.
6. After unpacking the whole machine, check whether the scale is normal and whether the action of the moving parts is normal.
7. During debugging after the assembly of the unpacked machine, pay attention to whether the sealing of the parts through which the material passes under the predetermined pressure is reliable. This check must be made before starting the machine.

### 3.3.2 Spare parts

1. Accessories: equipment side panel opening key, packing list, invoice, product manual and quality inspection certificate.
2. Unpack the device and check whether the accessories are complete and whether the device package is intact.
3. Original General Measure Technologies must be used.

The company is not responsible for the loss caused by using other parts.

If you have any questions, please don't hesitate to contact us.

## 3.4 Product packaging and transportation protection

### 3.4.1 Packaging requirements


1. It is packaged in wooden cases and can be stacked in two layers.  
GB/T4857.3 Basic Test for Transport Packages, Static Load Stacking Test Method.

2. Meet the vibration resistance requirements of long-distance highway transportation, GB/T4857.7 Basic Test for Transportation Packages, Sinusoidal Vibration (Constant Frequency) Test Method.

### 3.4.2 Transport protection

1. Before transportation, remove the metering bucket and invert it into the scale frame.
2. Use nuts at the lower flange of the equipment to secure the equipment to the transportation wooden box, and secure the unloading hopper.
3. Wrap the outer surface of the equipment with wrapping film.

### 3.4.3 Remove transport limit protection



This product is designed to prevent sensor damage during transportation. The method of disassembling and inverting the metering bucket inside the scale frame is adopted. After receiving the product, it is necessary to install the metering bucket. The illustration shows a single scale, and a double scale means two buckets.

The metering bucket of this product adopts a fast loading and unloading design. A single person can complete the installation of the metering bucket in 10 minutes.

As shown in the figure:

1. Open the scale frame door panel.
2. Loosen the retaining bolts of the metering bucket.
3. Take the metering bucket out of the scale frame and turn it upside down (as shown in the figure).
4. Insert the metering bucket horizontally into the metering bucket bracket (as shown by the arrow in the figure).

Note that the beveled edge of the metering bucket should catch the beveled edge of the bracket.

Take care to prevent the discharge door from opening.

5. After inserting into place, align the hole locations and lock the four eyebolts.
6. Connect the discharge cylinder air pipe.
7. Install the door panel.

#### 3.4.4 Requirements for equipment installation and maintenance

1. The operator must accept the company's skill training and safety education, and hold a work permit.
2. The personnel responsible for operating the machine must read and fully understand the operation manual.
3. Operators must have short hair or long hair up, clothing and shoes and hats should be easy to work. Wear a safety helmet and insulating shoes during testing or maintenance.
4. The operator must strictly follow the procedures and steps stipulated in the user manual.
5. Before lubrication, mechanical adjustment, maintenance and repair of the equipment, the power supply shall be cut off, the air source shall be closed, the residual pressure in the pneumatic pipeline shall be released, and the warning signs shall be hung at the electric control cabinet, the power switch and the air source valve.
6. The maintenance and repair of the air pressure system must be carried out under the condition of cutting off the power supply and releasing the pressure completely.
7. The production line shall not be operated until all safety protection facilities are in place.
8. After the device is powered on, do not touch the moving parts of the device.

9. When the production line is in operation, do not enter dangerous areas or cross the production line.


10. Do not modify the setting parameters of wiring in the control cabinet, motherboard program and driver.

11. The tool installation is reliable and safe, and the operator understands and understands all the safety requirements of the tool.



## 4. Product size

Product size unit: mm


#### 4.1 AF-25KII-103B Overall dimensions










## 4.2 AF-50KII-103B Overall dimensions





## 5. Electrical connections

### 5.1 Air supply connection




Air source inlet  $\phi 6$  air pipe, air source standard: 0.4~ 0.6mpa 2m<sup>3</sup>/h

### 5.2 Electrical connections

Insert the single-wire 220V power plug into the onsite power socket.

The internal layout of the electric control box is shown as follows:



The PCB interfaces are defined as follows:

### 5.2.1 External interface definition

- 1: Power cord port, 24V power port of the instrument (24V+, 24V -).
- 2: Motor control port 1, (M1\_24V+: 24V positive, M1\_24V -: 24V negative, PU1: pulse, DR1: direction, ZT1\_1: origin detection input, ZT1\_2: feeding door opening limit), can also be used as a common IO port, currently used for feeding motor control.
- 3: Motor control port 2, currently used as a common IO port.
- 4: Sensor wire ports, sensor wiring ports (SHLD, EX+, EX -, SN+, SN -, SIG+, SIG -).
- 5: RS485 serial communication port, serial port 1 (A1, B1, GND1) is generally used for local HMI communication.
- 6: Two RS485 serial communication ports, serial port 2 (A2, B2, GND2) and serial port 3 (A3, B3, GND3), can be used for upper computer communication, and both support Modbus communication.
- 7: Input ports, 8 customizable switching input interfaces (IN1, IN2, IN3, IN4, IN5, IN6, IN7, IN8), valid for low levels, and the definition of each port can be selected by yourself.


8: Output ports: 8 customizable switching output interfaces (OUT1, OUT 2, OUT 3, OUT 4, OUT 5, OUT 6, OUT 7, OUT 8). The definition of each port can be selected by yourself.

USB: USB interface can be used for various data import and export.

LAN: The network interface can be used for networking and data transmission.


IO-24V: Internal use.

## 5.2.2 Switching value interface wiring description




Switching value interface diagram


The switching value adopts photoelectric isolation method. If users need to use a switching interface, they need to provide and connect to a DC24V power supply. Switching value input is valid at low level; The output adopts the transistor collector open circuit output mode, and each drive current can reach 500mA.



Schematic diagram of input interface



Schematic diagram of output interface



Wiring diagram of user input and output ports

## 6. The Modbus address table

In [Communication Parameters], serial port communication is usually modbus-RTU. When the communication parameters are consistent with the Settings of the upper computer, modbus-RTU protocol is used for communication.

PLC address	Function	meaning	instructions	
<b>The following is a read-only register (function code 0x03)</b>				
<b>Instrument status parameter</b>				
<b>40001</b>	<b>00000</b>	The current weight	4 bytes, signed number	
<b>40002</b>	<b>00001</b>			
<b>40003</b>	<b>00002</b>	Instrument condition 1	position	instructions
			<b>. 00:</b>	The AD collection module is abnormal
			<b>. 01:</b>	Memory failure
			<b>. 02:</b>	keep
			<b>. 03:</b>	Abnormal sensor signal
			<b>. 04:</b>	The weight of overflow
			<b>. 05:</b>	Weight is stable
			<b>. 06:</b>	zero
			<b>. 07:</b>	Minus sign
			<b>. 08:</b>	Millivolts are stable
	<b>. 09 ~. 15:</b>	keep		
<b>40004</b>	<b>00003</b>	Instrument status 2	<b>. 00.</b>	run



			. 01	Before loading
			. 02	Quickly add
			. 03	To add
			. 04	Slowly add
			. 05	Constant value
			. 06	Super poor
			. 07.	Owe less
			. 08	Call the police
			. 09	Waiting for the clip bag
			. 10.	Clip bag
			. 11.	discharge
			. 12.	Charging to allow
			. 13.	Discharge allow
			. 14.	jam
			. 15.	keep
40005	00004	Instrument status 3	. 00:	keep
			. 01	keep
			. 02:	Complete one package (duration 1S)
			. 03 ~. 15:	keep
40006	00005	Alarm queue 1	. 00.	No alarm
			. 01	Batch to complete
			. 02	Clear out of range (2s)
			. 03	Unstable at zero clearing (2s)
			. 04	Target value 0 cannot start (2s)

			. 05	Pause the gap
			. 06	keep
			. 07.	Disable zero clearing operation in operation (2s)
			. 08	Overage and underage alarm
			. 09	keep
			. 10.	keep
			. 11.	Discharge fault
			. 12.	Discharging timeout
			. 13.	Feeding motor running time out
			. 14.	Discharging motor running timeout
			. 15.	Unable to run during emergency stop (2S)
			. 16.	Zero clearance failure (zero clearance before feeding operation)
			. 17.	Charging a timeout
			. 18.	Steady value judgment timeout (steady value judgment method)
			. 19.	Servo motor alarm
			. 99.	Software authentication failure
40007	00006	Alarm queue 2	1. When there are multiple alarms at the same time, press "Happening" Up to three alarms are displayed at the same time.	
40008	00007	Alarm queue 3		
40009	00008	The default package number	Initial value: 0. The value ranges from 0 to 99999	
40010	00009			

<b>40011</b>	<b>00010</b>	Number of preset packets remaining	Initial value: 0. The value ranges from 0 to 99999
<b>40012</b>	<b>00011</b>		
<b>40013</b>	<b>00012</b>	Current gross weight	Unlike 40001, this register is not subject to constant weight retention
<b>40014</b>	<b>00013</b>		Switch control, when the switch is on, even during unloading, also Return to actual weight
<b>40015</b>	<b>00013</b>	Current display value (floating point)	Unlike 40001, this register is not subject to constant weight retention
<b>40016</b>	<b>00014</b>		Switch control, when the switch is on, even during unloading, also Return to actual weight
<b>40017</b>	<b>00015</b>	Current gross weight (floating point)	= The current display value in the format of a single-precision floating point number
<b>40018</b>	<b>00016</b>		
<b>40019</b>	<b>00018</b>	The reserved	
...	...		
<b>40030</b>	<b>00029</b>		
<b>40031</b>	<b>00030</b>	Year (readable and writable)	Scope: 2000 ~ 2099
<b>40032</b>	<b>00031</b>	Month (readable and writable)	Scope: 1 ~ 12
<b>40033</b>	<b>00032</b>	Day (readable and writable)	Scope: 1 ~ 31
<b>40034</b>	<b>00033</b>	week	Scope: 1 ~ 7
<b>40035</b>	<b>00034</b>	Hours (readable and writable)	Scope: 0 ~ 23
<b>40036</b>	<b>00035</b>	Points (readable and writable)	Scope: 0 ~ 59
<b>40037</b>	<b>00036</b>	Second (readable and writable)	Scope: 0 ~ 59

<b>40038</b>	<b>00037</b>	System running time	The maximum value of a 0 to 4 byte long integer, exceeding natural reversal, in milliseconds
<b>40039</b>	<b>00038</b>		
<b>40040</b>	<b>00039</b>	The reserved	
...	...		
<b>40050</b>	<b>00049</b>		
<b>40051</b>	<b>00050</b>	Package formula number	Formula number and target value when "packing result weight" is generated, Manual unloading, also do a result save, but the formula number is equal to 0
<b>40052</b>	<b>00051</b>	Package target value	
<b>40053</b>	<b>00052</b>		
<b>40054</b>	<b>00053</b>	Packing result weight	Weight unit is system unit, updated at the end of unloading
<b>40055</b>	<b>00054</b>		
<b>40056</b>	<b>00055</b>	Actual packing time (including waiting time)	Update at the end of unloading, in milliseconds
<b>40057</b>	<b>00056</b>		
<b>40058</b>	<b>00057</b>	Theoretical packing time (Not including waiting time)	
<b>40059</b>	<b>00058</b>		
<b>40060</b>	<b>00059</b>	Delay before feeding (including clear Zero additional delay)	
<b>40061</b>	<b>00060</b>		
<b>40062</b>	<b>00061</b>	Quickly add time	
<b>40063</b>	<b>00062</b>		
<b>40064</b>	<b>00063</b>	To add time	
<b>40065</b>	<b>00064</b>		
<b>40066</b>	<b>00065</b>	Slowly add time	
<b>40067</b>	<b>00066</b>		
<b>40068</b>	<b>00067</b>		

<b>40069</b>	<b>00068</b>	Fixed time (slow plus end to Discharging start)	
<b>40070</b>	<b>00069</b>	Wait for bag clamping (unloading allowed) time	
<b>40071</b>	<b>00070</b>		
<b>40072</b>	<b>00071</b>	Discharging time	
<b>40073</b>	<b>00072</b>		
<b>40074</b>	<b>00073</b>	Actual packing speed	Update at the end of unloading, unit: BPH
<b>40075</b>	<b>00074</b>		
<b>40076</b>	<b>00075</b>	Theoretical packing speed	
<b>40077</b>	<b>00076</b>		
<b>40078</b>	<b>00077</b>	deviation	Signed double word, uncombined mode: packet result - packet target value. Combination mode: the first time, fixed at 0, the second time: combined total result-set the target value
<b>40079</b>	<b>00078</b>		
<b>40080</b>	<b>00079</b>	Number of speed sampling packets Nspeed (Readable and write)	Initial value: 6. Range: 6 to 12
<b>40081</b>	<b>00080</b>	Generation date of subcontracting data	Decimal 8-digit month day, such as: 20160111 (2016/01/11)
<b>40082</b>	<b>00081</b>		
<b>40083</b>	<b>00082</b>	Generation time of packet data	Decimal 6-bit time, such as 160552 (16:05:52)
<b>40084</b>	<b>00083</b>		
<b>40085</b>	<b>00084</b>	The reserved	
...	...		
<b>40100</b>	<b>00099</b>		

**The following contents are readable and writable**

<b>(Write a single register function code is 0x06, write multiple registers function code is 0x10, read function code is 0x03)</b>				
<b>Calibration parameters</b>				
<b>40101</b>	<b>00100</b>	The zero calibration	Write 1 to mark zero; read returns 0	
<b>40102</b>	<b>00101</b>			
<b>40103</b>	<b>00102</b>	There is weight gain calibration (Input weight)	The value ranges from 0 to 999999, expressed in grams	
<b>40104</b>	<b>00103</b>			
<b>40105</b>	<b>00104</b>	Material gain calibration (note Record current AD code)	Input 1 to record the gain AD code, and read returns 0	
<b>40106</b>	<b>00105</b>			
<b>40107</b>	<b>00106</b>	Material gain calibration (Input weight)	The value ranges from 0 to 999999, expressed in grams	
<b>40108</b>	<b>00107</b>			
<b>40109</b>	<b>00108</b>	Absolute Millivolt (read only)	Default 3 decimal points, unit: millivolt If the value is 12345, it means 12.345	
<b>40110</b>	<b>00109</b>			
<b>40111</b>	<b>00110</b>	Gain millivolts (read only)	Default 3 decimal points, unit: millivolt If the value is 12345, it means 12.345	
<b>40112</b>	<b>00111</b>			
<b>40113</b>	<b>00112</b>	Calibration result information (read only)	The results	instructions
			<b>0</b>	There is no information
			<b>1</b>	Calibration is successful
			<b>2</b>	The current sensor voltage is unstable
			<b>3</b>	Input weight is not reasonable
			<b>4</b>	The current sensor voltage is too high

			<b>5</b>	The current sensor voltage is too low
			<b>6</b>	Excessive calibration resolution
			The alarm message will be automatically eliminated after 2 seconds. Before elimination, no Allow to calibrate again	
<b>40114</b> ... <b>40200</b>	<b>00113</b> ... <b>00199</b>	The reserved		
<b>The basic parameters</b>				
<b>40201</b>	<b>00200</b>	unit	Initial value: 1,0: g; <b>1 kg;2: t;3: b</b>	
<b>40202</b>	<b>00201</b>	The decimal point	Initial value: 3. The value ranges from 0 to 4	
<b>40203</b>	<b>00202</b>	Dividing the value	Initial value: 1. Range: 1, 2, 5, 10, 20, 50	
<b>40204</b>	<b>00203</b>	Maximum range	If the device model is AF-5K, the initial value is 10000	
<b>40205</b>	<b>00204</b>		If the device model is AF-10K, the initial value is 20000 The value ranges from 1 to 999999, expressed in grams	
<b>40206</b>	<b>00205</b>	OFL indicates the type	Initial values: 0, <b>0:[maximum range + 9D] display OFL;</b> <b>1:[maximum range *120%] to display OFL;</b> <b>2:[maximum range *150%] to display OFL</b>	
<b>40207</b>	<b>00206</b>	Scale range mode	Initial values: 0, 0, 5 k; <b>1:25K;2:50K;3:10K;4: the reserved</b>	
<b>40208</b>	<b>00207</b>	Automatic zero clearance interval	Initial value: 80. The value ranges from 0 to 9999, expressed in milliseconds	
<b>40209</b>	<b>00208</b>	Start additional clearance times	Initial value: 2. The value ranges from 0 to 9	

40210	00209	Additional zero clearance time	Initial value: 1000. The value ranges from 0 to 9999, in milliseconds
40211	00210	Handling method of failure to clear data	Initial values: 0, <b>0: only alarm, lasts 1S, give up zero clearance this time, clear again next time;</b> <b>1: only alarm, lasts 1S, give up zero clearance this time, clear again next time, connect</b> Unable to reset three times, return to stop state!Continue to report to the police <b>2: alarm, but continue to wait for stability, once stable, eliminate the alarm,</b> Automatically continue to run; <b>3: alarm, immediately return to stop state.</b>
40212	00211	Reset the scope	Initial value: 10. Range: 0 to 99, unit: %
40213	00212	Sentenced to stabilizing range	Initial value: 5. Range: 0 to 99, unit: D
40214	00213	Sentenced to stabilizing time	Initial value: 300. The value ranges from 100 to 9999, expressed in milliseconds
40215	00214	Zero tracking range	Initial value: 3. Range: 0 to 9, unit: D
40216	00215	Zero tracking time	Initial value: 2000. The value ranges from 0 to 9999, expressed in milliseconds
40217	00216	Stop the AD filter series	Initial value: 9. The value ranges from 0 to 9
40218	00217	Add AD filter series	Initial value: 2. The value ranges from 0 to 9
40219	00218	Fixed value AD filter series	Initial value: 5. The value ranges from 0 to 9
40220	00219	Discharging AD filter series	Initial value: 2. The value ranges from 0 to 9
40221	00220	Power-on automatic reset switch	Initial value: 0. Range: 0 to 1



40222	00221	Manual unloading cumulative switch	Initial value: 0. Range: 0 to 1
40223	00222	Constant weight hold switch	Initial value: 1 the value ranges from 0 to 1
40224	00223	Unloading mechanism mode	Initial value: 0,0: pneumatic, 1: unidirectional general motor, <b>2: common motor bidirectional, 3: one-way stepping motor</b>
40225	00224	Unloading working mode	<b>0: timing mode, discharging signal output continuous discharging time (formula Parameter) is turned off. Discharging abnormal after discharging</b> Judge; <b>1: Judge zero zone mode, signal output, until the weight is below zero zone</b> Value, and then start unloading delay time, when the time is up, close unloading After entering the discharging delay, there is no need to distinguish the weight.
40226	00225	Discharge delay	Initial value: 200. The value ranges from 0 to 9999, expressed in milliseconds
40227	00226	Discharging timeout time	Initial value: 2000. The value ranges from 0 to 20000, expressed in milliseconds
40228	00227	Loose bag model	<b>0: automatically loosens the bag after unloading. 1: automatically loosens the bag after unloading</b> Manual loose bag
40229	00228	Discriminant mode of feeding allowance	<b>0: judge only when start feeding, no longer judge during feeding;1:</b> Keep judging during feeding.
40230	00229	Allowable discharging discriminant mode	<b>0: judge only when starting unloading, no longer judge in unloading process;1:</b> Keep judging during unloading.

40231	00230	Over range feeding protection	<p>Initial value: 1,  <b>0: close;</b>  <b>1: on. When on, from the calibration zero (plus zero clearing)</b>          Cleared part), the weight is greater than or equal to specification *1.2, then judged OFL, whether or not the maximum range is exceeded. Preventing zero clearing will be large          After the weight is cleared to 0, the weight is small, but it is          Overcharge. at the same time, adjust the settable value of the clearing range from 99%          The whole of 20%</p>
40232	00231	Whether the feeding mechanism contains a vibrating disk	<p>Initial value: 0,0: no vibration plate.<b>1: with a vibrating disk.</b></p>
40233	00232	Type of feeding motor	<p>Initial value: 1,0: step;<b>1: servo</b></p>
40234	00233	Intelligent ban switch	<p>Initial value: 0,0: forbid intelligent ban, when using the set ban          1: intelligent ban on: automatic change according to the feeding speed          Set a time limit.</p>
40235	00234	Intelligent judgment switch for current cutoff	<p>0: Off 1: On, the program automatically judges the cutoff state</p>
40236	00235	Outage timeout	<p>Setting greater than 10000 does not work, between 2000 and 10000.It will work even if the intelligent judgment switch for current cutoff is turned off</p>
40237 ... 40242	00236 ... 00241	The reserved	

40243	00242	Fixed value method	Initial value: 0,0: fixed time. <b>1: judge the stability value</b>
40244	00243	Fixed value stabilization timeout	Initial value: 0. The value ranges from 0 to 999. Unit: 0.1s The maximum time allowed to wait for stability when determining the stability value exceeds If the time is not stable, the "fixed value" is used to judge the stable timeout handler Method "handles.0, it doesn't work.
40245	00244	Fixed value judgment timeout processing method	Initial value: 0, range: 0~3, <b>0: The meter will consider the current weight as the stabilized weight, then</b> Continue with the following steps and alarm [constant value timeout] for 1S. <b>1: The meter will consider the current weight as the stabilized weight, then</b> Continue the following steps and alarm for 1S. After three consecutive times, Return to stop state, continuous alarm [continuous constant value timeout]. <b>2: alarm, but continue to wait for stability, once stable, eliminate the alarm,</b> Automatically continue running. <b>3: alarm, immediately return to stop state.</b>
40246	00245	Dual Scale Interlock Mode	Default 0, Range: 0-2, 0: No interlock; 1: Double scale A; 2: Double scale B;
40247 ... 40300	00246 ... 00299	The reserved	
<b>User preferences</b>			
40301	00300	Material no.	Initial value: 1. The value ranges from 0 to 10

<b>40302</b>	<b>00301</b>	The formula,	Initial value: 1. The value ranges from 0 to 20
<b>40303</b>	<b>00302</b>	The target	Initial value: 0. The value ranges from 0 to 999999, expressed in grams
<b>40304</b>	<b>00303</b>		
<b>40305</b>	<b>00304</b>	Step up quickly	Initial value: 0, range: 0 to maximum range, unit: gram
<b>40306</b>	<b>00305</b>		
<b>40307</b>	<b>00306</b>	Add the lead quantity	Initial value: 0, range: 0 to maximum range, unit: gram
<b>40308</b>	<b>00307</b>		
<b>40309</b>	<b>00308</b>	Slow down and advance	Initial value: 0, range: 0 to maximum range, unit: gram
<b>40310</b>	<b>00309</b>		
<b>40311</b>	<b>00310</b>	Zero value	Initial value: 0, range: 0 to maximum range, unit: gram
<b>40312</b>	<b>00311</b>		
<b>40313</b>	<b>00312</b>	Discharging time	Initial value: 300. The value ranges from 0 to 99999, expressed in milliseconds
<b>40314</b>	<b>00313</b>		
<b>40315</b>	<b>00314</b>	Delay before feeding	Initial value: 0. The value ranges from 0 to 99999, expressed in milliseconds
<b>40316</b>	<b>00315</b>		
<b>40317</b>	<b>00316</b>	Fixed hold time	Initial value: 900. The value ranges from 0 to 99999, in milliseconds
<b>40318</b>	<b>00317</b>		
<b>40319</b>	<b>00318</b>	Switch for detecting overcurrent and undercurrent	Initial value: 0. Range: 0 to 1
<b>40320</b>	<b>00319</b>	Ultra difference	Updated at the end of unloading, range: 0~ maximum range, unit: g
<b>40321</b>	<b>00320</b>		
<b>40322</b>	<b>00321</b>	Owing to difference	Updated at the end of unloading, range: 0~ maximum range, unit: g
<b>40323</b>	<b>00322</b>		
<b>40324</b>	<b>00323</b>		

40325	00324	Overtime and undertime alarm	Initial value: 0. The value ranges from 0 to 99999, expressed in milliseconds
40326	00325	Pause switch over and under difference	Initial value: 0. Range: 0 to 1
40327	00326	Combined mode (read only)	Initial value: 1, Read-only 1 or 2:1 Uncombined mode 2 Combined mode
40328	00327	Feeding level (read only)	Initial value: Automatically determined according to the target value  Feeding series,2: two-stage feeding; <b>3: three-stage feeding. The controller will</b>  Automatic selection according to the range is two - stage feed or three - stage feed  Material.[grade 2, fast + slow add, add lead and add open [grade 3, add + add + slow add, but add or add quickly  If the lead is set to 0 or the opening is set to 0, it still does not go fast plus or medium Add]
40329	00328	The opening is configured independently	Initial value: 0. Range: 0 to 1
40330	00329	The formula is quickly widened	Initial value: 8000. Range: 0 to maximum openness
40331	00330	Add the opening in this formula	Initial value: 5000. Range: 1 to the maximum openness
40332	00331	This recipe is slow in opening	Initial value: 1800, range: 2~ maximum openness
40333	00332	Discharge opening of this formula	
40334	00333	Slow feeding function switch	Range: 0-1

40335	00334	Single time of slow feeding and replenishment	Range: 0.1~9.999s	
40336	00335	Times of slow feeding and replenishment	Range: 1~9	
40337	00336	Cut off the flow	Range: 0~999999	
40338	00337	Cut off the flow Slow increase the opening weight		
40339	00338	Flow cutoff slow increase opening	Range: 2000~30000	
40340	00339	Combination method count	Range: 0-99	
40341	00340	Interlock delay time	Initial value: 1000, range: 0~99999, unit: milliseconds	
40342	00341	The reserved		
...	...			
40400	00399			
<b>Switching parameter</b>				
40401	00400	Start/end the switch test	Write 1 to start the switching test; Write 0 to end the switch measurement try	
40402	00401	Input switching test (Read Only)	From low to high each represents an input state	
40403	00402	Output switching test	Each digit represents an output state from low to high	
40404	00403	IN1	The initial	instructions

			<b>1</b>	Enter a list of definitions:
<b>40405</b>	<b>00404</b>	IN2	<b>2</b>	I00: No definition
<b>40406</b>	<b>00405</b>	IN3	<b>5</b>	I01: start
<b>40407</b>	<b>00406</b>	IN4	<b>6</b>	I02: stop
<b>40408</b>	<b>00407</b>	(1-ZT1)	<b>4</b>	I03: stop
<b>40409</b>	<b>00408</b>	(1-ZT2)	<b>23</b>	I04: Feeding stepper motor origin (close the door to A level)
<b>40410</b>	<b>00409</b>	(2-ZT1)	<b>0</b>	I05: Feeding allowed
<b>40411</b>	<b>00410</b>	(2-ZT2)	<b>0</b>	I06: Unloading allowed
<b>40412</b>	<b>00411</b>	IN5	<b>0</b>	I07: Clear alarm
<b>40413</b>	<b>00412</b>	IN6	<b>0</b>	I08: keep
<b>40414</b>	<b>00413</b>	IN7	<b>0</b>	I09: Open/close unloading door [originally manual unloading Function, switch discharging output state]
<b>40415</b>	<b>00414</b>	IN8	<b>0</b>	I10: Manual unloading I11: Manual slow add I12: Manually add I13: Manual fast add [by fast open open The door] I14: Manual cleaning [open according to the maximum opening The door] I15: Start/stop (double edge: effective edge, Start;Invalid edge, stop) I16: Start/emergency stop (double edge) I17: Manual unloading (double edge) I18: Manual slow adding (double edge)

				I19: Manual adding (double edge) I20: Manual quick add (double edge) I21: Manual cleaning (double edge) I22: reset I23: Emergency stop [level](valid, no Start allowed, manual feeding not allowed, not allowed Manual unloading is allowed) I24: feeding stepping motor limit point. I25: Unloading stepping motor origin. I26: limit point of unloading stepping motor. I27: jam I28: Servo motor alarm I29: Double scale interlock input
<b>40416</b>	<b>00415</b>	OUT1	<b>1</b>	Output definition list: O00: No definition Run O01: O02: Refueling request O03: Feeding stepper motor direction [PW available The signal is set to feed PWM]
<b>40417</b>	<b>00416</b>	OUT2	<b>4</b>	
<b>40418</b>	<b>00417</b>	OUT3	<b>5</b>	
<b>40419</b>	<b>00418</b>	OUT4	<b>6</b>	
<b>40420</b>	<b>00419</b>	OUT5	<b>7</b>	
<b>40421</b>	<b>00420</b>	OUT6	<b>8</b>	O04: quick to add I add O05: O06: slow O07: fixed value O08: unloading L O09: over difference O10: alarm



				11: clip bag O12: Preset number of packets completed O13: Once packing is completed (unloading is completed After output 1s clock) O14: stop O15 unloading step motor direction O16 Discharging motor running/forward O17 discharging motor reverses O18 feeding PWM[only AVAILABLE for OUT7/OUT8] O19 Discharging PWM[only available at OUT7/OUT8]
<b>40422</b>	<b>00421</b>	OUT7[DR1]	<b>3</b>	PWM port output definition, definition value reference general
<b>40423</b>	<b>00422</b>	OUT8[DR2]	<b>8</b>	
<b>40424</b>	<b>00423</b>	OUT9[PWM1]	<b>0</b>	
<b>40425</b>	<b>00424</b>	OUT10[PWM2]	<b>0</b>	Custom output port (when PWM1 is set to non-0 ,DR1,PWM1 as the corresponding motor control Output, definition invalid)(when PWM2 is set to non-0 ,DR2,PWM2 as the corresponding motor control Output, definition invalid)
<b>40426</b>	<b>00425</b>	PWM1 function		Initial value, 1,0: off;1: charging PWM;2: unloading PWM
<b>40427</b>	<b>00426</b>	PWM2 function		Initial value, 0,0: close;1: charging PWM;2: unloading PWM
<b>40428</b>	<b>00427</b>	Start the		Write: 1, read: 1: running status, 0: stopped status

<b>40429</b>	<b>00428</b>	scram	Write: 1, read: 1: running status, 0: stopped status
<b>40430</b>	<b>00429</b>	stop	Write: 1, read: 1: Stop signal has been entered (this time packing The process will stop after the end), 0: the stop signal is not entered
<b>40431</b>	<b>00430</b>	reset	Write: 1, read: 1: weight is 0, 0: weight is not 0
<b>40432</b>	<b>00431</b>	Remove alarm	Write: 1, read: 1: no alarm, 0: alarm
<b>40433</b>	<b>00432</b>	Choose the formula	Write: 1, read: 0
<b>40434</b>	<b>00433</b>	Loose bag	Write: 1, read: 1: packed, 0: not packed.
<b>40435</b>	<b>00434</b>	Open/close discharge door	Write: 1, switch unloading door status, valid -> invalid, invalid -> Yes Read: 1: discharging effective, 0: discharging invalid
<b>40436</b>	<b>00435</b>	Slowly add manually	Write: 1, read: 1: slow add effective, 0: slow add invalid.
<b>40437</b>	<b>00436</b>	Manually add	Write: 1, read: 1: add valid, 0: add invalid.
<b>40438</b>	<b>00437</b>	Quickly add manually	Write: 1, read: 1: fast add is valid, 0: fast add is invalid
<b>40439</b>	<b>00438</b>	Manually removing mixture	Write: 1, read: 1: cleaning effective, 0: cleaning ineffective
<b>40440</b>	<b>00439</b>	Manual maximum opening speed	Write: 1, read: 1: fast add is valid, 0: fast add is invalid
<b>40441</b>	<b>00440</b>	Automatic feeding once (fixed value junction Stop after bundle)	Write: 1, read: 1: automatic feeding, 0: not automatic feeding material
<b>40442</b>	<b>00441</b>	Emergency stop	Write :0/1, exit/enter emergency stop lock Read :1: emergency stop, 0: no emergency stop

<b>40443</b>	<b>00442</b>	Manual discharging once	Write: 1, read: 1: discharging, 0: discharging invalid
<b>40444</b>	<b>00443</b>	Allowed to add	Read/write 1, grant valid, read/write 0, grant invalid
<b>40445</b>	<b>00444</b>	Allow unloading	Read/write 1, enable/disable, read/write 0, enable/disable
<b>40446</b> ...	<b>00445</b> ...	The reserved	
<b>40500</b>	<b>00499</b>		
<b>Communication parameters</b>			
<b>40501</b>	<b>00500</b>	Serial port 1 Slave (read only)	Initial value, 1. Range: 1 to 99
<b>40502</b>	<b>00501</b>	Serial port 1 communication protocol (only Read)	Initial value: 0,0: Modbus-RTU, 1: Modbus-ASCII
<b>40503</b>	<b>00502</b>	Serial port 1 Baud rate (read only)	Initial value, 3, 0:9600, 1:19200, 2:38400, <b>3:57,600, 4:115,200</b>
<b>40504</b>	<b>00503</b>	Serial port 1 data format (only Read)	Initial value, 1,0:18N2, 1:18e1, 2:18o1, 3: <b>18N1</b>
<b>40505</b>	<b>00504</b>	Serial port 1 Modbus double word mail Memory order (read only)	Initial value, 0,0: ABCD, 1: CDAB
<b>40506</b>	<b>00505</b>	Serial port 2 Slave machine number	Initial value, 1. Range: 1 to 99
<b>40507</b>	<b>00506</b>	Serial port 2 communication protocol	Initial value: 0,0: Modbus-RTU, 1: Modbus- <b>ASCII</b>
<b>40508</b>	<b>00507</b>	Serial port 2 baud rate	Initial value, 3, 0:9600, 1:19200, 2: <b>38400, 3:57,600, 4:115,200</b>

<b>40509</b>	<b>00508</b>	Serial port 2 data format	Initial value, 1,0:18N2, 1:18 E1, 2: <b>18O1, 3:18N1</b>
<b>40510</b>	<b>00509</b>	Serial port 2Modbus High Low Word Order	Initial value, 0,0: ABCD, 1: CDAB
<b>40511</b>	<b>00510</b>	Serial port 3 slave number	Initial value, 1. Range: 1 to 99
<b>40512</b>	<b>00511</b>	Serial port 3 communication protocol	Initial value: 0,0: Modbus-RTU, 1: Modbus- <b>ASCII</b>
<b>40513</b>	<b>00512</b>	Serial port 3 baud rate	Initial value, 3, 0:9600, 1:19200, 2: <b>38400, 3:57,600, 4:115,200</b>
<b>40514</b>	<b>00513</b>	Serial port 3 data format	Initial value, 1,0:18N2, 1:18 E1, 2: <b>18O1, 3:18N1</b>
<b>40515</b>	<b>00514</b>	Serial port 3Modbus High Low Word Order	Initial value, 0,0: ABCD, 1: CDAB
<b>40516</b>	<b>00515</b>	Network port IP group 1	0~255
<b>40517</b>	<b>00516</b>	Network port IP group 2	0~255
<b>40518</b>	<b>00517</b>	Network port IP group 3	0~255
<b>40519</b>	<b>00518</b>	Network port IP group 4	0~255
<b>40520</b>	<b>00519</b>	Network port number	0~~65535
<b>40521</b>	<b>00520</b>	Network interface communication protocol	0: Modbus-TCP/IP 1: Minicenter 2: Web

<b>40522</b>	<b>00521</b>	High and low byte order of network interface	0: AB-CD 1: CD-AB
<b>40523</b>	<b>00522</b>	MAC1	0~0xFF
<b>40524</b>	<b>00523</b>	MAC2	0~0xFF
<b>40525</b>	<b>00524</b>	MAC3	0~0xFF
<b>40526</b>	<b>00525</b>	MAC4	0~0xFF
<b>40527</b>	<b>00526</b>	MAC5	0~0xFF
<b>40528</b>	<b>00527</b>	MAC6	0~0xFF
<b>40529</b> ... <b>40600</b>	<b>00528</b> ... <b>00599</b>	The reserved	
<b>External setting parameters</b>			
<b>40601</b>	<b>00600</b>	Clip bag delay	Initial value: 500. The value ranges from 0 to 9999, expressed in milliseconds
<b>40602</b>	<b>00601</b>	Delay before releasing bag	Initial value: 500. The value ranges from 0 to 9999, expressed in milliseconds
<b>40603</b> ... <b>40700</b>	<b>00602</b> ... <b>00699</b>	The reserved	
<b>System parameters</b>			
<b>40701</b>	<b>00700</b>	Device model (ASCII code) Character) (read only)	'G'+ 'M'
<b>40702</b>	<b>00701</b>		'-' + 'F'
<b>40703</b>	<b>00702</b>		'0' + '1'
<b>40704</b>	<b>00703</b>		0
<b>40705</b>	<b>00704</b>		0

40706	00705		0
40707	00706		0
40708	00707		0
40709	00708		0
40710	00709		0
40711	00710	Version number (read Only)	4 bytes, unsigned number, such as converted decimal value to 123456, 12.34.56, range: 0 to 999999
40712	00711		
40713	00712	Compile date: year (read only)	2000 ~ 2099
40714	00713	Compile date: Month (read only)	1 ~ 12
40715	00714	Compile date: day (read only)	1 to 31
40716	00715	Compile date: time (read only)	0 ~ 23
40717	00716	Compile date: Fen (read only)	0 ~ 59
40718	00717	Compile date: seconds (read only)	0 ~ 59
40719	00718	Parameters of the reset	Write: <b>0 resets all (production use, including all the following additional also</b> There are statistical data clearance, cumulative clearance, putter related parameters) (Super user) <b>1 Reset all (clients) including all below</b> <b>2 Reset basic parameters</b> <b>3 Reset calibration parameters</b> <b>4 Reset user parameters</b>

			<b>5 Reset peripheral parameters</b> <b>6 Reset the adaptive parameters</b> <b>7 Reset communication parameters</b> <b>8 Reset Switch Value User-defined parameter</b> <b>9 Reset adaptive statistics</b> Read: 0
<b>40720</b>	<b>00719</b>	keep	
<b>40721</b>	<b>00720</b>	Enable/disable USB	<b>1: USB is enabled. 0: USB is disabled</b>
<b>40722</b>	<b>00721</b>	The USB device is connected (only Read)	<b>0: the USB device is connected. 1: the USB device is not connected</b>
<b>40723</b>	<b>00722</b>	USB mass storage device Connected (read Only)	<b>0: The USB mass storage device is connected</b> <b>1: The USB mass storage device is not connected</b>
<b>40724</b> ... <b>40750</b>	<b>00723</b> ... <b>00749</b>	The reserved	
<b>"Usb flash drive update application" function parameter</b>			
<b>40751</b>	<b>00750</b>	Enter or exit the Bootloader	Read: <b>0: the main program is automatically entered after a delay of 3 seconds</b> <b>1: The Bootloader is installed</b> Write: <b>1: Enters the Bootloader</b> <b>2: Exits the Bootloader and enters the main program</b>
<b>40752</b>	<b>00751</b>	The USB device is connected (only Read)	<b>0: The USB device is connected</b> <b>1: the USB device is not connected</b>

<b>40753</b>	<b>00752</b>	USB mass storage device has been installed Connect (read Only)	<b>0: The USB mass storage device is connected</b> <b>1: The USB mass storage device is not connected</b>
<b>40754</b>	<b>00753</b>	Upgrade file scanning result (only Read)	<b>0: no upgrade file</b> <b>1: control board upgrade file exists</b>
<b>40755</b>	<b>00754</b>	Control board program upgrade information (read-only)	<b>Zero: no</b> <b>1: The control board is being upgraded</b> <b>2: The controller module fails to be upgraded</b> <b>3: The controller module is successfully upgraded</b> <b>4: The control board upgrade file does not match the instrument model</b> <b>5: The upgrade file of the control module is incorrect</b> <b>6: The upgrade file of the control board does not exist</b>
<b>40756</b>	<b>00755</b>	Reserved (read only)	
<b>40757</b>	<b>00756</b>	Version number of the upgrade file on the control board	Read: Version number (6 decimal digits)
<b>40758</b>	<b>00757</b>		Write: 1 Upgrade this version of the program
<b>40759</b> ... <b>40800</b>	<b>00758</b> ... <b>00799</b>	The reserved	
<b>Adaptive correlation parameters</b>			
<b>40801</b>	<b>00800</b>	Adaptive master switch	Initial value: 1 the value ranges from 0 to 1
<b>40802</b>	<b>00801</b>	Self - adaptive & automatic scale adjustment	Initial value: 1. The value ranges from 0 to 4
<b>40803</b>	<b>00802</b>	Positive error function switch	Initial value: 0. Range: 0 to 1



<b>40804</b>	<b>00803</b>	The reserved	
...	...		
<b>40900</b>	<b>00899</b>		
<b>Internal reserved parameter</b>			
<b>40901</b>	<b>00900</b>	The reserved	
...	...		
<b>40916</b>	<b>00915</b>		
<b>40917</b>	<b>00916</b>	Add more time to your sentence	Initial value: 700. The value ranges from 0 to 9999, expressed in milliseconds
<b>40918</b>	<b>00917</b>	The reserved	
...	...		
<b>40923</b>	<b>00922</b>		
<b>40924</b>	<b>00923</b>	Canada time of suspension	Initial value: 700. The value ranges from 0 to 9999, expressed in milliseconds
<b>40925</b>	<b>00924</b>	Slow down the sentence	Initial value: 700. The value ranges from 0 to 9999, expressed in milliseconds
<b>40926</b>	<b>00925</b>	The reserved	
...	...		
<b>41100</b>	<b>01099</b>		
<b>Target value data parameter</b>			
<b>[Only the target value of each formula under the current material number, it is not supported to read the target value of each formula number of different materials]</b>			
<b>41101</b>	<b>01100</b>	Target value (Formula 1)	The value ranges from 0 to 999999, in grams, read-only
<b>41102</b>	<b>01101</b>		
<b>41103</b>	<b>01102</b>	Target value (Formula 2)	The value ranges from 0 to 999999, in grams, read-only
<b>41104</b>	<b>01103</b>		
<b>41105</b>	<b>01104</b>	Target value (Formula 3)	The value ranges from 0 to 999999, in grams, read-only
<b>41106</b>	<b>01105</b>		

<b>41107</b>	<b>01106</b>	Target value (Formula 4)	The value ranges from 0 to 999999, in grams, read-only
<b>41108</b>	<b>01107</b>		
<b>41109</b>	<b>01108</b>	Target value (Formula 5)	The value ranges from 0 to 999999, in grams, read-only
<b>41110</b>	<b>01109</b>		
<b>41111</b>	<b>01110</b>	Target value (Formula 6)	The value ranges from 0 to 999999, in grams, read-only
<b>41112</b>	<b>01111</b>		
<b>41113</b>	<b>01112</b>	Target value (Formula 7)	The value ranges from 0 to 999999, in grams, read-only
<b>41114</b>	<b>01113</b>		
<b>41115</b>	<b>01114</b>	Target value (Formula 8)	The value ranges from 0 to 999999, in grams, read-only
<b>41116</b>	<b>01115</b>		
<b>41117</b>	<b>01116</b>	Target value (Formula 9)	The value ranges from 0 to 999999, in grams, read-only
<b>41118</b>	<b>01117</b>		
<b>41119</b>	<b>01118</b>	Target value (Formula 10)	The value ranges from 0 to 999999, in grams, read-only
<b>41120</b>	<b>01119</b>		
<b>41121</b>	<b>01120</b>	The reserved	
...	...		
<b>41200</b>	<b>01199</b>		
<b>Cumulative data parameter</b>			
<b>41201</b>	<b>01200</b>	Clear the total accumulated data	Write 1 to clear the total cumulative data and cumulative data of all formulations Write 2 Clear the total accumulated data Do not clear the formula accumulated data
<b>41202</b>	<b>01201</b>	Clear cumulative formula data	Write person 0 to clear all formula accumulations Write 1 to 20 to clear the accumulated data of formula 1 to 20
<b>41203</b>	<b>01202</b>		

...	...	The reserved	
<b>41500</b>	<b>01499</b>		
<b>Packet record parameters</b>			
<b>41501</b>	<b>01500</b>	Total number of entries	Write 0 to clear record, range: 0~50000, update at the end of unloading
<b>41502</b>	<b>01501</b>	View the start number of entries	Range: 1~50000, updated at the end of unloading
<b>41503</b>	<b>01502</b>		
...	...	The reserved	
<b>42000</b>	<b>01999</b>		
<b>Automatic adjustment of weighing parameters</b>			
<b>42001</b>	<b>02000</b>	Automatic balance status adjustment	Read: Automatic balancing Status :0/1: Stop/running.2. Automatic balancing Done.[pause set back to 0 instead of 2], read only
<b>42002</b>	<b>02001</b>	Maximum material type	<b>10~40. Temporarily fixed to 10. Later adjustment. That is, maximum support insurance</b> Store 10 different materials, read only
<b>42003</b>	<b>02002</b>	=40301, current material type	read-only
<b>42004</b>	<b>02003</b>	=40302, current formula number	read-only
<b>42005</b>	<b>02004</b>	=41050, the scale of the current specification is the highest Large range points	read-only
<b>42006</b>	<b>02005</b>	=41096, current target value In the range point	read-only


<b>42007</b>	<b>02006</b>	Automatic weighing times	Initial value: 6. The value ranges from 3 to 10
<b>42008</b>	<b>02007</b>	How many	
<b>42009</b>	<b>02008</b>	Qualified times	
<b>42010</b>	<b>02009</b>	Automatically adjust the scale grade	Initial value: 1, range: 0~4, the smaller the level, the better the speed First, each level increase, small cast time about 0.2S longer
<b>42011</b>	<b>02010</b>	Start/stop automatic adjustment scale	Read: Automatic balance status :0/1: Stop/run (complete state 0), write :1/0: enable/disable automatic balancing
<b>42012</b>	<b>02011</b>	Save the result of automatic balancing	Write 1: saves the result of automatic balancing to the current current material number Formula number, write 2: abandon save, restore the debugging result is silent Value.
<b>42013</b> ... <b>42020</b>	<b>01207</b> ... <b>02019</b>	The reserved	
<b>42021</b>	<b>02020</b>	Material XSegY fast increase and advance quantity	X= Material number,Y segment number, material number change, target value change [span Range range], the value of this range may change automatically
<b>42022</b>	<b>02021</b>	The results of	
<b>42023</b>	<b>02022</b>	Add material XSegY in advance	
<b>42024</b>	<b>02023</b>	The results	
<b>42025</b>	<b>02024</b>	Material XSegY slowly add and advance quantity	
<b>42026</b>	<b>02025</b>	The results of	

<b>42027</b>	<b>02026</b>	Material XSegY fast opening knot fruit
<b>42028</b>	<b>02027</b>	Material XSegY in the opening knot fruit
<b>42029</b>	<b>02028</b>	Material XSegY slow opening knot fruit
<b>42030</b>	<b>02029</b>	keep
<b>42031</b>	<b>02030</b>	Material XSegY fast increase and advance quantity The initial value
<b>42032</b>	<b>02031</b>	
<b>42033</b>	<b>02032</b>	Add material XSegY in advance
<b>42034</b>	<b>02033</b>	Amount of the initial value
<b>42035</b>	<b>02034</b>	Material XSegY slowly add and advance quantity The initial value
<b>42036</b>	<b>02035</b>	
<b>42037</b>	<b>02036</b>	Material XSegY fast opening Starting values
<b>42038</b>	<b>02037</b>	Material XSegY in the opening Starting values
<b>42039</b>	<b>02038</b>	Material XSegY slow opening Starting values
<b>42040</b>	<b>02039</b>	keep

Note: The above is all the contents of Modbus communication address table of AF-25KII - 103B/ AF-50KII -103B automatic quantitative unit.If the device is equipped with a 7 - or 10-inch touch screen, read all of Chapter 7 carefully.Do not read Chapter 7 if the device is not equipped with a touch screen.

## 7. Touch screen Operation Instructions (optional)

### 7.1 Login screen



**Interface Description: The interface is displayed after startup and before login.**










Operating instructions for buttons and operation boxes (applicable to all operating interfaces of the device):




1. **Setting** Click this button to enter the parameter setting interface.



2. **Auto Setting** Click this button to enter the automatic scale adjustment interface.

- 
3.  **Histroy Data** Click this button to enter the historical data interface to view relevant data.
  4.  **Zeroing** Click this button to perform a reset operation.
  5.  **Stop** Click this button to make the device emergency stop.
  6.  **Stop** Click this button to start and stop the device.
  7.  Click this type of operation box to modify this value.
  8.  Click this type of operation box to select and set this definition.
  9.  Click this type of operation box to perform corresponding operations.
  10.  Click this type of operation box to set the opening and closing of corresponding functions.
  11.  [Previous Page](#) Click this type of operation box to switch pages.

## 7.2 Touch screen login permission description



### Interface description:

- 1: indicates the level of the current login user.
- 2: indicates the system date and time, indicating the current system date and time.
- 3: indicates the working status of the equipment.
- 4: Weight display area, display the current weight and weight unit, if the weight overflow or sensor overflow, there will be text prompt in this area, such as: "weight overflow", "weight overflow", etc.
- 5: Login user selection area, showing all users that can be selected.
- 6: User password input box, select a user account and enter the corresponding user password


user name	user	Password	limits of authority
Admin	administrators	0	Not allowed: scale calibration/switching value/motor parameters, etc



Operator01	Operator01	1	it is not allowed to set the scale calibration/switching value/motor parameters/system information, etc
Operator02	Operator02	2	
Operator03	Operator03	3	
Engineer	Engineer	Please obtain the password from the manufacturer	Unlimited operation
Reserved	Reserved	No user action required	No user action required

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

### 7.3 Main Interface description



The screenshot displays the main interface of the F116B.5IIY scale, showing two weighing stations (A and B) side-by-side. The interface includes a top status bar with 'User Resered', 'F116B.5IIY', and the date/time '2018-07-17 11:02:39'. Each station shows a large digital display for weight (0.000kg) and a 'Zeroing' button. Below the display are speed control buttons (FAST, MIDDLE, SLOW, WAIT, DISC) and a '1981' indicator. The bottom section contains target and material information, status indicators (A first, WAIT\_A, Disc\_A, Delayed, B first, WAIT\_B, Disc\_B, Delayed), and control buttons for 'A-(M)Clear Hopper', 'A-(M)EnDisc', '(M)EnDisc', 'B-(M)EnDisc', and 'B-(M)Clear Hopper'. At the very bottom are 'Setting' and 'History Data' buttons for both stations, along with 'START' and 'STOP' buttons.

Numbered callouts in the image point to the following elements:

- 1: Points to the 'Zeroing' button on both stations.
- 2: Points to the 'FAST', 'MIDDLE', 'SLOW', 'WAIT', and 'DISC' speed control buttons.
- 3: Points to the 'A-(M)Clear Hopper' and 'B-(M)Clear Hopper' buttons.
- 4: Points to the 'Target: 5.000kg' and 'Material: 01' information.
- 5: Points to the '4.121kg | - kg | 2.121kg | 3.123kg' weight and material data.
- 6: Points to the 'A first', 'WAIT\_A', 'Disc\_A', and 'Delayed' status indicators.
- 7: Points to the 'A-(M)EnDisc' and 'B-(M)EnDisc' buttons.

#### Interface description:

1. Current weight and equipment status, where:

- 1) Communication status. When the communication is normal, the icon is green.
- 2) Zero flag. When the current weight is at zero, the icon is green.
- 3) Weight stability indicator. When the weight is stable, the indicator icon is green.
- 4) Opening mark, opening of current material door.

In addition, there are allowed feeding, unloading, operation or stop status display.

2. The current material number and formula number can be set to replace the formula or material. Click the "Formula Setting" button on the right to modify the current formula parameters.

3. Currently available manual operation: manual discharging A, manual discharging A, manual discharging, manual discharging B, manual discharging B, all the buttons can manually control the corresponding action (the operation is invalid during operation).

4. Each state of the device when it is running. When the device is in the stopped state, the corresponding manual operation can be performed (the runtime operation is invalid).













5. Current target value.

6. The feed cut-off advance value and target value under the current formula.

7. Discharge time and feeding door opening Settings under the current formula.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

#### 7.4 The parameter setting page is described

<b>A-Setting</b> < HOME		 0.000 kg Running FAST MIDDLE SLOW DISC	 0.000 kg Running FAST MIDDLE SLOW DISC	2018-08-18 10:02:26 USER: engineer
 <b>Work Parameters</b> Zeroing, digital filter, stable judge	>	 <b>Communication Para.</b> Protocol, baud rate, format	>	
 <b>Recipe Parameter</b> Target, Reserves, Steps...	>	 <b>History Data</b> Query, export, clear data	>	
 <b>Calibration</b> Capacity, calibration...	>	 <b>Auto Setting</b> Process parameter self-learning	>	
 <b>I/O</b> Define, Test...	>	 <b>User Management</b> Password modification, logout	>	
 <b>Control Parameters</b> Frequency, Door Opening	>	 <b>System Information</b> Version, Backup, Upgrade...	>	

#### Interface description:

**Working parameters:** basic parameters of the product can be set, such as zero clearance range, zero clearance time, unloading mode and so on.

**Communication parameters:** the communication parameters of the product can be set. Serial port 1 is used to communicate with the touch screen. The parameters cannot be modified, but can be adjusted automatically through the serial port. Serial port 2 can be used as an external serial communication interface. The communication parameters can be set by oneself, but should be consistent with the communication equipment (see 7.10 Communication Interface description for details).

**Formula parameters:** can modify the current formula number, as well as the parameter value of the current formula to modify, such as modify the lead quantity, material door opening, unloading time, etc.

**Historical data:** You can query previous packing records on the historical data screen and export the packing records to a USB flash drive.

**Calibration scale:** zero calibration, weight calibration, material calibration, and maximum range setting.

**Automatic balance:** Can only set up the target and the scale number, click the start after adjustment scale button, the equipment is up and running, in setting the number of times to adjust the value of each schedule, after completing the scale number, if meet the needs of users, the user can press the save button, will automatically adjust the data as the current formula value after the nc data, if give up, The debugging data is restored to the factory default data.

**On/Off quantity:** Users can define and set the input quantity and output quantity according to their own requirements. The control board has 4 inputs and 6 outputs (for details, see 7.8 Switch Quantity Description).

**User management:** Switch user rights.



**Control parameters:** parameters of the feeding motor can be set.

**System information:** Displays the current touch screen software version and control board software version. You can also update the control board program using the USB flash drive (for details, see 7.14 USB Flash Drive Upgrade Description).



Users can also reset the parameters, time and screen display related Settings.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".



## 7.5 Description of working parameters

A-Work Para.-1  <b>0.000 kg</b> <span style="float: right;">Running</span> FAST MIDDLE SLOW DISC		 <b>0.000 kg</b> <span style="float: right;">Running</span> FAST MIDDLE SLOW DISC		2018-08-18 10:02:26 User: engineer
< Parameters Setting				
Zeroing Range:	10%	Stable range/time:	1d	0.300s
Auto Zero Interval:	0	DigitalFilter (Running)	Feed: 7   Wait: 3   Disc: 8	
Additional Clear Nums at sart:	3	Digital filter level[STOP]	9	
Delay Time for Zeroing:	0.200s	Add to Total When(M)Disc:	<input type="checkbox"/>	
Automatic Zero When powered on:	<input type="checkbox"/>	Result Holding:	<input type="checkbox"/>	
Zero Tracking Range/Time:	1d 0.200s	Self Adaption:	<input type="checkbox"/>	
Processing of Zeroing failure:	Waiting for stability >	Auto Setting/ Self Adaption Level	Level2[balanced] >	
< HOME		Next Page >		

### Working parameters 1 diagram

A-Work Para.-2  <b>0.000 kg</b> <span style="float: right;">Running</span> FAST MIDDLE SLOW DISC		 <b>0.000 kg</b> <span style="float: right;">Running</span> FAST MIDDLE SLOW DISC		2018-08-18 10:02:26 User:engineer
< Parameters Setting				
Disc mechanism Type:	Air-operated >	Disable Feeding When OFL:	<input type="checkbox"/>	
Disc Mode:	Near zero+delay >	Positive Deviation:	<input type="checkbox"/>	
Disc Delay Time:	9.999s	UnLock Bag Mode:	Auto UnLock >	
Disc Overtime:	9.000s	After Lock/UnLock Delay Time:	0.500s	
End Wait Mode:	Dealy Dnd Wait >	Before UnLock Delay Time:	0.500s	
Wait Over Time:	0.0s	Feeding cut-off Judgment Time:	15.000s	
Deal with Wait Over Time:	Alarm&Stop >	Feeding cut-off Smart Judgment:	<input type="checkbox"/>	
< Previous Page		< HOME		Next Page >

### Working parameters 2 diagram

A-Work Para.-3		 <span style="float: right;">Runing</span> +0+ <b>0.000 kg</b> FAST MIDDLE SLOW DISC		 <span style="float: right;">Runing</span> +0+ <b>0.000 kg</b> FAST MIDDLE SLOW DISC		2018-08-18 10:02:26	
< Parameters Setting						User:engineer >	
Set Batch Number:		_ 0					
Uncomplete Batche Number:		_ 0					
				Scale Range Type:		5K	
				Vibrator:		<u>Yes</u>	
				Motor Type:		<u>Server Motor</u>	
< Previous Page				< HOME			

Working parameters 3 diagram

### Interface description:

- (1) Clearing range: clearing range (1%-20% of the full range).
- (2) Automatic zeroing interval: during operation, the device automatically zeroing after completing the set number of packets.
- (3) Start additional zeroing times: after the equipment enters the running state, the second scale shall start, and zeroing shall be performed continuously before feeding, and the number of times shall be equal to the set value of this parameter. For example, the number of additional zeroing is 2, the second and third scales are zeroed before feeding after starting.
- (4) Additional delay of zero clearing: when zero clearing is needed (whether automatic zero clearing interval or additional zero clearing interval), before zero clearing, the equipment completes the delay before feeding + after this delay, the operation of zero clearing begins.
- (5) Automatic zeroing when the device is powered on: The device is automatically zeroed when it is powered on.
- (6) Zero-point tracking range/time: zero-point tracking range 0-9D This parameter is optional. Zero-point tracking time ranges from 0.001 to 9.999.
- (7) Automatic clearing failure handling: Indicates the handling method after automatic clearing failure, including clearing the next packet again, suspending the three-packet failure, continuing to wait for stability, and suspending the packet immediately.
- (8) Stability range/time: the range of stability evaluation is 0~99d, which is optional. If the weight change within the stability evaluation time does not exceed the range of stability evaluation, it is considered as stable; otherwise, it is considered as unstable.
- (9) Operation filtering level: the filtering level used in the operation process, ranging from 0 to 9, which can be divided into feeding, fixed value and unloading. The higher the value,

the better the filtering effect, but the greater the lag.

(10) Stop filtering level: the filtering level used in the stopped state, 0-9, the larger the value, the better the filtering effect, but the greater the lag.

(11) Manual unloading accumulation: when manual unloading, packing weight is counted into the accumulation.

(12) Constant weight retention: the weight display shall remain unchanged after the end of the fixed time until the unloading is completed.

(13) Adaptive switch: If this switch is turned on during the operation of the device, the device will automatically adjust the scale according to the adaptive level.

(14) Adaptive & automatic balancing grade: it can be divided into five grades: zero grade for optimal speed, first grade for slightly better speed, second grade for equalization, third grade for slightly better accuracy, and fourth grade for optimal accuracy.

(15) Unloading mechanism type: pneumatic and electric, can be selected according to the specific structure of the equipment.

(16) Discharging mode: it can be divided into two modes: time control discharging mode and zero-zone delay discharging mode. The discharging door is closed when the unloading time is from discharging to discharging; the unloading door is closed when the unloading weight is less than zero zone value when the delay time is started.

(17) Unloading timeout time: if the unloading process exceeds the set time, the equipment will prompt the unloading timeout alarm message and automatically return to the stop state.

(18) Fixed value mode: it can be divided into two modes: time fixed value and judgment stable value.

(19) Fixed value timeout: If the fixed value is not completed within this time, the fixed value timeout processing will be entered.

(20) Fixed value timeout processing: optional timeout alarm without suspension, three-packet alarm before suspension, continuous alarm and wait for stability, continuous alarm and pause.

(21) Overrange protection: when turned on, from zero to zero (plus the part cleared), the weight is large

When it is equal to 1.2 times of the upper limit of the quantitative range, it enters the state of overrange protection. This function can prevent the occurrence of the situation that the weight is small but it has been overflowed after the larger weight is cleared to 0.

(22) Positive error mode: in the process of feeding after opening, the error generated by feeding results will be positive.

(23) Bag loosening mode: You can choose between automatic bag loosening or manual bag loosening.

(24) Delay after bag clamping/loosening: After the bag clamping or bag loosening signal is output, delay the time to stop the signal output.

(25) Delay before bagging: After delaying this time, the bagging signal is output.

(26) Fast heater cutoff timeout: If the material does not reach the set value after delaying this time, it is determined as fast heater cutoff.



(27) Intelligent judgment of fast heater cutoff: When turned on, it enters the intelligent judgment mode of fast heater cutoff.

(28) Set Batch Number: The set batch number.



- (29) Number of remaining batches: The number of remaining batches.
- (30) Compulsory use of three-level feeding (shared by AB scale).
- (31) AB interlock scale mode: When turned on, it enters the three-level feeding mode.
- (32) Forced shutdown of A (only used when A scale fails): A scale can be directly closed.
- (33) Scale specification, vibration plate and motor type: these functions are set by the manufacturer, but not by engineers and users.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".


## 7.6 Description of formula parameters

A-Rec. Para.-1						2018-08-18 10:12:26	
Parameters Setting				User:engineer			
Target:		5.000kg		Recipe ID:		09	
Fast Remains:		3.800kg		Fast Steps:		16001	
Middle Reserve:		-----kg		Middle Steps:		----	
Slow Reserve:		0.038kg		Slow Steps:		----	
Disc Mode:		Time Control Disc					
Disc Delay Time:		0.200s		Waiting Time:		0.800s	
				Multiple Disc Num:		00	
				HOME		Next Page	

Formula parameters 1 diagram

A-Rec. Para.-2 <div style="float: right;">                     2018-08-18 10:12:26                      User:engineer                 </div>	
< Parameters Setting	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Running</p> <p>→0← 0.000 kg</p> <p>FAST MIDDLE SLOW DISC</p> </div> <div style="text-align: center;">  <p>Running</p> <p>→0← 0.000 kg</p> <p>FAST MIDDLE SLOW DISC</p> </div> </div>
Before Feeding time[T1]:	0.300s
OVER/Under Check:	<input type="checkbox"/>
OVER Value:	0.010kg
Under Value:	0.005kg
SLOW Feeder Replenish:	<input type="checkbox"/>
Alarm time:	2.000s
Replenish Once Time:	0.400s
Auto Stop When Alarm:	<input type="checkbox"/>
Max Num of Replenish	1
< Previous Page      < HOME      Next Page >	

Formula parameters 2 figure

A-Rec. Para.-3 <div style="float: right;">                     2018-08-18 10:12:26                      User : engineer                 </div>	
< Parameters Setting	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Running</p> <p>→0← 0.000 kg</p> <p>FAST MIDDLE SLOW DISC</p> </div> <div style="text-align: center;">  <p>Running</p> <p>→0← 0.000 kg</p> <p>FAST MIDDLE SLOW DISC</p> </div> </div>
Feeding cut-off Judgment Time:	15.000s
Feeding cut-off Smart Judgment:	<input type="checkbox"/>
Safe Steps Actived Weight:	0.000kg
Safe Steps after Feeding Cut-Off:	0
when the Fast Feeding time over the "Feeding out-off Judgment Time", it is judged the flow Cut-off then, if the remaining weight is greater than "Safe Steps Actived Weight" the Feeding gate opened with Safe Steps, else turn to Slow Feeding	
< Previous Page      < HOME	

Formula parameter 3 diagram

**Interface description:**

- (1) Target value: A quantitative weight is required.
- (2) Rapid acceleration advance: During the quantitative process, if the weighing value is  $\geq$



the target value - the rapid acceleration advance, the rapid acceleration will be turned off.

(3) Intermediate dosing advance: During the dosing process, if the weighing value is  $\geq$  the target value - intermediate dosing advance, the intermediate dosing will be turned off.

(4) Drop value: During the quantitative process, if the weighing value is  $\geq$  the target value - drop value, the slow heater will be turned off.

(5) Unloading mode: You can select time controlled unloading or zero zone delayed unloading.

(6) Unloading time: Unloading signal output stops after lasting for this time.

(7) Zero zone value: During the quantitative process, if the weighing value is  $\leq$  zero zone value, the unloading delay timer will be started.

(8) Recipe Number: The number of the current recipe.

(9) Quick feeding opening: The opening of the feeding door during fast feeding of materials.

(10) Medium dosing opening: the opening of the feeding door when adding materials.

(11) Slow feeding opening: The opening of the feeding door during slow feeding of materials.

(12) Fixed value time: the time to determine the weight after feeding is completed.

(13) Combination Times: This is a reserved parameter. Currently, the device does not support the multi scale combination function.

(14) Delay before feeding T1: When the quantitative process starts, the feeding process starts after a delay of T1 time;

(15) Slow feeding and replenishment switch: When this switch is turned on, the equipment automatically performs slow feeding and replenishment.

(16) Single Replenishment Time: The time of a single replenishment.

(17) Maximum Replenishment Times: The maximum number of replenishment times for the equipment.

(18) Over/under tolerance switch: A switch that enables the over/under tolerance detection function.

(19) Over tolerance: During the quantitative process, if the weighing value is greater than the target value+over tolerance, it will be judged as over tolerance.

(20) Under tolerance: During the quantitative process, if the weighing value is less than the target value - under tolerance, it is judged as under tolerance.

(21) Over/under tolerance alarm time: The duration of the over/under tolerance alarm output after detecting over/under tolerance. After this time, the over/under tolerance alarm automatic output is invalid.

(22) Over/under tolerance pause switch: When this switch is turned on, if over/under tolerance occurs, the device pauses for user processing, and can then "clear the alarm" and continue running; You can also return to the stop state after an "emergency stop".

(23) AB interlocking scale body mode: There are single scale, A scale, and B scale options. When using dual scale interlocking, it can be set to A scale or B scale.

(24) AB interlock delay time: The interlock delay time is a limit time given to another weighing machine. It is specified that the output is valid within this time, and the other weighing machine cannot be unloaded. The default time is 1s

(25) Fast heater cutoff timeout: If the set value is not reached after exceeding this time, it is determined as fast heater cutoff.

(26) Intelligent judgment of fast heater cutoff: Turn on the switch, and the system will





automatically determine the fast heater cutoff.

(27) Opening weight of cut-off safety opening: When the material weight is higher than this value during cut-off, the safety opening will be opened, otherwise the original opening will remain unchanged.

(28) Safety opening degree of flow cutoff: This opening degree can ensure that the material will not be overweight when it is washed down instantaneously when it comes again. Target value: The weight to be quantified.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

## 7.7 Calibration interface description

<b>A-Calibration</b>				2018-08-18 10:12:26 User:engineer
< Parameters Setting				
Unit: [ "kg" only]	kg >	Decimal point:	0.000 >	
Minimum Division: [1d=0.001kg]	01 >	Capacity:	15.000kg	
Over Capacity mode:	Cap*120% >			
Step 1: Confirm that the hopper is empty and the discharge door is closed, Wait for the indication to be stable, click the buton to complete the cibration!		Step 2: Add standard weight, wait until the display is stable, input the actual weight, and click the button!		
Loadcell Output-mV:		Zero Calibration	Weight-mV:	
			Weight:	3.000kg
			Weight Calibration	
		< HOME Calibration with materials >		

### Interface specification

- (1) Unit: The fixed value is kg
- (2) Minimum score: 1 2 5 10 20 50 Optional.
- (3) Display mode of overrange: there are three options: when the current weight is greater than: maximum range + 9D, maximum range \*120%, and maximum range \*150%, the device will prompt weight overflow.
- (4) Decimal point: fixed value 0.000, that is, three decimal places after the decimal point.
- (5) Maximum range: maximum range of the device (do not set it to more than 20.00kg).

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

## 7.8 Step of weight calibration

1. Zero point calibration: empty the hopper and close the discharge door. Click "Zero point Calibration" after the weight is stabilized. During the calibration process, the weight display area above will display the calibration result, and stability will be displayed after successful calibration.
2. Gain calibration: Add weights to the weighing mechanism, click the weight input box after the weight is stable, input the weight of the weight, click "weight Calibration", the weight display area above the calibration process will also display the calibration result. After successful calibration, the weight displayed in the weight display area is the input weight. Otherwise gain calibration fails. Try again.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

## 7.9 Material calibration steps

<b>Calibration with materials</b> < Parameters Setting	Running +0+ 0.000 kg FAST MIDDLE SLOW DISC	Running +0+ 0.000 kg FAST MIDDLE SLOW DISC	2021-09-26 10:02:26 User □ engineer >
<b>Step1:</b> Empty the scale bucket and wait for the MV value to The indication should return to zero.	12.000 mV	Zero Calibration	
<b>Step2:</b> Click "automatic feeding"[by target value]or "(M)Fast"[by time]. Start charging. (please make sure the weight has been calibrated before automatic charging, The weight is roughly accurate, otherwise it may be filled with overflow, etc) Wait until the weight indication is stable, click "record weight" to save the current displayed value Bag claming and unloading. weigh on the standard scale to obtain the weight of the double scale (pay attention to peeling)	Target: 5.000kg Auto Feeding Udfeeding (M) Feeding TIME: 1.0s	Current Weight: 1.000kg Save the weight	(M) Disc
<b>Step3:</b> Input the weight of the weigher, click "automatic feeding", and the controller will automatically Record the weight Calibration as the weight of the scale	Standard weight: 3.000kg	Calibration with materials	
< Weight Calibration      < HOME			

1. Zero calibration: the method is the same as the zero calibration of the weight calibration scale.

2. Gain calibration:

A. Use "automatic feeding" (automatically run a scale according to the current formula target value) or "manual feeding" (click once to start fast adding, click again to close fast adding), stop feeding and wait for the weight to stabilize, click "Record Weight" to save the current displayed value.

B. Place the bag or container prepared in advance at the unloading port, click "Manual unloading", unload all the materials in the hopper into the bag or container, weigh the


materials in the bag or container (pay attention to remove the weight of the bag or container).

C. Click the input box of "Compound weight", enter the weight of the material obtained by the compound weight, and click "Material Calibration" for calibration. Wait until the calibration succeeds. After successful weight calibration is completed, exit the menu.


For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

## 7.10 Description of switch quantity interface

A-I/O-1:Input


0.000 kg

FAST MIDDLE SLOW DISC


0.000 kg

FAST MIDDLE SLOW DISC

2018-08-18 10:12:26  
 User:engineer

← Parameters Setting


Port	Define	Status	Port	Define	Status
IN01	START	<input checked="" type="radio"/>	IN05	Bag clamping request	<input checked="" type="radio"/>
IN02	Emergency Stop	<input checked="" type="radio"/>	IN06	undefined	<input checked="" type="radio"/>
IN03	Clear alarm	<input checked="" type="radio"/>	IN07	undefined	<input checked="" type="radio"/>
IN04	Interlock input	<input checked="" type="radio"/>	IN08	undefined	<input checked="" type="radio"/>

I/O Signal Test:


← HOME
Next Page →

Switching quantity 1 diagram

A-I/O-2:Output


0.000 kg

FAST MIDDLE SLOW DISC


0.000 kg

FAST MIDDLE SLOW DISC

2018-08-18 10:12:26  
 User:engineer

← Parameters Setting

Port	Define	Status	Port	Define	Status
OUT01	RUN	<input type="checkbox"/>	OUT05	LockBag	<input type="checkbox"/>
OUT02	STOP	<input type="checkbox"/>	OUT06	undefined	<input type="checkbox"/>
OUT03	FAST	<input type="checkbox"/>	OUT07	undefined	<input type="checkbox"/>
OUT04	A&B Lock out	<input type="checkbox"/>	OUT08	undefined	<input type="checkbox"/>

I/O Signal Test:

← Previous Page
← HOME
Next Page →

Switching quantity 2 diagram

A-I/O-3: Motor Control PWM < Parameters Setting		Running 0.000 kg FAST MIDDLE SLOW DISC	Running 0.000 kg FAST MIDDLE SLOW DISC	2018-08-18 10:12:26 User: engineer >
A-PWM1 Port		Feed StepMotor >	A-PWM2 Port	
Port	Define	Status	Port	Define
PU1	Feed Motor PU		PU2	<input type="text" value="undefined"/>
DR1	Feed Motor DR		DR2	<input type="text" value="undefined"/>
ZT1_1	Feed Motor Closed	<input checked="" type="radio"/>	ZT2_1	<input type="text" value="undefined"/>
ZT1_2	Feed Motor Limit	<input checked="" type="radio"/>	ZT2_2	<input type="text" value="undefined"/>
I/O Signal Test: <input type="checkbox"/>				
< Previous Page		< HOME		

Switching quantity 3 diagram

### Parameter Description:

(1) Input ports (IN01, IN02, IN03, IN04, IN05, IN06, IN07, IN08) can be customized by customers:

(2) The input ports (ZT1\_1, ZT1\_2) are fixed as photoelectric signals for the motor in place; The input ports (ZT2\_1, ZT2\_2) are general-purpose switching values, where ZT2\_1 has been set as servo alarm by default, ZT2\_2 Customer customizable.

(3) The output ports (OUT01, OUT02, OUT03, OUT04, OUT5, OUT6, OUT7, OUT8) can be customized by the customer.

(4) The output ports (DR1, PU1) are direction signals and pulse signals of the motor; The output ports (DR2, PU2) are general-purpose switching values, where the default setting for DR2 is slow acceleration, and the default setting for PU2 is unloading.

(5) Switching value test: After being turned on, you can test whether the corresponding switching value signal is normal.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

### Input definition:

The port number	The initial value	Custom list
-----------------	-------------------	-------------

IN1	1	<b>I00: No definition</b> <b>I01: start</b> <b>I02: stop</b>
IN2	2	<b>I03: stop</b> <b>I04: Feeding stepper motor origin (close the door to A level)</b>
IN3	5	<b>I05: Feeding allowed</b> <b>I06: Unloading allowed</b>
IN4	6	<b>I07: Clear alarm</b> <b>I08: keep</b>
IN5	0	<b>I09: Open/close unloading door [originally manual unloading Function, switch discharging output state]</b>
IN6	0	<b>I10: Manual unloading</b> <b>I11: Manual slow add</b> <b>I12: Manually add</b>
IN7	0	<b>I13: Manual fast add [by fast open open The door]</b>
IN8	0	<b>I14: Manual cleaning [open according to the maximum opening The door]</b>
ZT1_1	4	<b>I15: Start/stop (double edge: effective edge, Start;Invalid edge, stop)</b>

ZT1_2	24	<b>I16: Start/emergency stop (double edge)</b> <b>I17: Manual unloading (double edge)</b>
ZT2_1	0	<b>I18: Manual slow adding (double edge)</b> <b>I19: Manual adding (double edge)</b>
ZT2_2	0	<b>I20: Manual quick add (double edge)</b> <b>I21: Manual cleaning (double edge)</b> <b>I22: reset</b> <b>I23: Emergency stop [level](valid, no Start allowed, manual feeding not allowed, not allowed Manual unloading is allowed)</b> <b>I24: feeding stepping motor limit point.</b> <b>I25: Unloading stepping motor origin.</b> <b>I26: limit point of unloading stepping motor.</b> <b>I27: jam</b> <b>I28: Servo motor alarm</b> <b>I29: Double scale interlock input</b>







**Output definition:**

The port number	The initial value	Custom list
OUT1	1	<b>O00: No definition</b> <b>Run O01:</b> <b>O02: Refueling request</b> <b>O03: Feeding stepper motor direction [PW available</b> The signal is set to feed PWM] <b>O04: quick to add</b> <b>I add O05:</b> <b>O06: slow</b> <b>O07: fixed value</b> <b>O08: unloading L</b> <b>O09: over difference</b> <b>O10: alarm</b> <b>11: clip bag</b> <b>O12: Preset number of packets completed</b> <b>O13: Once packing is completed (unloading is completed</b> After output 1s clock) <b>O14: stop</b> <b>O15: direction of discharging stepper motor</b> <b>O16: Discharging motor running/forward</b> <b>O17: The unloading motor reverses</b> <b>O18: Feeding PWM[only available at OUT7/OUT8]</b>
OUT2	4	
OUT3	5	
OUT4	6	
OUT5	7	
OUT6	0	
OUT7	0	
OUT8	0	
DR1	3	
PU1	0	
DR2	8	
PU2	0	

		<b>O19: Discharging PWM[only available at OUT7/OUT8]</b> <b>O20: Servo motor alarm</b> <b>O21: Completion of setting value</b> <b>O22: Double scale interlock output</b>
PWM1 function	<b>1</b>	<b>1: general switching quantity</b> <b>2: feeding motor control</b> <b>3: unloading motor control</b>
PWM2 function	<b>0</b>	

### 7.11 Control Parameters screen Description

A-Control Parameters		 <span style="font-size: 24px; font-weight: bold;">0.000</span> kg <span style="float: right; font-size: 10px;">Runing</span>	 <span style="font-size: 24px; font-weight: bold;">0.000</span> kg <span style="float: right; font-size: 10px;">Runing</span>	2018-08-18 10:12:26
< Parameters Setting				User:engineer >
Disable judgment Time	0.700/ 0.700/ 0.700 s	Feeding StepMotor Status:	RUN CLOSE ZERO 2198	
Disable judgment Time Auto Adjust	<input type="checkbox"/>			
		Feeding StepMotor Work Frequency	60.0kHz	
		Feeding StepMotor Start Frequency	20.0kHz	
		Fast Steps:	6123	Feeding StepMotor Steps Tab
Feeding StepMotor Max.Step:	20000	Fast Steps:	4123	
		Slow Steps:	2	
< HOME				

#### Interface specification

(1) Prohibition time for fast, medium, and slow acceleration: At the beginning of quantification, to avoid overshoot, weight judgment is not performed at this time. Fast acceleration, medium acceleration, and slow acceleration are always effective

(2) Slow acceleration intelligent prohibition switch: When this switch is turned on, the slow acceleration intelligent prohibition function is enabled.



(3) Motor Subdivision: Set value of motor subdivision.

(4) Reducer reduction ratio: The reduction ratio of the current reducer.



- (5) Maximum angle of feeding gate: the maximum opening angle of the current feeding gate.
- (6) Maximum opening degree of charging motor (pulse number): To protect the motor, the maximum opening degree allowed after starting the motor is allowed.
- (7) Initial Opening Calibration Value: The calibration value of the current initial opening.
- (8) Feeding motor status: four states can be seen: stop, open, origin, and opening.
- (9) Feeding motor operating frequency: the frequency at which the feeding motor operates normally.
- (10) Starting frequency of charging motor: the frequency at which the charging motor is started.
- (11) Quick heater opening: the current fast heater opening value.
- (12) Medium Plus Opening: The current medium plus opening value.
- (13) Slow heater opening degree: the current slow heater opening degree value.

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

## 7.12 Communication Parameters screen description

A-Communication Para.		 <span style="float: right;">Runing</span> <span style="font-size: 2em;">0.000 kg</span> <small>FAST MIDDLE SLOW DISC</small>		 <span style="float: right;">Runing</span> <span style="font-size: 2em;">0.000 kg</span> <small>FAST MIDDLE SLOW DISC</small>		2018-08-19 10:09:36	
◀ Parameters Setting						User:engineer ▶	
A-COM1	Used to this HMI, Cannot set:			A-LAN	The LAN port on the controller. Not the LAN port on this HMI.		
ID:	001			IP and Port:	_ 0 . _ 0 . _ 0 . _ 0 : 000		
Protocol:	Modbus-RTU ▶			Protocol:	Modbus-TCP/IP ▶		
BAUD:	[may not be default, adaptive]		57600 ▶	DoubleWord Format:	AB-CD ▶		
Byte Format:	[Parity bit can be different]		1-8-E-1 ▶	MAC:	00: 00: 00: 00: 00: 00:		
DoubleWord Format	AB-CD ▶						
HMI parameters:	COM2	57600	Even				
◀ HOME				Next Page ▶			

Communication parameter 1 diagram



A-Communication Para.		 <span style="float: right;">Running</span> <span style="font-size: 2em;">0.000 kg</span> <small>FAST MIDDLE SLOW DISC</small>		 <span style="float: right;">Running</span> <span style="font-size: 2em;">0.000 kg</span> <small>FAST MIDDLE SLOW DISC</small>		2018-08-19 10:09:36	
<a href="#">Parameters Setting</a>						User:engineer	
A-COM1 Used to this HMI, Cannot set:				A-LAN The LAN port on the controller. Not the LAN port on this HMI.			
ID: 001				IP and Port: 0.0.0.0:000			
Protocol: Modbus-RTU				Protocol: Modbus-TCP/IP			
BAUD: [may not be default, adaptive] 57600				DoubleWord Format: AB-CD			
Byte Format: [Parity bit can be different] 1-8-E-1				MAC: 00:00:00:00:00:00			
DoubleWord Format AB-CD							
HMI parameters: COM2 57600 Even							
<a href="#">HOME</a>				<a href="#">Next Page</a>			

Communication parameter 2 diagram

### Interface description:

- (1) Address number: Slave number. The ID number of the serial communication
- (2) Protocol Type: Communication protocol. Select the protocol for serial communication.
- (3) Baud Rate: Select the baud rate of the serial port.
- (4) Byte Format: Data format. Initial value; 1-8-E-1 (8-bit data bit-even parity - 1-bit stop bit;)
- (5) Double word register order: Modbus high and low words The order in which high words come first is AB-CD, and the order in which low words come first is CDAB.
- (6) Current HMI communication parameters: Displays the current communication parameters of the touch screen.
- (7) IP and Port: IP address.
- (8) MAC: MAC address.



### 7.13 Historical data page description

A-History Data		 <span style="float: right;">Runing</span> <span style="font-size: 2em;">0.000 kg</span> <small>FAST MIDDLE SLOW DISC</small>		 <span style="float: right;">Runing</span> <span style="font-size: 2em;">0.000 kg</span> <small>FAST MIDDLE SLOW DISC</small>		2018-08-19 10:09:36		User:engineer >		
< HOME										
Index	TIME	Mat.Rec	Target	ACT.	Time	E	Sec.	Total PCS	Total	OP. OL.
									Select	OP. OL.
									Goto	OP. OL.
										OP. OL.
									Auto Refresh	<input type="checkbox"/>
									(M)Refresh	
									Export to Udisk	
FirstPage	PreviousPage	NextPage	LastPage	Setting	Clair Data			< HOME		

#### Interface description:

- (1) Automatic refresh/Manual refresh: Refreshes data.
- (2) Usb disk export: You can export historical data.
- (3) Clear data: Clear historical data.

## 7.14 Description of automatic balance adjustment interface

A-Automatic						2018-08-18 10:42:26	
← Parameters Setting						User:engineer >	
Material ID/Name: 03/		Material 03 >		Auto Setting/ Self Adaption Level: Level2[balanced] >			
Recipe ID/Tareget: 01 /		5.000kg		Steps Auto Adjust <input type="checkbox"/>		Levels	
Fast Remains: 2.000		1.600kg		Fast Steps: 1		6123	
Middle Reserve:				Middle Steps:			
Slow Reserve: 0.008		0.005kg		Slow Step: 1123		2	
Previous: 24.998		Total Time: 3.982		Remaining NUMS: 00		Current Status: END	
Fast: 2.232 Middle: 0.000		Slow: 1.234		Auto Setting Nums: 09		<input type="button" value="Give up"/>	
Wait: 0.900 Disc: 0.000		T1: 1.004				<input type="button" value="Start Auto Setting"/> <input type="button" value="SAVE"/>	
< HOME							

### Interface description:



- (1) Material No./Name: You can set the material number and name;
- (2) Recipe Number/Target Value: Set the recipe number and target value;
- (3) Adaptive&Automatic Scaling Level: There are four levels in total, with Level 0 being the fastest, and the higher the level, the slower the speed;
- (4) Automatic adjustment of opening: automatic adjustment function switch for the opening of the feeding door;
- (5) Feeding Level: Two or three levels of feeding, automatically set by the system based on the target value;
- (6) Quick charging opening: the opening of the fast charging door.
- (7) Medium feeding opening: the opening of the medium feeding door.
- (8) Slow feeding opening: the opening of the slow feeding door.
- (9) Scale adjustment times: You can set the scale adjustment times.

### Automatic weighing steps and description

Schedule and the opening is divided into two columns, as shown in the above, in front of its value for the automatic tuning weigh the value of the former at the back of the numerical value for automatic adjustment scale, users only need to set the number of scales (range 3-10), click on "start adjustment scale" can be in the process of automatic adjustment scale, equipment according to set automatically adjustable scale level automatically adjustable scale, At the same time, users can choose to save or abandon the adjusted value of automatic balancing according to the adjustment value of automatic balancing. Save the adjusted value of automatic balancing into the current formula. If you give up, the value before automatic balancing will still be used.If the balance adjustment

fails to meet the requirements of the user after completion, the customer can start the automatic balance adjustment again, and the equipment will adjust and modify again on the basis of the completion of the last balance adjustment. Users can also manually modify the lead and opening parameters.

## 7.15 Describes the user management interface

User Management < Parameters Setting			2018-08-18 10:45:20 User:engineer >
Current User <span style="float: right;">Engineer</span>			
Change Password >			
Log-off, Re-login >			
Auto Login: <input checked="" type="checkbox"/>			
< HOME			

### Interface description:

Displays the current logged-in user, can change password and set automatic logged-in.

The user level of this system is divided into four levels, from high to low: reserved user (used by manufacturers), engineer, administrator and operator.

### The cancellation

After a user logs in, to log out or switch to another user, click User Logout →



To switch a user, log out of the user management page and enter the user ID and password on the login page

### Change the password



Path: parameter setting, user management, password modification, click on the password input box, and follow the prompts

For specific operation methods, please refer to Chapter 7.1 "Operating Instructions for Buttons and Operation Boxes".

## 7.16 System information interface description



SYS Info-1: Name and Version				2018-08-18 10:02:26
<a href="#">Parameters Setting</a>				User:engineer >
Device Name:	AF-5K StepMotor/Serov Packing Scale			
Model :	AF-5K	<input type="button" value="COM1 ID Config"/>		
Software Version:	Weighing controller:	Ver:03.02.00	2018/08/08 18:18:18	<input type="button" value="A-U-disk Upgrade"/>
PLC:				
HMI: Ver:01.00.02 2018/08/09 18:19:19				
Manufacturer:	杰曼科技			
Support Hotline:	( +86 ) 0000 - 00000000			
		<a href="#">HOME</a>		<a href="#">Next Page</a> >

System information 1 figure

SYS Info-2: A-Reset Para.				2018-08-18 10:02:26
<a href="#">Parameters Setting</a>				User:engineer >
Restore factory settings:	(Engineer) >	Reset Work Parameters:	(Engineer) >	
Recipe Parameter Reset	(Admin,Engineer) >	Calibration parameters Reset	(Engineer) >	
Reset I/O Define	(Engineer) >	Communication Para.Reset	(Engineer) >	
Reset Peripheral pameters	(Engineer) >	Reset Self Adaption Para	(Engineer) >	
<p>be careful: If you perform this operation,the original parameters will be lost It may lead to abnormal working condition of equipment</p>				
<a href="#">Previous Page</a>		<a href="#">HOME</a>		<a href="#">Next Page</a> >



System information 2 figure

SYS Info-3:HMI Para and A Sync:		 <span style="float: right;">Running</span> <div style="text-align: center; font-size: 24px; font-weight: bold;">0.000 kg</div> <div style="display: flex; justify-content: space-around; font-size: 10px;"> <span>→0←</span> <span>FAST</span> <span>MIDDLE</span> <span>SLOW</span> <span>DISC</span> </div>		 <span style="float: right;">Running</span> <div style="text-align: center; font-size: 24px; font-weight: bold;">0.000 kg</div> <div style="display: flex; justify-content: space-around; font-size: 10px;"> <span>→0←</span> <span>FAST</span> <span>MIDDLE</span> <span>SLOW</span> <span>DISC</span> </div>		2018-08-18 10:02:26	
<a href="#">← Parameters Setting</a>				User : engineer >			
Auto screen closing without operation: <input type="checkbox"/>				Auto off Screen Delay Time: <u>300s</u>			
Auto screen Save: <input type="checkbox"/>				Auto Screen Save Time: <u>300s</u>			
Hidden Language Select Menu: <input type="checkbox"/>							
HMI Time: 2018-08-18 10:02:26		<a href="#">Setting</a>		(M)Time Sync: <a href="#">HMI -&gt; GMF01</a>		<a href="#">GMF01 -&gt; HMI</a>	
GMF01 Time: 2018-08-18 10:02:26		<a href="#">Setting</a>					
<a href="#">← Previous Page</a>				<a href="#">← HOME</a>			

System information 3 figure

### Interface description:

System information 1 Shows the device information diagram. You can see the device name, model number, software version, manufacturer, technical support number, and so on.

System info 2 shows the restoration of factory Settings. Engineers and reserved users can reset all parameters. Specific instructions are as follows:

**Restore factory Settings - Reset all system parameters to their default Settings.**

**Operating parameter reset - Resets basic system parameters to their default Settings.**

**Calibration parameter reset - Reset system calibration parameters to their default Settings.**

**Recipe parameter Reset - Resets system recipe parameters to their default Settings.**

**Peripheral parameter reset - Resets system peripheral parameters to their default Settings.**

**Adaptive parameter Reset - Resets system adaptive parameters to default Settings.**

**Communication parameter reset - Resets system communication parameters to default Settings.**

**Switch quantity definition reset - Reset the system switch quantity definition to the default configuration.**

System info 3 The screen setting diagram is shown. Engineers can set the parameters of the touch screen.

**Usb disk upgrade system:**

This operation is very important and cannot be performed unless necessary. If the operation is necessary, please contact the company and complete under the guidance of professional personnel.

## 8. Basic Function description

### 8.1 Basic running process

After the external input running signal is effective, the equipment enters the running state and begins the automatic quantitative process. The specific process is as follows:

1. Judgment before starting, whether the target value is set reasonably, whether the size of the feeding door needs to be adjusted, etc.
2. Delay time before starting feeding.
3. If the self-adaptive function is turned on, judge whether self-learning is needed again (if the current formula does not have fast increase lead amount and fall value parameters, self-learning needs to be restarted); otherwise, feed directly according to the current formula parameters. The following describes the process after the adaptive function is enabled
4. If the adaptive function is turned on, the first scale learns the approximate fast increase and drop value.
5. Start feeding normally from the second scale, and according to the feeding results of each scale, the controller will calculate automatically to judge whether the fast adding value and the drop value are appropriate and make automatic correction.
6. Start the fixed hold time after feeding.
7. Record the current weight value as the result of the scale after the fixed holding time.
8. If the overcurrent and undercurrent detection switch is turned on, the overcurrent and undercurrent detection function is processed.
9. Judge the bag input signal is effective, then output unloading.
10. When the unloading time is up, close the unloading output and start the loosening bag to delay the loosening bag.
11. After the completion of a basic packaging process, proceed to the next packaging process and start the delay time before feeding.

### 8.2 Overage and underage detection function

After the over-under-difference switch is opened and the feeding is completed during operation, the current feeding result is judged after the fixed holding time ends:

Target value - underdifference value  $\leq$  feeding result  $\leq$  target value + out-of-tolerance value, then judged as qualified.

Feeding result  $>$  target value + overerror value, then judged as overerror, output overerror alarm signal.

If the feeding result is less than the target value - underdifference value, it is judged as underdifference, and the over-underdifference alarm signal is output.

When the overgap occurs, if the overgap suspension switch is opened, the controller will temporarily schedule the packaging operation, prompting the overgap suspension and waiting for the user to process. The user can input the clear alarm signal to continue the

packaging operation, or input the emergency stop signal to enter the stop state and stop the packaging operation.


### 8.3 Overage and underage detection function

1. After setting the AB scale, the unloading delay time, and the on-off signal, it defaults to the dual scale mode.

2. After the external input operation signal is valid, the device enters the operation state.

3. Judge whether the bag clamping signal is valid. In the dual scale mode, Scale A responds to the bag clamping and unloads the material. At the same time, it will output an interlock signal to Scale B, and then Scale B will automatically cancel the bag clamping request (here is an example).

4. After completing a basic packaging process, proceed to the next packaging process.



Schematic Diagram of Double Scale Interlock

## 9. Common failure analysis and troubleshooting

Common faults in use, causes and handling methods.

The serial number	The fault phenomenon	fault	To deal with
1	Equipment start does not fall material	1. No material in storage bin 2. Storage bin stop door is not opened 3. Air source leakage connection 4. Air source pressure is too low or no pressure	1. Add material to storage bin 2. Open the storage bin stop door 3. Connect the air source 4. Increase air pressure or turn on air pressure switch
2	No unloading after weighing	1. The device cannot receive the bagging signal 2. The number of combinations of single scales is not set to 0	1. Check and eliminate 2. Set the corresponding combination times as required
3	The actual weighing has been out of tolerance	1. Equipment not calibrated 1. Fast increase the time limit setting is too large	1. To a scale 2. Fast increase the time limit appropriately reduced
4	The value is unstable	1. Strong winds or strong vibrations in the surrounding environment 2. Weight sensor failure	1. Check and eliminate 2. Check the sensor and replace if necessary
5	The weight is not up to standard	1. Weight sensor failure 2. Not cleared before use 3. Equipment not calibrated 4. Incomplete unloading	1. Check the sensor and replace if necessary 2. Stop reset 3. recalibrate 4. Increase discharge time appropriately

---

6	Data cannot be exported	1.U disk is damaged 2.The USB interface of the electrical control box is damaged	1.Replace the U disk 2.Check the interface
---	-------------------------	---	---

## 10. Maintenance and warranty

To ensure the weighing accuracy of the equipment, do not place the equipment in a cold and damp environment. Clean the dust generated by materials inside the equipment regularly according to the use condition. Remember to close the door of the electric control cabinet after daily use or maintenance.

- Warranty principle

In principle, the first installation and debugging should be carried out by our professional and technical personnel or companies entrusted by our company.

Equipment failure caused by the following conditions is not covered by our warranty:

- Do not follow the operation instructions
- Installation without professional guidance
- Make structural changes to the equipment
- Unauthorized damage to equipment
- Programming and operation errors
- Natural equipment damage