



杰 • 曼 • 科 • 技

M04-D

User's Manual

110609090003

V01.00.11_01


©2018 Shenzhen General Measure Technology Co., Ltd. All rights reserved.

Without Shenzhen General Measure Technology Co., Ltd.'s permission, any company or person have no responsibility to copy, transmit, transcribe or translate to any language version.

Our company's products are under continually improvement and updating so we reserved the right to modify this manual at any time without notice. For this reason, please visit our website regularly to update newest information.

Company Website <http://www.szgmt.com>

Product performance standards: GB / T 7724-2008



able of Contents

1.	Outline.....	- 1 -
1.1	Functions and Features.....	- 1 -
1.2	Front Panel Description.....	- 1 -
1.3	Rear Panel Description.....	- 2 -
1.4	Technical Specifications.....	- 2 -
1.4.1	General specifications	- 3 -
1.4.2	Analog part.....	- 3 -
1.4.3	Digital part.....	- 3 -
2.	Installation.....	- 4 -
2.1	General principle	- 4 -
2.2	Load Cell Connection.....	- 4 -
2.3	I/O Module Port Connection	- 5 -
2.4	Power Supply Connection	- 6 -
2.5	Serial Port Connection.....	- 6 -
3.	User Permission Description.....	- 8 -
4.	M Menu.....	- 9 -
4.1	Recipe Parameter.....	- 11 -
4.2	Operating Parameter.....	- 15 -
4.3	Peripheral Parameter	- 17 -
4.4	Motor Parameter.....	- 20 -
4.5	Calibration.....	- 27 -
4.6	Cumulative and batch.....	- 29 -
4.7	I/O Module	- 30 -
4.7.1	Output port & input port definition	- 31 -
4.7.2	I/O Test.....	- 40 -
4.8	Serial Port Parameter.....	- 41 -
4.9	User Management	- 42 -
4.10	System Information	- 42 -
5.	Function Description	- 46 -
5.1	Setting the operating mode.....	- 46 -
5.2	Batch	- 47 -
5.3	Filling Level Control	- 47 -
5.3.1	Dual Supplement	- 47 -
5.3.2	Single Supplement.....	- 47 -
5.4	Quick Setup.....	- 47 -
5.5	Sewing Process.....	- 48 -

5.6 Bracket upward	- 49 -
5.7 Discharge patting function	- 49 -
6. Serial port communication	- 50 -
6.1 Printing method	- 50 -
6.1.1. Auto Print	- 50 -
6.1.2 Total cumulative print (key 1)	- 51 -
6.1.3 Cumulative print the recipe (key 2/3).....	- 51 -
6.1.4 User cumulative print (4/5 button)	- 52 -
6.2 Continuous mode.....	- 52 -
6.2.1 Continuous mode data frame format is as follows:	- 52 -
6.3 Modbus-RTU protocol	- 53 -
6.3.1 Function code and abnormal code.....	- 53 -
6.3.2 MODBUS transmission mode	- 54 -
6.3.3 MODBUS address assignment	- 54 -
6.3.4 Modbus-RTU protocol	- 80 -
7. Automatic packaging process.....	- 82 -
7.1 Dual scale with hopper mode packaging.....	- 82 -
7.2 Scale A with hopper mode packaging	- 84 -
7.3 Scale B with hopper mode packaging	- 84 -
7.4 Dual scale without hopper mode packaging.....	- 86 -
7.5 Dual scale without hopper individual packaging	- 87 -
8. Motor Work Process	- 88 -
8.1 Motor Filling Portion	- 88 -
8.1.1 Step Motor Drive Filling	- 88 -
8.1.2 Motor Drive Filling	- 88 -
8.2 Motor lock Bag Portion.....	- 89 -
8.2.2 Motor Drive Dual-Limit lock/unlock bag	- 89 -
8.3 Motor Discharge Portion	- 90 -
8.3.1 Step Motor Drive Discharge.....	- 90 -
8.3.2 Motor Drive Single-Limit Discharge	- 91 -
8.3.3 Motor Drive Dual-Limit Discharge.....	- 91 -
8.3.4 Motor Drive Rotating Discharge	- 92 -
9. Dimension (mm)	- 93 -


1. Outline

M04-D is a dual scale bagging controller specifically developed for automatic quantitative packing scale. With English display interface, simple operation and new algorithms enable weighing faster and more accurate. The USB connecting port and dual serial ports make it easier to connect with system. **M04-D** controller can be widely used in below industry, feed, chemicals, grain and other needs quantitative packaging equipment.

1.1 Functions and Features


- Full English display interface, make the operation more intuitive and easy
- Two optional weigher mode: With hopper mode and without hopper mode.
- 20 switch input and output control (8 in /12 out), input and output port location can be customized. Support extended IO board (4 in /5 out) for maximum user convenience
- Switch test functions, and convenient packaging weighers debugging
- Three levels speed automatic control feeding, with optional slow jogging.
- It can store 40 kinds of recipes for different range of materials
- Convenient USB port to input and output of various types parameters
- feed control functions, convenient packing scale with the front feeding device of control
- Multiple digital filter function
- Automatic drop correction function
- Multiple digital filtering function
- Batch number setting function
- Patting bag function for packing powder materials
- Automatic zero tracking function
- Time / date function
- User permission identity settings
- Dual serial ports to connect with printer, computer, Secondary display.

1.2 Front Panel Description



- ◆ Display interface: to show weight value, state and recipe information.
- ◆ Digit keys: for data input and change shortcut parameters.
- ◆ Function key: **【Zero1】** Zero key for scale A
【Zero2】 Zero key for scale B
【M】 Menu key, administrators and system administrators can set parameters list.
【Esc】 Exit key, to exit the current interface and return to the previous screen.
【Enter】 Confirm key, to confirm the current operation.

1.3 Rear Panel Description



1.4 Technical Specifications

1.4.1 General specifications

Power supply: AC **90~260V50Hz (or 60Hz)±2%**

Power filter: Included

Operating temperature: -10 to 40°C

Maximum humidity: 90% RH without dew

Power consumption: about **15W**

Dimensions: 218×118×76.5mm

1.4.2 Analog part

Load cell power supply: DC**5V 125mA (MAX)**

Input impedance: 10MΩ

Zero adjustment range: **0.002~15mV (when load cell is 3mV/V)**

Input sensitivity: 0.02uV/d

Input range: **0.02~15mV**

Conversion: **Sigma-Delta**

A/D Conversion rate: **120,240,480,960** Times/second

Non-linear: **0.01% F.S**

Gain drift: **10PPM/°C**

The maximum display accuracy: 1/**100000**

1.4.3 Digital part

Display: **5 inch TFTLCD screen (800x480)**

Negative display: "-"

Overload Indication: weight over range/low signal of load cell

Decimal point position: 5 options

2. Installation


2.1 General principle

M04-D controller uses AC220V 50Hz power supply with grounding to guarantee the safety of the controller and other equipment connected.


The cables connecting M04-D to load cells should not bind with other cables, especially power supply cables, and must use shielded cables, because the signals from the load cells is low voltage analog signals.

Note: Please DON'T connect the Ground Wire of the controller directly to the GND of other equipment.


To install the M04-D into a control box, please refer to the last chapter of this manual first, and make appropriate installation holes according to the position of screw holes on the housing box, remove the fixing plates on both sides of M04-D, put the controller into the housing box, fix it with the fixing plates and lock them with screws.



Aperture Of Control Box




Insert Controller



Tighten Strips Of Both Sides

2.2 Load Cell Connection

When you chose the six-wired load cells, you must bridge the SN+ with EX+ and bridge the SN- with EX-



EX+: Excitation+ EX-: Excitation- SN+: Sense+ SN-: Sense- SIG+: Signal+ SIG-: Signal-

2.3 I/O Module Port Connection

M04-D Controller uses optoelectronic isolation technology to transfer the ON/OFF data. This needs 24V DC power supply that is provided from outside, through the 24V+ and the 24V-. The I/O signal input is low level effective. The output is open-collector output. The driving current can reach 500mA.




Figure: Input Schematics (Take IN1, IN3, IN5, IN7 as example)





Figure: Input Schematics (Take OUT1, OUT9 as example)

M04-D I/O signals definitions refer Section 4.6.

2.4 Power Supply Connection


M04-D Packaging controller uses **90 ~ 260V, 50Hz** power supply with grounding. The correct connections are depicted below:




L-Live Wire **GND -Ground Wire** **N- Null Wire**

2.5 Serial Port Connection


M04-D can provide two serial ports. It is depicted below. One for RS485(Port A、B、GND), the other is for optional RS232 or RS485. Factory is defaults to RS-232, and RS485 is required when ordering.(Port RXD/A、TXD/B、GND) serial ports support MODBUS mode, Cont mode and Print format.



Controller and computer connection diagram:



Connection between M04-D and a host computer(RS-232):



Connection between M04-D and a Host Computer (RS-485)

3. User Permission Description

In order to prevent wrong operation causing M04-D working improperly, it provides three rights (operators, administrators and system administrators). System administrator can perform all operations (not open to users). The operator and administrator rights restrictions are as follows:

Character	Operation
Operator	Not allow to set calibration parameter or calibration.
	Not allow to revise the working parameter.
	Not allow to define I/O.
	Not allow to delete or clear accumulated value.
	Allow to enter System information check version.
Administrator	Not allow to revise weigher structure parameter in Working parameter.
	Not allow to set shortcut defines or input parameters by USB.

- ◆ Operators log on when connect power.
- ◆ User log in identity shifted by pressing Zero button. The initial password is 000000.
- ◆ To set password of administrator in User administration of System Info.

4. M Menu

Administrator and system administrator can press **M** button to enter menu for checking or revise parameters.

Description	
Administrator	
Recipe	Indicator has 40 recipe memories from 01 to 40.
Working Parameter	Each recipe includes many parameters.
Peripherals	User can accordingly set and edit this value.
Motor Parameter	
Calibration	
ACUM And Batch	Recipe ID: 01
I/O Module	Target: 0.00kg
Serial Port	
User Management	Button: 1-Choose Recipe
System Info.	
Items	Information

As figure showed above, the left side is parameter list; the right side is brief description and parameter information.

- ◆ **【▲】** and **【▼】** : Change parameter option.
- ◆ **【Enter】** Check and set parameter information.
- ◆ **【Esc】** Exit the current interface and return to the previous page.

Menu	Parameter	Parameter list	Description
M	Recipe parameters	Quantitative value	Quantitative value setting.
		Scale A parameter setting	Scale A feeding weight and time setting.
		Scale B parameter setting	Scale B feeding weight and time setting.
		Time Parameters	Quantitative time setting.
		Over/Under	Over/Under mode, supplement parameters setting.
		Fall correction	Fall correction mode, range parameters setting.
	Operating parameters	Basic parameters	Basic parameters setting.
		Advanced parameters	Run state parameter setting.

	Scale structure	Scale structure parameter setting.
Peripheral parameters	Patting parameters	Pat time, mode setting.
	Coding parameters	Coding parameters setting.
	Conveyor parameters	Conveyor parameters setting.
	Print parameters	Serial port print parameter setting.
Calibration	Weighing parameters	Units, decimal, range and other parameters setting.
	Scale A empty calibration	Scale A zero point calibration.
	Scale A weight calibration	Scale A weight value calibration.
	Scale B empty calibration	Scale B zero point calibration.
	Scale B weight calibration	Scale B weight value calibration.
Accumulated and Batch	Recipe list	Check, clear, print recipe accumulative information
	User list	Check, clear, print accumulated information for each user package
	Batch	Batch setting, check accumulated batch.
I/O Module	Input definition	Input port definition.
	Output definition	Output port definition.
	Input test	To test whether each input port is normal
	Output test	To test whether each output port is normal
Serial Port Parameters	RS485	Serial port 1(RS485) parameter setting.
	RS232/RS485 Optional	Serial port 2(RS232/RS485) parameter setting.
User Man-	User list	Change user log in.

	Management	User editing	Edit user permission and password.
		Auto login	User auto-login setting.
	System Info.	View version	View the software version and time of system.
		Password Management	Parameters password management(calibration password must set ON.)
		Recovery / Backup	Parameters backup and restore to factory settings
		Data input via USB	Input working parameter, recipe parameter, calibration parameter, I/O module parameter and serial port parameter.
		Data output via USB	Output working parameter, recipe parameter, calibration parameter, I/O module parameter and serial port parameter.
		Shortcut keys definition	Digit button definition.
		Other settings	Screen brightness adjustment, screen saver time, select serial port.

4.1Recipe Parameter

Administrator	
Recipe	Indicator has 40 recipe memories from 01 to 40.
Working Parameter	Each recipe includes many parameters.
Peripherals	User can accordingly set and edit this value.
Motor Parameter	
Calibration	
ACUM And Batch	Recipe ID: 01
I/O Module	Target: 0.00kg
Serial Port	
User Management	Button: 1-Choose Recipe
System Info.	

When move to recipe parameter interface:

- ◆ Press digit 1 and display recipe number, input 1~40 to revise recipe number.
- ◆ Press 【Enter】 to enter the current recipe parameters.

In the recipe parameters interface:

- ◆ 【◀】 & 【▶】 Change recipe parameters.
- ◆ 【▲】 & 【▼】 Select the corresponding parameter item.
- ◆ Press 【Enter】 to modify parameters.
- ◆ Press 【Esc】 key to exit.

Recipe Item	Parameter	Description
Quantitative value	Packaging weight value setting.	
	1.Target value	Quantitative target value
	2.A Target value	Effective in solo mode
	3.B Target value	Effective in solo mode
	4.Zero zone value	In quantitative process, if the weighing value $\leq$ zero zone, starts t5 discharge delay timer.
A.param eter settings	1.A Coarse Flow lead quantity	In quantitative process, if the weighing value $\geq$ target value – Coarse Flow leading quantity, closing Coarse Flow feed.
	2.A Medium Flow lead quantity	In quantitative process, if the weighing value $\geq$ target value – Medium Flow leading quantity, closing Medium Flow.
	3. A free fall value	In quantitative process, if the weighing value $\geq$ target - free fall value, closing Fine Flow.
	4. A Coarse Flow inhibit timer	When quantitation begins, in order to avoid weight overshooting is not performed; the Coarse Flow is effective during this period.
	5. A Medium Flow inhibit timer	When Coarse Flow feed is completed, in order to avoid weight over shooting is not performed, the Medium Flow is effective during this period.
	6. A. Fine Flow inhibit timer	When Medium Flow is completed, in order to avoid weight over shooting is not performed, the Fine Flow is effective during this period.
	7. A. Unlock Bag Pre-Delay Timer	This parameter is invalid in hopper mode. In no hopper mode, scale A result waiting (patting) finish, output unlock bag signal.
B.param eter settings	1.B. Coarse Flow lead quantity	In quantitative process, if the weighing value $\geq$ target - Coarse Flow feed lead quantity, closing Coarse Flow.

	2.B. Medium Flow lead quantity	In quantitative process, if the weighing value $\geq$ target - Medium Flow lead quantity, closing Medium Flow.
	3.B. free fall value	In quantitative process, if the weighing value $\geq$ target -free fall value, closing Fine Flow.
	4. B. Coarse Flow inhibit timer	When quantitation begins, in order to avoid weight over-shooting is not performed, the Coarse Flow is effective during this period.
	5. B. Medium Flow inhibit timer	When Coarse Flow is completed, in order to avoid weight over shooting is not performed, the Medium Flow is effective during this period.
	6. B. Fine Flow inhibit timer	When Medium Flow is completed, in order to avoid weight over shooting is not performed, the Fine Flow is effective during this period.
	7. B. Unlock Bag Pre-Delay Timer	This parameter is invalid in hopper mode. In no hopper mode, scale B result waiting (patting) finish, output unlock bag signal.
Time parameters	Addition process for setting the delay time dependent parameter	
	1Before feeding delay	In with hopper mode, when quantitation begins, controller will proceed stable and zeroing after delay timer, and then start feeding. (Not stable or zero if out of zero interval.) In without hopper mode, when completed bag lock, the controller will judge stable and tare.
	2Over/Under detection time	When the function set ON, detection timer will begin after feeding complete.
	3. Value hold time	When the setting mode is selected for delay setting, after closing the Fine Flow, starting value within the hold time, and than move to next step.
	4. Discharge delay time	In discharge process, the delay timer will start when weighing value is smaller than zero zone value. The discharge signal turned off when delay time is over.
	5. Discharge interlock time	With hopper mode, A, B discharge interval.
	6. Bag lock delay timer	When received bag lock signal and delay timer passed, bag lock completed.
	7. Bag unlock delay timer	With hopper mode: output bag lock signal after delay timer. Without hopper mode: output bag lock signal after patting bag completed.

	8. Low level valid signal delay	Without hopper mode is active, the scales A bag locked and detected a valid signal, B also bag locked, then even in this case the low level is invalid then B should start feeding.
	9.Bracket upward delay time	In hopper - free mode, the delay is executed after the rise signal is emitted. Initial value: 0.0; Range: 0.0 ~ 99.9. (Unit s).
	10.Bracket downward delay time	Start the value delay after it ends. Initial value: 5.0;Range: 0.0 ~ 99.9.(unit s)
Over/Under	Over/Under alarm parameter setting	
	1Over/Under detection switch	ON/OFF. Judge over/under when in quantition process.
	2Over/Under pause switch	ON/OFF. If set ON, the controller will stop if over or under. Input emergency stop and return to stop status, clear alarm information. Or input clearing alarm, press ENTER to procees quantitation.
	3Over value	In quantitative process, if the weighing value $\geq$ target value+over value, judged as under. Initial value: 0 .
	4.Under value	In quantitative process, if the weighing value $\leq$ target value-under value, judged as under. Initial value: 0 .
	5.Supplement material switch	Supplement material judgement switch. ON: Slow jogging of material when under. (According to supplementary times). OFF: Not supplement materials.
	6.Supplement material times	If under, start to supplement materials as per setting times. Initial value: 1 . Range: 1~99.
	7.Effective supplement time	Effective jogging time within a cycle period. Initial value: 0.5. Range: 0 ~ 99.9s.
	8.Ineffective supplement time	Ineffective jogging time within a cycle period. Initial value: 0.5. Range: 0 ~ 99.9s.
Free fall correc- tion	For setting parameters automatically adjust the gap	
	1. Free fall correction switch	Correct according to actual falling materials.
	2Correction sampling times	Catch the average of free fall value and set as correction basis. Initial value: 1. Range: 1~99.
	3.Free fall correction	When this drop value exceeds the set range, it will not be included in the arithmetic average range. Initial value: 2.0 .

	range	Range: 0.0 ~ 9.9(Percent of the target)
	4.Free fall correction magnitude	Every fall correction magnitude; Option: 100%, 50%, 25% I. Initial value: 50%.

* note: new parameters A. delay time before loose bag and B. there is an interlock relationship between delay time before loose bag and delay time before loose bag.

In ab-independent mode without bucket: A. delay time before loose bag and B. delay time before loose bag can be set as values; delay time before loose bag is locked as unsettable state.

In combination mode with bucket or without bucket AB, the delay time before the loose bag can be set to A value. A. the delay time before the loose bag and B. the delay time before the loose bag are locked to an unsettable state.

4.2Operating Parameter

In the interface operating parameters:

- ◆ 【◀】 and 【▶】 to change the operating parameters.
- ◆ 【▲】 and 【▼】 to select the corresponding handover parameter item.
- ◆ Press 【Enter】 to modify item parameters setting.
- ◆ Press 【Esc】 to exit the operating parameters of the interface.

Items	Parameters	Description
Basic parameter	1.Auto-zero power on	ON/OFF. Automatically zeroing when power on. Initial value: OFF.
	2.Zero range	Initial value: 50, range: 1~99 (The percentage of full scale).
	3. Stable range	Stable if the controller is within this range. Initial value: 2. Range: 0~99(d) .
	4. Stable time	Initial value: 0.3. Range: 0.1~9.9.
	5. Zero tracking range	The controller will be auto zero within the range. Zero tracking will not proceed if zero. Initial value: 0. Range : 0~9(d) .
	6. Zero tracking time	Initial value: 2.0, range: 0.1~99.9
	7Digital filtering level	AD digital filtering parameters: 7 : No filter. 9 : Strongest filtering. Initial value: 7 , range: 0~9
	8 Secondary filter switch	ON/OFF. The second filter will proceed on the basis of digital filter. Initial value:ON.
	9.A/D sampling rate	Option : 120 Times/sec, 240 Times/sec, 480 Times/sec, 960 Times/sec. Initial value: 480 Times/sec.

Ad- vanced param- eter	1.Auto-zero in- tervals	To proceed zeroing after packing Initial value: 0 , range: 0~99 . This parameter is only effective metering hopper packag- ing mode.
	2. Value mode	Stable and value: Turn off Fine Flow until stable, value process completed. Value delay: Turn off Fine Flow and move on value hold time to complete value process. Initial value: stable and value.
	3. Valued weight hold	ON/OFF. If set ON, weight value hold on after valuing. It will display actual weight value when discharge weight lower than zero zone value.
	4.Manual dis- charge acum- ulated	ON/OFF. If set ON, manual discharge weight value will be included in accumulated value. Initial value: OFF.
	5.Manual dis- charge to judge bag locked/ bag unlocked switch	In with hopper mode stop status, it will allow discharge after bag locked during manual discharge process. Initial value: OFF.
	6.Discharge real time detection switch	If set to OFF, the controller not need to detect the dis- charge signal, detected once when start feeding in each run time. Once the limit signal is detected, it does not need to re-signal the detection limit. If set ON, real-time detection of motor to check whether is in discharge limit. If not, mask output and alarm, until the detection limit feed was restored.
	7.Without hopper package mode	Gross/Net mode. Clear tare weight firstly and enter value package process with net weight value.
	8.Dynamic filter switch	Whether enter filter opearation in packaging process. Pa- rameters are valid when set ON.
	9.Feed filter grade	Feed filter parameters in feeding process: 9 : Strongest filter. Initial value: 4 , range: 0~9 .
	10. Value filter grade	Filter parameters in value process: 9 : Strongest filter. Ini- tial value: 7 , range: 0~9 .
	11. Discharge filter grade	Filter parameters in discharge process: 9 : Strongest filter. Initial value: 3 , range: 0~9 .

Scale structure parameter	1. Scale structure	With hopper mode/Without hopper mode. Initial value: with hopper mode.
	2. Operating mode	With hopper: AB scales, solo scale A, solo scale B. Without hopper: solo AB, AB combination. Initial value: with hopper AB scale.
	3. AB target setting	ON: A, B solo target setting; OFF: common target. Initial value: OFF
	4. Feeding mode	Solo feeding/Combination feeding. Initial value: combination feeding. Combination mode: Coarse /medium/Fine Flow at same time, when Medium Flow, Medium/Fine Flow at same time, Fine Flow. Solo mode: Coarse Flow/Medium Flow/Fine Flow
	5. Without hopper dual scales bag unlocked mode	In without hopper combination mode, bag unlock mode can select: OFF, bag unlock synchronously normal mode, bag unlock synchronously quick mode. Initial value: OFF.
	6. The maximum capacity of single hopper	Valid in with hopper mode.

4.3 Peripheral Parameter

In peripheral parameters interface:

- ◆ 【◀】 【▶】 to change peripheral parameters.
- ◆ 【▲】 【▼】 to change the corresponding subkey handover parameter item.
- ◆ Press 【Enter】 to modify item parameters.
- ◆ Press 【Esc】 to exit the parameter interface peripherals.

Peripheral Item	Parameter	Description
Pat bag parameter	Pat bag parameters setting.	
	1 Pat bag mode	Initial value: Not pat bag. With hopper mode option: not pat bag, pat bag after valuing. Without hopper mode option: not pat bag, pat bag after valuing, pat bag in feeding, pat bag in valuing and feeding.
	2 Pat bag initial weight	Start to pat bag once value reach initial weight. Initial value: 0, range: 0~full capacity.
	3. Pat times in feeding	Pat times setting in feeding. Initial value: 0, range: 0 ~ 99s.

	4.Pat bags after valuing	Pat bag times setting after valuing. Initial value: 4, range: 0 ~ 99s.
	5.Pat bag before delay	When start to pat bag, output is valid after this delay time.. Initial value: 0.5, range: 0.0 to 99.9s.
	6.Pat bag effective time	Pat bag effective time through a cycle. Initial value: 0.5, range: 0.0 to 99.9 s.
	7.Pat bag ineffective time	Pat bag ineffective time through a cycle. Initial value: 0.5, range: 0.0 to 99.9 s.
	8.Extra pat bag effective time	Only applied in without hopper mode. One extra ON timer will be added when patting completed. Initial value: 0. Range: 0.0~99.9s. (Note: After patting bag, bag unlocked delay timer should be longer than extra ON timer to ensure bag unlocked after patting bag.)
Coding parameters	1.Coding switch	ON/OFF. Controller has coding output function if set ON. Initial value: OFF.
	2.Coding start-up delay	Bag locked completed, coding output is valid after this delay. Initial value: 0.5 , range: 0.0 ~ 99.9s .
	3.Coding output timer	Coding output effective time. Initial value: 0.5 , range: 0.0 ~ 99.9s .
	4.Allow feed/dischARGE in coding	ON/OFF. Not allow to feeding output (without hopper mode) or discharging output (with hopper mode) in coding process. Initial value: OFF.
Conveyor parameters	1.Conveyor switch	ON/OFF. With conveyor output function if set ON. Initial value: OFF. Valid in without hopper mode.
	2.Conveyor start-up delay	In without hopper mode, Conveyor start completed after this delay timer. Initial value: 0.5 , range: 0~99.9s .
	3.Conveyor run time	In without hopper mode, conveyor running time setting. Initial value: 4.0 , range: 0 - 99.9s .
	4.Scale B start feeding delay	In without hopper mode, scale B feeding delay again. Only valid for scale B, which in order to prevent the immediate feeding of the bag after bag locked and causing the bag below to withstand the feeding bag. Initial value: 2.0 , range: 0 - 99.9s .
Print parameters	1Auto-print switch	ON/OFF. Auto-print package result when bagging completed if set ON. (Serial port select Print, initial value:

ters		OFF)
	2Print Format	Initial value: 24 lines. Option: 24 lines/32 lines.
	3Print language	Initial value: English, option: Chinese/English
	4Print lines	Print lines after printing completed. Initial value: 3. Option: 0~9.
Dis-charge patting	1.Discharge patting On/Off	Initial Value:0; Range 0~1。 (0: on; 1: off)
	2.Discharge value time	When the holding time of fixed value reaches, the effective unloading time is the period from the start of output unloading signal to the start of unloading delay after the unloading is completed.If the unloading time exceeds this time, it is considered abnormal and the unloading vibration is started. Initial value: 2.0;The range of 0.0 ~ 9.9.(unit s)
	3. Discharge patting value time	Initial Value:0.5; Range 0.0~9.9。 (Unit:s)
	4. Discharge patting inval-ue time	Initial Value:0.5; Range 0.0~9.9。 (Unit:s)
	5. Discharge patting times	Initial Value:10; Range 0~99。
Sewing machine	1. Sewing start delay	After the start switch of the sewing machine is effective, start the delay time of the sewing machine. Initial value: 0.5. Range: 0.0~99.9。 (Unit: s)
	2. Sewing machine out-put time	After the delay time arrives, start the sewing machine output and continue to output the sewing machine output time. Initial value: 4.0.Range: 0.0~99.9.(unit s)
	3. Cutting machine start delay	After the output time of the sewing machine is finished, the startup delay of the machine will be continued. Initial value: 0.5.Range: 0.0~99.9.(unit s)
	4.Cutting machine out-put timer	After the output time of the sewing machine ends, start the output of the machine and continue the output time of the machine. Initial value: 0.5.Range: 0.0~99.9.(unit s)
	5. Sewing	After the work of the cutting machine is completed, the sew-

	machine stop delay	ing machine will continue to work, and stop when the delay time of the machine stops. Initial value: 0.5.Range: 0.0~99.9.(unit s)
--	--------------------	--

4.4Motor Parameter

Motor parameters interface:

- ◆ 【◀】 【▶】 Change motor parameters.
- ◆ 【▲】 【▼】 Change corresponding subkey handover parameter item.
- ◆ Press 【Enter】 to modify item parameter setting.
- ◆ Press 【Esc】 to exit the peripherals parameter interface.

Motor parameter	Parameter	Description
Motor parameters		
	1Current recipe number	Present recipes. Default value: 1, range: 1~40.
	2Motor ID no. of recipe	Feeding motor ID no. of current recipe. Default value: 0, range 0~4.
Feeding parameters	1.Feeding mode	0: Pneumatics mode, 1: Stepper motor mode, 2: Normal motor mode
	2.Feeding gate closed overtime	Default value: 4.0, range: 0.0~99.9.
	3. Feeding gate closed ready signal type.	0: Positive logic (If input is valid, gate closed ready). 1: Anti-logic (If input is invalid, gate closed ready).
	4.Feeding motor ID no.	Default value: 0, range: 0~4. Feed motor ID no. setting.
	5.Scale A feeding motor frequency	Default value: 12000, range: 1~50000.
	6.Scale A Fine Flow pulse quantity	Default value: 1800, range: 1 ~ 60000.
	7.Scale A	Default value: 4300, range: 1 ~ 60000.

	Medium Flow pulse quantity	
	8.Scale A Coarse Flow pulse quantity	Default value: 7750, range: 1~60000.
	9.Scale A opening gate rotation direction signal state	Scale A opening gate rotation direction signal state. 0: When Scale A gate opened, the stepping motor rotation direction output signal is invalid. When Scale A gate closed, signal output is valid. 1: When Scale A gate opened, the stepping motor rotation direction output signal is valid. When Scale A gate closed, signal output is invalid.
	10.Scale B feeding motor frequency	Default: 12000, range:1 ~50000
	11.Scale B closed to Fine Flow pulse quantity needed	Default: 1800, range:1 ~ 60000
	12. Scale B closed to Medium Flow pulse quantity needed	Default: 4300, range:1 ~ 60000
	13. Scale B closed to Coarse Flow pulse quantity needed	Default: 7750, range: 1 ~ 60000
	14. Scale B opening gate rotation direction signal state	Scale B opening gate rotation direction signal state. 0: When Scale B gate opened, the stepping motor rotation direction output signal is invalid. When Scale B gate closed, signal output is valid. 1: When Scale B gate opened, the stepping motor rotation direction output signal is valid. When Scale B gate closed, signal output is invalid.
	15.Scale A	Default: 2000

	feeding motor start frequency	(This value is not more than Scale A feeding motor frequency)
	16.Scale A feeding motor acceleration time	Scale A feeding motor acceleration time (unit: ms) Default: 100ms, range: 0 ~ 9999.
	17.Scale A feeding motor deceleration time	Scale A feeding motor deceleration time (unit: ms) Default: 50ms, range: 0 ~ 9999
	18.Scale B feeding motor start frequency	Scale B feeding motor start frequency (This value is not more than Scale B feeding motor frequency.)
	19.Scale B feeding motor acceleration time	Scale B feeding motor acceleration time (unit: ms) Default: 100ms, range: 0~ 9999
	20.Scale B feeding motor deceleration time	Scale B feeding motor deceleration time (unit: ms) Default: 50ms, range: 0 ~ 9999
	21.Scale A Coarse Flow gate opened time	Time required when scale A gate opened to Coarse Flow. Default: 0.8, range: 0 ~ 99.99
	22.Scale A Medium Flow gate opened time	Time required when scale A gate opened to Medium Flow. Default: 0.4, range: 0 ~ 99.99
	23. Scale A Fine Flow gate opened time	Time required when scale A gate opened to Fine Flow. Default: 0.2, range: 0 ~ 99.99
	24. Scale B Coarse Flow	Time required when scale B gate opened to Coarse Flow. Default: 0.8, range: 0 ~ 99.99

	gate opened time	
	25. Scale B Medium Flow gate opened time	Time required when scale B gate opened to Medium Flow. Default: 0.4, range: 0 ~ 99.99
	26. Scale B Fine Flow gate opened time	Time required when scale B gate opened to Fine Flow. Default: 0.2, range: 0 ~ 99.99
Bag locked/unlocked parameters	1. Bag locked mode	0, pneumatic bag locked/unlocked; 1, stepping motor bag locked/unlocked; 2, double restrict motor bag locked/unlocked; 3, single restrict motor bag locked/unlocked. Default: 0, pneumatic bag locked/unlocked.
	2, Bag unlocked process over time	Default: 3.0, range: 0.0 ~ 99.9s
	3, Bag locked process over time	Default: 3.0, range: 0.0 ~ 99.9s
	4, Bag locked position signal type	0: positive logic (If input is valid, gate closed ready.) 1: anti logic (If input is invalid, gate closed ready.)
	5, Scale A bag locked frequency	Default: 30000, range: 1 ~ 50000
	6, Scale A bag unlocked frequency	Default: 20000, range: 1 ~ 50000
	7, Scale A bag locked pulse quantity required	Default: 12000, range: 1~ 60000
	8, Scale A bag locked direc-	0: When bag locked, stepping motor rotation direction signal output is invalid, but it is valid when bag unlocked.

	tion signal	1: When bag locked, stepping motor rotation direction signal output is valid, but it is invalid when bag unlocked.
	9, Scale B bag lock frequency	Default: 30000, range: 1 to 50000
	10, Scale B bag unlocked frequency	Default: 20000, range: 1 to 50000
	11, Scale B bag locked pulse quantity needed.	Default: 12000, range: 1 to 60000
	12, Scale B bag locked direction signal	0: When bag locked, stepping motor rotation direction signal output is invalid, but it is valid when bag unlocked. 1: When bag locked, stepping motor rotation direction signal output is valid, but it is invalid when bag unlocked.
	13, Scale A bag locked motor start frequency	Default: 2000. (This value is not more than scale A bag locked frequency.)
	14, Scale A bag locked acceleration time	Default: 200ms, range: 0.0 ~ 99.99ms
	15, Scale A bag locked deceleration time	Default: 50ms, range: 0.0 ~ 99.99ms
	16, Scale B bag locked motor start frequency	Default: 2000. (This value is not more than scale A bag locked frequency.)
	17, Scale B bag locked acceleration	Default: 200ms, range: 0.0 ~ 99.99ms

	18, Scale B bag locked deceleration time	Default: 50ms, range: 0.0 ~ 99.99ms
	19, Bag unlocked open gate effective time	Normal motors bag unlocked effective time Default: 0.2s, range: 0 ~ 99.99s
Dis-charge parameters	1, Discharge mode	0, pneumatic mode; 1, stepping motor discharge; 2, single-limit discharge motor 3, double-limit discharge motor; 4, one-way rotation motor discharge Default: 0, pneumatic mode
	2, Discharge gate closed over time	Default: 3.0, range: 0.0 ~ 99.9s
	3, Discharge gate open over time	Default: 3.0, range: 0.0 ~ 99.9s
	4, Discharge ready signal type	0, positive logic (If input signal is active, gate closed OK). 1, anti-logic (If input signal is invalid, gate closed OK).
	5, Scale A discharge gate opened motor frequency	Default: 30000, range: 1 ~ 50000
	6, Scale A discharge gate closed motor frequency	Default: 20000, range: 1 ~ 50000
	7, Scale A pulse quantity needed in discharge	Default: 12000, range: 1 ~ 60000
	8, Scale A discharge	The motor direction signal state of discharge motor from closing to opening.

	direction signal	0: The output signal of discharge stepping motor rotating is invalid when discharge gate opened. It is valid when closing discharge gate. 1: The output signal of discharge stepping motor rotating is valid when discharge gate opened. It is invalid when closing discharge gate.
	9, Scale B discharge gate open motor frequency	Default: 30000, range: 1 ~ 50000
	10, Scale B discharge gate closed frequency	Default: 20000, range: 1 ~ 50000
	11, Scale B pulse quantity needed in discharge	Default: 12000, range: 1 ~ 60000
	12, Scale B discharge direction signal	The motor direction signal state of discharge motor from closing to opening. 0: The output signal of discharge stepping motor rotating is invalid when discharge gate opened. It is valid when closing discharge gate. 1: The output signal of discharge stepping motor rotating is valid when discharge gate opened. It is invalid when closing discharge gate.
	13, Scale A discharge motor start frequency	Default: 2000. (This value is not more than scale A discharge frequency.)
	14, Scale A discharge motor acceleration time	Default: 200ms, range: 0.0 ~ 99.99ms
	15, Scale A discharge motor decel-	Default: 50ms, range: 0.0 ~ 99.99ms

	eration time	
	16, Scale B discharge motor starting frequency	Default: 2000 (This value is not more than scale B discharge frequency.)
	17, Scale B discharge motor acceleration time	Default: 200ms, range: 0.0 ~ 99.99ms
	18, Scale B discharge motor deceleration time	Default: 50ms, range: 0.0 ~ 99.99ms
	19, Scale A discharge gate opened effective output time	Scale A discharge motor gate opened signal output time Default: 1.00s, range: 0.00 ~ 99.99s
	20, Scale B discharge gate opened effective time	Scale B discharge motor gate opened signal output time Default: 1.00s, range: 0.00 ~ 99.99s

4.5 Calibration

Calibration should be done when a M04 controller is used at the first time, or the preset parameters can't meet the user's demand due to change any part of the weighing/bagging system.

To enter calibration parameter need to input correct password as it is protected by password per International Standard. Calibration password can be set in Password Administration of System Info. (Initial password: 000000.)

In calibration interface:

- ◆ **【◀】 & 【▶】** change calibration parameter.
- ◆ **【▲】&【▼】** change and select the corresponding subkey handover parameter item.
- ◆ Press **【Enter】** modify item parameters setting.
- ◆ Press **【Esc】** exit calibration interface.

Calibra-	Item parameter	Description
----------	----------------	-------------

tion pa- rameter			
Weighing parameters	1.Unit	Initial value: kg . Option: g/kg/t/lb .	
	2. Decimal point	Initial value: 0.00 . Option: 0~0.0000.	
	3 Minimum divi- sion	Initial value: 1 . Option: 1/2/5/10/20/50 .	
	4 Full capacity	Initial value: 100.00 ; full capacity $\leq$ minimum divi- sion*100000	
	5. Filling time	Initial Value: 0.0; Max value 99.9, Min value 0.0; Unit:s	
Scale A empty scale cali- bration	A.Current weight	Display scale A cur- rent weight value	Clear scale A and press 【Enter】 to set current state as zero point.
	A.Current voltage value	Display scale A load cell voltage output value	
Scale A weight calibration	A.Current weight	Display scale A cur- rent weight value	Adding weight on scale A and pressing 【Enter】 to input weight value, calibration completed.
	A.Relative volt- age value	Display scale A load weight voltage output value	
Scale B empty scale cali- bration	B.Current weight	Display scale B cur- rent weight value	Clear scale B and press 【Enter】 to set current state as zero point.
	B.Current voltage value	Display scale B load cell voltage output value	
Scale B weight calibration	B.Current weight	Display scale B cur- rent weight value	Adding weight on scale B and pressing 【Enter】 to input weight value, calibration completed.
	B.Relative volt- age value	Display scale B load weight voltage output value	

A. Mate- rial cali- bration	A.Current weight	Display scale A cur- rent weight value	In this interface, empty the scale A (weighing bucket) and press [1] to calibrate the current state to zero.
	A.Relative volt- age value	Display scale A load weight voltage output value	

B. Material calibration	B.Current weight	Display scale B current weight value	Press [2] to feed, press [3] to unload, press [Enter] to input the weight of the discharged material, and then complete the weight calibration of the controller.
	B.Current voltage value	Display scale B load cell voltage output value	

Material calibration process:

Material calibration function is to use calibration method when it is inconvenient to use weight calibration on site. The steps are as follows:

Step 1: empty the hopper and click "1". This step is to calibrate the zero point, requirements: metering bucket empty, weighing body stable.

Step 2: click "2". When the feeding door is opened, some materials will be added to the metering bucket. Click "2" again, and the feeding door will be closed. (note: if the "feeding time" setting in the weighing parameter is not 0, the feeding door will be automatically closed after waiting for the manual feeding time.)

Step 3: click "3". When the discharge door is opened, the current relative millivolts are recorded in the background. The discharged material is reprocessed by electronic weighing and recorded.

Step 4: click "M" to enter the weighing data and click ok. Material calibration ends.

4.6 Cumulative and batch

User can check the recipe accumulate value, accumulate times, clear accumulate zeroing, printing etc. under cumulative and batch.

- ◆ 【◀】 & 【▶】 Check recipe information, user total and batch of recipe No.1-No.10, No.11-No.20, No.21-No.30 and No.31-No.40.
- ◆ 【▲】 & 【▼】 Change recipe no. and press 【Enter】 to confirm.
- ◆ In recipe total interface, press 【Zero1】 can delete selected recipe total.
- ◆ In recipe total interface, press 【Zero2】 can delete all recipes total
- ◆ In user total interface, press 【Zero1】 can delete selected user total.
- ◆ In user total interface, press 【Zero2】 can delete all user totals.
- ◆ If one serial port sets as Print, below keys can enter according function. digit 1-Print total, digit 2-Print selected recipe total, digit 3-Print all recipes total, digit 4-Print selected user total, digit 5-Print all user totals. If there is not serial port set as Print, the digit function is invalid.
- ◆ In Batch interface, pressing 【Enter】 can start to set batch. If batch completed, the controller will display batch completed, alarm and stop. At the same time, user can press Enter, and then the controller will clear alarm and return to stop status.

Note: When operating in combined mode, the target batch counter will add 1 once com-

pleted. The set batch and accumulated can save before power down.

4.7 I/O Module

M04-D has equipped with 12 input ports and 16 output ports if with expansion board to connect with other devices.

The initialization definition of I/O as following, Output ports 1-17 matches with OUT1~OUT12 and PWM1~PWM5. Input ports 1-12 matches with IN1~IN12.

With hopper mode:

Output		Input	
OUT1	Run	IN1	Start up
OUT2	Stop	IN2	Emergency stop
OUT3	Scale A Coarse Flow	IN3	Scale A zero
OUT4	Scale A Medium Flow	IN4	Scale B zero
OUT5	Scale A Fine Flow	IN5	Scale A manual discharge
OUT6	Scale B Coarse Flow	IN6	Scale B manual discharge
OUT7	Scale B Medium Flow	IN7	Bag locked/unlocked request
OUT8	Scale B Fine Flow	IN8	Clear alarm
OUT9	Scale A value	IN9	Scale A manual Fine Flow
OUT10	Scale B value	IN10	Scale B manual Fine Flow
OUT11	Scale A discharge	IN11	Select recipes
OUT12	Scale B discharge	IN12	Slow stop
OUT13	Bag locked		
OUT14	Pat bag		
OUT15	Alarm		
OUT16	Over/Under		
OUT17	Coding/Scale A coding		

Without hopper mode:

Output	Input
--------	-------

OUT1	Run	IN1	Start up
OUT2	Stop	IN2	Emergency stop
OUT3	Scale A Coarse Flow	IN3	Slow stop
OUT4	Scale A Medium Flow	IN4	Scale A zero
OUT5	Scale A Fine Flow	IN5	Scale B zero
OUT6	Scale B Coarse Flow	IN6	Scale A bag locked/unlocked request
OUT7	Scale B Medium Flow	IN7	Scale B bag locked/unlocked request
OUT8	Scale B Fine Flow	IN8	Scale A manual feed (level)
OUT9	Scale A value	IN9	Scale B Manual feed B (level)
OUT10	Scale B value	IN10	Scale A manual Fine Flow
OUT11	Scale A bag locked	IN11	Scale B manual Fine Flow
OUT12	Scale B bag locked	IN12	Clear Alarm
OUT13	Scale A pat bag		
OUT14	Scale B pat bag		
OUT15	Alarm		
OUT16	Over/Under		
OUT17	Coding/Scale A coding		

4.7.1 Output port & input port definition

The output port and the input port can be defined according to the application content. In I/O interface:

- ◆ 【◀】 & 【▶】 to change output port, input port and IO test interface.
- ◆ 【▲】 & 【▼】 to change selected parameter input ports or output ports.
- ◆ Press 【Enter】 to turn into.
- ◆ 【◀】 & 【▶】 flip page on the definition (total four pages).
- ◆ 【▲】 & 【▼】 to select the desired definition content.
- ◆ Press 【Enter】 to confirm and exit the definition page.
- ◆ Press 【Esc】 to exit.

I/O module description

Output		
Code	Content	Explanation
O0	Undefined	Undefined if output port is O0.
O1	Run	The output signal is defined valid in run status.
O2	Stop	The output signal is defined valid in stop status.
O3	Scale A Coarse Flow	To control large discharge opening of scale A feeding system. If present weight value<target value –scale A Coarse Flow leading quantity in feeding process, output signal is effective.
O4	Scale A Medium Flow	To control medium discharge opening of scale A feeding system. If present weight value<target value –scale A Medium Flow leading quantity in feeding process, output signal is effective.
O5	Scale A Fine Flow	To control slow discharge opening of scale A feeding system. If present weight value<target value –scale A Fine Flow leading quantity in feeding process, output signal is effective.
O6	Scale B Coarse Flow	To control large discharge opening of scale B feeding system. If present weight value<target value –scale B Coarse Flow leading quantity in feeding process, output signal is effective.
O7	Scale B Medium Flow	To control medium discharge opening of scale B feeding system. If present weight value<target value –scale B Medium Flow leading quantity in feeding process, output signal is effective.
O8	Scale B Fine Flow	To control slow discharge opening of scale B feeding system. If present weight value<target value –scale B Fine Flow leading quantity in feeding process, output signal is effective.
O9	Scale A bag locked	To control bag locked. Effective signal: bag locked. Ineffective signal: bag unlocked.
O10	Scale A value	Used to indicate scale A feeding completed. During Fine Flow complete and material discharge (with hopper mode) or before pat bag (without hopper), output signal is effective.
O11	Scale A discharge	To control hopper discharge gate. Output signal is effective when start discharging material from hopper A to bag.
O12	Scale B bag locked	To control bag locked system. Effective signal: bag locked. Ineffective signal: bag unlocked. Only effective in without hopper mode.

O13	Scale B value	Used to indicate scale B feeding completed. During Fine Flow complete and material discharge (with hopper mode) or before pat bag (without hopper), output signal is effective.
O14	Scale B discharge	To control hopper discharge gate. Output signal is effective when start discharging material from hopper B to bag.
O15	Scale A pat bag	Used to control pat bag machine. The pulse width and times are controllable.
O16	Scale B pat bag	Used to control pat bag machine. The pulse width and times are controllable. (Only for without hopper mode.)
O17	Scale A cut material	Output is effective only during scale A feeding period.
O18	Scale B cut material	Output is effective only during scale B feeding period.
O19	Feeding	To control the feeding system. When the low material level input defined invalid, the output is effective. When the upper material level defined valid, the output is ineffective.
O20	Lack of material	When the low material level input defined invalid, the output is effective. When the upper material level defined valid, the output is ineffective.
O21	Scale A zero zone	Output port defined effective if scale A current weight is smaller than near-zero value.
O22	Scale B zero zone	Output port defined effective if scale B current weight is smaller than near-zero value.
O23	Alarm	Output port defined effective if Over/Under or batch times are over.
O24	Batch completed	Output port defined effective if batch completed.
O25	Over	Signal is effective when over.
O26	Under	Signal is effective when under.
O27	Over/Under	Signal is effective when over or under.
O28	Conveyor output	To control conveyor starts and stop in without hopper mode. Effective signal: start. Ineffective signal: stop.
O29	Coding/Scale A coding	Output this signal when coding delay over and bag locked output is effective.
O30	Scale B coding	Output this signal when coding delay over and bag locked output is effective. Only for without hopper mode.

O31	Scale A feeding pulse output	When the feeding mode is set to a stepping motor controlled feed gate switch, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT13~OUT17.
O32	Scale A feeding direction	When the feeding mode is set to a stepping motor controlled feed gate switch, the output signal is a direction signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT12.
O33	Scale B feeding pulse output	When the feeding mode is set to a stepping motor controlled feed gate switch, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT13~OUT17.
O34	Scale B feeding direction	When the feeding mode is set to a stepping motor controlled feed gate switch, the output signal is a direction signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT12.
O35	Scale A bag lock/unlock pulse output	When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT13~OUT17.
O36	Scale A bag lock/unlock direction signal	When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a direction signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT12.
O37	Scale B bag lock/unlock pulse output	When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT13~OUT17. (Only for without hopper mode)

O38	Scale B bag lock/unlock direction signal	When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a direction signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT12. (Only for without hopper mode)
O39	Scale A discharge pulse output	When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT13~OUT17.
O40	Scale A discharge direction signal	When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT12.
O41	Scale B discharge pulse output	When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT13~OUT17.
O42	Scale B discharge direction signal	When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT12.
O43	Scale A feeding gate open	When the feeding mode is set normal feeding motor controlled the discharge gate, used to control large discharge gate opening of scale A. This signal is valid in feeding process and the valid time can be set in the motor parameters.
O44	Scale B feeding gate open	When the feeding mode is set normal feeding motor controlled the discharge gate, it used to control large discharge gate opening of scale B. This signal is valid in feeding process and the valid time can be set in the motor parameters.
O45	Scale A feeding gate closed	When the feeding mode is set normal feeding motor controlled the discharge gate used to control large discharge gate opening of scale A. This signal is valid in the end of Coarse/Medium/Fine Flow until feeding limit is effective and

		the valid time can be set in the motor parameters.
O46	Scale B feeding gate closed	When the feeding mode is set normal feeding motor controlled the discharge gate used to control large discharge gate opening of scale B. This signal is valid in the end of Coarse /medium/Fine Flow until feeding limit is effective and the valid time can be set in the motor parameters.
O47	Scale A bag unlock	When bag locked mode is set normal motor control bag locked/unlocked. Effective signal: bag unlocked. Ineffective signal: bag locked.
O48	Scale B bag unlock	When bag locked mode is set normal motor control bag locked/unlocked. Effective signal: bag unlocked. Ineffective signal: bag locked.
O49	Scale A discharge gate closed	When the discharge mode is set to discharge with a common motor reversing controlling so as to control scale A discharge gate closing. Effective signal: discharge gate closed after discharging. Ineffective signal: stop closing.
O50	Scale B discharge gate closed	When the discharge mode is set to discharge with a common motor reversing controlling so as to control scale B discharge gate closing. Effective signal: discharge gate closed after discharging. Ineffective signal: stop closing.
O51	Discharge patting A	Discharge patting A output
O52	Discharge patting B	Discharge patting B output
O53	Cutting machine input	When the input of the sewing machine is valid, the output of the sewing machine is valid.
O54	Cutting machine output	After the output time of the sewing machine ends, the output is valid, and the valid time is the output time of the cutting machine.
O55	A Metering bracket upward	A Metering bracket upward output
O56	B Metering bracket upward	B Metering bracket upward output
	Input	
I0	Undefined	Undefined if input port is 00

I1	Start	This signal is valid in running status. (Pulse input signal)
I2	Emergency stop	Return to stop state if signal is valid. (Pulse input signal)
I3	Slow stop	Finish current package and then return to stop status. (Pulse input signal)
I4	Scale A zero	Clear zero of scale A if signal is effective. (Pulse input signal)
I5	Scale B zero	Clear zero of scale B if signal is effective. (Pulse input signal)
I6	Bag locked/unlocked request	To control bag locked/unlocked. Bag locked when first input this signal; bag unlocked if input the signal again.
I7	Scale B bag locked/unlocked request	To control bag locked/unlocked. Scale B bag locked when first input this signal; scale B bag unlocked if input the signal again. Only for without hopper.
I8	Clear accumulated	To clear accumulated weight and times. Accumulated recipes and users total are cleared at the same time.
I9	Scale A manual discharge	Used to manually clear the material in the hopper. Scale A discharge output is valid when input signal is valid, but invalid if again.
I10	Scale B manual discharge	Used to manually clear the material in the hopper. Scale B discharge output is valid when input signal is valid, but invalid if again.
I11	Scale A manual Fine Flow	Scale A slow output is valid when first input this signal, invalid if input again.
I12	Scale B manual Fine Flow	Scale B slow output is valid when first input this signal, invalid if input again.
I13	Scale A manual feeding	Combination feeding mode: Scale A Coarse /Medium/Fine Flow output is valid when first time input the signal. Invalid if input again. Solo feeding mode: Scale A Coarse Flow output is valid when first time input the signal. Invalid if input again.
I14	Scale B manual feeding	Combination feeding mode: Scale B Coarse /Medium /Fine Flow output is valid when first time input the signal. Invalid if input again. Solo feeding mode: Scale B Coarse Flow output is valid when first time input the signal. Invalid if input again.
I15	Select recipes	Only valid once. Recipe changes to next one which target value

		is not zero.
I16	Clear alarm	Clear alarm output. (Pulse input signal)
I17	Upper level	To connect upper level of the hopper. (Level input)
I18	Under level	To connect under level of the hopper. (Level input) Lack materials if invalid. Unlack materials if valid.
I19	Start/Stop (Level)	Enter running status if signal is valid, return to stop status if invalid. This is level signal.
I20	Start/Slow stop (Level)	Enter running status if signal is valid, return to stop status if invalid. This is level signal.
I21	Scale A manual discharge (Level)	Manually clear the materials in the hopper. Scale A discharge output is valid if input is effective.
I22	Scale B manual discharge (Level)	Manually clear the materials in the hopper. Scale B discharge output is valid if input is effective.
I23	Scale A bag locked ready	If the input is defined, valid means ready, invalid means not ready. With hopper mode: If bag locked in the running process, the controller will begin to discharge when bag locked ready. In discharge process, will not check the effectivity of signal. Without hopper mode: If bag locked in the running process, the controller will begin to feed when bag locked ready. In feeding process, will not check the effectivity of signal. This is level input.
I24	Scale B bag locked ready	If input signal is valid, means bag locked ready and invalid means bag locked not ready. Without hopper mode: The controller starts to feed once detect bag locked ready is valid. In feeding process, will not check the effectivity of signal. This is level input.
I25	Scale A discharge gate closed ready	If the signal is valid, means scale A gate closed ready. If discharge real time detection set ON and detect invalid signal, will shield feeding output and alarm, the output controller light will be off. If detect valid signal and have to feed, it will clear alarm automatically and continue to feed. If discharge real time detection set OFF and discharge gate closed not ready, it will alarm. Once detect valid signal, starting to feed.

I26	Scale B discharge gate closed ready	If the signal is valid, means scale B gate closed ready. If discharge real time detection set ON and detect invalid signal, will shield feeding output and alarm, the output controller light will be off. If detect valid signal and have to feed, it will clear alarm automatically and continue to feed. If discharge real time detection set OFF and discharge gate closed not ready, it will alarm. Once detect valid signal, starting to feed.
I27	Scale A manual Fine Flow (level)	Effective signal: Scale A manual Fine Flow output is valid. Ineffective signal: Scale A manual Fine Flow output is invalid.
I28	Scale B manual Fine Flow (level)	Effective signal: Scale B manual Fine Flow output is valid. Ineffective signal: Scale B manual Fine Flow output is invalid.
I29	Scale A manual feed (level)	Combination feeding mode: Scale A Coarse/Medium/Fine Flow output are valid if effective input. Solo feeding mode: Scale A Coarse Flow output is valid if effective input.
I30	Scale B manual feed (level)	Combination feeding mode: Scale B Coarse/Medium/Fine Flow output are valid if effective input. Solo feeding mode: Scale B Coarse Flow output is valid if effective input.
I31	Scale A feed gate closed ready	When stepping motor controls feeding gate switch, it is limit digit input signal for scale A feeding gate closed ready. When normal motor controls feeding gate switch, it is limit digit input signal for scale A feeding gate closed ready. (Note: this signal is determined by the digit signal type. Positive logic: The feeding gate is closed if signal is valid. Negative logic: The feeding gate is closed if signal is invalid.)
I32	Scale B feed gate closed ready	When stepping motor controls feeding gate switch, it is limit digit input signal for scale B feeding gate closed ready. When normal motor controls feeding gate switch, it is limit digit input signal for scale B feeding gate closed ready. (Note: this signal is determined by the digit signal type. Positive logic: The feeding gate is closed if signal is valid. Negative logic: The feeding gate is closed if signal is invalid.)
I33	Scale A bag unlocked ready	It is a limit input signal of bag unlocked ready when stepping motor and motor double limit digit controlling bag locked/unlocked.

		(Note: this signal is determined by the digit signal type. Positive logic: Bag unlocked ready if signal is valid. Negative logic: Bag unlocked ready if signal is invalid.)
I34	Scale B bag unlocked ready	It is a limit input signal of bag unlocked ready when stepping motor and motor double limit digit controlling bag locked/unlocked. (Note: this signal is determined by the digit signal type. Positive logic: Bag unlocked ready if signal is valid. Negative logic: Bag unlocked ready if signal is invalid.)
I35	Scale A discharge gate opened ready	When material discharged is controlled by normal motor reversible double limit, it is a signal of discharge gate opening ready and discharge gate open.
I36	Scale B discharge gate opened ready	When material discharged is controlled by normal motor reversible double limit, it is a signal of discharge gate opening ready and discharge gate open.
I37	Sewing machine start	When the I/O Module input is valid, start the valid output of the sewing machine.
I38	Sewing machine stop	When the I/O Module input is valid, the sewing machine stops the output.
I39	A. Control bracket up/down	When the input of the I/O Module is valid, the valid output of the A bracket will go up.
I40	B. Control bracket up/down	When the input of the I/O Module is valid, the valid output of the B bracket will go up.

4.7.2 I/O Test

User could check output ports, input ports by IO test.

Output port test: In IO test interface, pressing digital button to start test. If the port is lighting, the output will be valid. If invalid, means the connection is abnormal.

Input port test: In IO test interface, if output signal is valid, the input port will turn to green. If no response showed on the interface while the external input is valid, means the connection is abnormal.

I/O Module			
Input Define	Output Define	Input Test	Output Test
IN1 Start	IN2 Emergency Stop	IN3 A:Zeroing	
IN4 Zeroing	IN5 A:Manual Discharge	IN6 B:Manual Discharge	
IN7 Bag Lock/Unlock	IN8 Clear Alarm		
Note:DR Function Only Define To 1-12 Output Port			

I/O Module			
Input define	Output define	Input Test	Output Test
OUT1 1 Running	OUT2 2 Stopped	OUT3 3 A:Coarse Flow	OUT10 <- B:Result Waiting
OUT4 4 A:Medium Flow	OUT5 5 A:Fine Flow	OUT6 6 B:Coarse Flow	OUT11 0 A:Discharge
OUT7 7 B:Medium Flow	OUT8 8 B:Fine Flow	OUT9 9 A:Result Waiting	OUT12 ..? B:Discharge
Note:DR Function Only Define To 1-12 Output Port			

4.8 Serial Port Parameter

M04-D has two serial ports, the definition of input or output port can refer to Chapter 2.5.

In serial port parameter interface:

- ◆ 【◀】 & 【▶】 Change serial port.
- ◆ 【▲】 & 【▼】 Change and select the item parameters
- ◆ Press 【Enter】 to modify item parameters.
- ◆ Press 【Esc】 to exit the serial port parameters interface.

Serial port parameters	Item Parameters	Description
Serial port parameters (Serial port 1, RS485)	1. ID No.	Initial value: 1 . Option: 1~99 .
	2. Communication mode	Initial value: Modbus-RTU . Option: Modbus-RTU/Print/Continuous mode.
	3. Baud rate	Initial value: 38400 . Option: 9600/19200/38400/57600/115200.
Serial port 2,	4. Data format	Initial value: 8-E-1 (8 data bits - even parity -1 stop

RS232/RS485 Optional)		bit). Option: 8-E-1/8-N-1/7-E-1/7-N-1.
	5. Modbus Hi-Lo	Modbus communication mode: Initial value: AB-CD (High word first). Option: AB-CD (High word first) / CD-AB (Low word first).

4.9 User Management

Administrators and system administrators can log in user entry, user editing and set up user login automatically.

In the user management interface,

- ◆ **【◀】** & **【▶】** To check user list, user editing and automatic login information.
- ◆ **【▲】** & **【▼】** To change and select item parameter.
- ◆ Press **【Enter】** to modify item parameters setting.
- ◆ Press **【Esc】** to exit the user management interface.

User Man- agement	Items	Description
User list	User login	Login user: 0-7: Operators, 8: Administrator 9: System administrator (supreme authority)
User editing	1.Current user	Displays the current logged-in user, which can not be modified.
	2.ID	Write user ID which required edited.
	3.Authority	Administrator/Operator
	4.Password switch	ON/OFF. When set OFF, user can log in without password.
	5. Password modi- fication	To set/modify password, user has to input correct password before operation. The password must be six bits.
Auto-login	Auto-login	0-8: User login automatically 9: Previous user login.

4.10 System Information

Administrators and system administrators can view the controller version, password management, data recovery and back up, shortcut key in system information.

Under the system information interface,

- ◆ **【◀】 & 【▶】** To check version, password management and other information.
- ◆ **【▲】 & 【▼】** To change item parameters.
- ◆ Press **【Enter】** to modify item parameters
- ◆ Press **【Esc】** to exit system information interface.

System Information	Items	Description
Password management	1.Recipe parameter password	Option: ON/OFF, user can enter without password if set OFF. To press 【Zero2】 can revise password of according parameter. Initial password: 000000.
	2.Working parameter password	
	3.Peripheral parameters password	
	4.Motor parameter	
	5.Calibration password	
	6.Clear accumulated password	
	7.I/O module setting password	
	8.System information password	
Recovery / Backup	1Reset all parameters	Press [Enter] key to restore all value to the factory settings.
	2.Reset calibration parameter	Press [Enter] key to restore the calibration value to the factory settings.
	3. Reset Operating parameters	Press [Enter] key recovery value to the factory settings.
	4. Reset Recipe parameters	Press [Enter] key recovery formula value to the factory settings.
	5. Reset Peripheral parameters	Press [Enter] key recovery peripherals value to the factory settings.
	6. Reset motor parameters	Press [Enter] Motor Recovery value to the factory settings.
	7. Reset Switch defined	Press [Enter] recovery switch defined value to the factory settings.

	8.Reset Shortcut Keys defined	Press [Enter] key to quick recovery	Key DefinitionsSet the value to the factory.
	9.Execution parameter backup	Backup Press [Enter] key controller will set the value of the parameter.	
	10.Restore the backup data	Press [Enter] key controller to restore the most recent backup parameter value.	
	11.Delete the backup parameters	Press [Enter] key to delete backed-up controller parameters.	
USB dataImport	1All parameters	Import all parameters from USB	
	2.Operating parameters	Import operating parameters from USB	
	3.Recipe parameters	Import recipe parameters from USB	
	4.Peripheral parameters	Import peripheral parameters from USB	
	5.Motor parameters	Import motor parameters from USB	
	6.Calibration parameters	Import calibration parameters from USB	
	7.I/O parameters	Import I/O parameters from the USB	
	8.Serial port parameters	Import serial port parameters from USB	
USB dataExport	1All parameters	Export all parameters from USB	
	2.Operating parameters	Export operating parameters from USB	
	3.Recipe parameters	Export recipe parameters from USB	
	4.Peripheral parameters	Export peripheral parameters from USB	
	5. Motor parameters	Export motor parameters from USB	
	6. Calibration parameters	Export calibration parameters from USB	
	7. I/O parameters	Export I/O parameters from the USB	
Shortcut Setting	1. Shortcut -1	Initial value: operating parameters	Press [Enter] Alternatively defined key functions. use 【◀】 Key and 【▶】Find keys to
	2. Shortcut -2	Initial value: Calibration	
	3. Shortcut -3	Initial value: number	

	of batches	select the page (13 pages)
4. Shortcut -←	Initial value: target	
5. Shortcut -4	Initial value: System Information	
6. Shortcut -5	Initial value: Recipe number	use 【▲】Key and 【▼】Keys to select the function parameter values in the current page
7. Shortcut -6	Initial value: Cumulative review	
8. Shortcut -0	Initial value: User Management	
9. Shortcut -7	Initial value: serial port parameters	
10. Shortcut -8	Initial value: switch	
11. Shortcut -9	Initial value: recipe parameters	
12. Shortcut -.,?	Initial value: Peripheral parameters	

Note: For defined shortcut keys, at shortcut keys interface, press corresponding key controller enter corresponding parameters, for example: shortcut-1 initial default is "operating parameters", in shortcut keys interface, press 1 enter the "working parameters" screen. When the shortcut key 1 defined "Set up", press set up button, controller setted up.

5. Function Description

5.1 Setting the operating mode

1. Operating parameter scale structure is with hopper.

Set the following nine kinds of ways:

1) Operating mode chose dual weigher with hopper

1.1) AB target value set off separately, set target value > single hopper weighing limit, single hopper target value automatically converted.

1.2) AB target value set off separately, set target value $\leq$ single hopper weighing limit, single hopper target value is target value.

1.3) AB target value set on separately, set A/Btarget $\leq$ single hopper weighing limit.

2) Operating mode chose A weigher with hopper

2.1) AB target value set off separately, set target value > single hopper weighing limit, single hopper target value automatically converted.

2.2) AB target value set off separately, set target value $\leq$ single hopper weighing limit, single hopper target value is target value.

2.3) AB target value set on separately, set A target value $\leq$ single hopper weighing limit.

3) Operating mode chose B weigher with hopper

3.1) AB target value set off separately, set target value > single hopper weighing limit, single hopper target value automatically converted.

3.2) AB target value set off separately, set target value $\leq$ single hopper weighing limit, single hopper target value is target value.

3.3) AB target value set on separately, set B target value $\leq$ single hopper weighing limit.

Note: With hopper mode normally choose dual scale operating mode, the rest mode is failure mode.

2. Operating parameter scale structure is without hopper.

Set the following four kinds of ways:

1) Without hopper dual scale operate individually mode: operating mode choose without hopper AB individual, AB target value set off individually, AB both using target value.

2) Without hopper dual scale operate individually mode: operating mode choose without hopper AB individual, AB target value set on individually, AB using A/B target value separately.

3) Without hopper dual scale comb mode: operating mode choose AB Comb without hopper, AB target value set off individually, AB both using target value.

4) Without hopper dual scale comb mode.: operating mode choose AB Comb, AB target value set on individually, AB using A/B target value separately.

Note: Controller default: with hopper AB target value is off.

5.2 Batch

Batch is used for packaging frequency reminder, when automatic operation is completed and set batch is reached, controller show batch reached, alarm and shutdown, waiting for user to process, batch reached and alarm is valid, user can press [Enter] Key or to "clear alarm" input signal is valid, controller clears alarm. The batch number is zero, and then batch number judgment is not operated.

Batch range is 0~9999.initial default value is 0 (No batch judgment) .

5.3 Filling Level Control

Depending on application difference, controller material tank's level gage mounting has two ways: Dual Supplement (Supplement Full, Supplement Empty), Single Supplement (Supplement Empty) and no filling level control.

5.3.1. Dual Supplement

Supplement full and supplement empty are defined, corresponding to the case of dual level. In this situation, controller include feeding control function, which control principle is: when Supplement full and supplement empty input are invalid, controller feeding output is valid, when Supplement full input is valid, feeding output is invalid. Meanwhile, before feeding (coarse flow, medium flow, fine flow) , controller detect supplement empty if is valid, if invalid wait for signal, only this signal is valid then start feeding process. In the feeding procession, controller do not detect supplement empty signal if is valid.

5.3.2. Single Supplement

Supplement empty is defined; supplement full is undefined, corresponding to the case of signal level, controller do not contain feeding control function, detect supplement empty before feeding, waiting for the signal when supplement empty is invalid, only the signal is valid, then start feeding process. controller do not detect supplement empty signal if is valid when feeding.

Supplement empty and supplement full are undefined, corresponding to the no material level editor. Controller do not control feeding, do not detect supplement empty signal if is valid when feeding.

5.4 Quick Setup

In stop mode, quick modify recipe data stored in real time.

Modification of runtime data, a zero value is stored in real-time, other parameters after exiting the quick setup interface, automatic updates are operated (combined mode need to unlock bags, start to run the next scale then target value is updated) when the next scale started.

Finished modifying the recipe parameters when running, but not yet reached the next

scale update, the emergency stop signal is input into the controller, controller in stop mode, recipe update immediately.


Modbus the recipe value and advance value can be modified when communicating.

5.5 Sewing Process

The function of sewing machine involves switch quantity: "sewing machine output", "tangent machine output", "sewing machine start", "sewing machine emergency stop".

1 (sewing machine output time not 0) : sewing machine after start (impulse) signal effectively, sewing machine working process, first of all, the sewing machine start delay, delay time to think after sewing machine started in place, then carries on the sewing machine output, wait until time to sewing machine output, think FengBao end, at the same time start tangent machine startup delay and delay before sewing machine downtime. When the start delay time of the tangent machine is up, the tangent line will start. After the output time of the tangent machine, the tangent line will be considered finished. The delay time of the sewing machine before stopping starts at the same time as the start delay of the cutting machine. When the delay ends, the output of the sewing machine is invalid and the process ends.

2 (0) sewing machine output time: sewing machine after start (level) signals effectively, the sewing machine start first time delay, delay time to detection sewing machine start again after the input signal is valid, invalid sewing machine output signal is not output, effective output sewing machine output signal, waiting for sewing machine input is invalid, then the tangent machine startup delay and delay before sewing machine downtime. When the sewing machine is delayed before stop, the output of the sewing machine is invalid and the sewing bag is over. After the start time of the tangential machine arrives, the tangential work will begin. After the output time of the tangential machine, the tangential work will be considered to be finished and the sewing process will be finished.



5.6 Bracket upward

With on bucket mode, starts the controller, after clip the bag, controller upward signal output is valid, wait until delay timer is finished, starts tare(net weight mode), if patting function is on, upward signal follow patting signal to output(patting output invalid, upward in valid, patting output valid, upward valid), same as result waiting after patting. Bracket upward signal is invalid, bracket goes downward, starts bracket downward delay, when bracket downward delay finished, starts unlock bag.

When the controller is in stop state, bracket upward signal valid, bracket goes upward, when bracket upward signal invalid, bracket goes downward.

5.7 Discharge patting function

Discharge patting function involves the I/O module: "Discharge patting ".

Discharge patting is on, running state, the device starts to discharge start timing, when discharging time more than setting the discharge time effectively, measuring the material weight haven't return to zero, the discharge patting A effective output, the output pulse, effective time for unloading oscillation effectively, invalid time for unloading shaking is invalid).After the unloading vibration number reaches, the current weight of the measuring bucket has not been lower than zero zone, and the meter output discharging timeout alarm will return to the stop state.When the unloading vibration times are not reached or just finished, and the weight of the material in the measuring bucket is less than the value of zero zone, the unloading delay time will start, and the weighing will end after the delay time.

6. Serial port communication

M04-D It provides two serial port, it provides two serial communication interface, and serial port 1 and 2 can be selected in a continuous manner, Modbus mode and printed three functions. controller for the first serial port is RS-232, the second is RS-485.

6.1 Printing method

When serial port parameter port 1 or 2 choose print mode, corresponding to the serial port can be connected to a serial printer to print the contents accumulated by implementation-dependent.

Print mode communication parameters refer to serial port parameters, need to note:

- 1) **Baud Rate**——parameters need to consist with connected printer.
- 2) **Communication format**——parameters need to consist with connected printer.

Note: When printing options for Chinese language, can not use the data bits to 7 formats, otherwise there will be printing error.

- 3) **Print format**——Peripheral parameters can be setted by print format of 24 or 32 formats. Besides by peripherals parameters printing language is Chinese or English.

6.1.1. Auto Print

In printing mode, the parameters of the peripheral automatically print switch is set to open. So after each weighing is completed, controller automatically prints the weighing result of this time, the format as follow:

English 24 print formats are as follows:

Packing list

Unit: kg

Recipe Number: 20

The total cumulative number of results

1	5.50
2	5.50

English 32 print formats are as follows:

Packing list

Unit: kg

Recipe Number: 20

The total cumulative time	target value	result
---------------------------	--------------	--------

3	5.60	5.50
4	6.00	5.80

6.1.2 Total cumulative print (key 1)

In printing mode, stop, press the 6 key, and enter the total batch interface, press the number key 1 to the total cumulative print. Format is as follows:

English 24 print formats are as follows:

The total cumulative report

Time: 2017/12/19 13:28

Unit: kg

The total cumulative number of times: 18

Total cumulative weight: 84.16

English 32 print formats are as follows:

The total cumulative report

Time: 2017/12/19 13:36

Unit: kg

The total cumulative number of times: 24

Total cumulative weight: 129.40

6.1.3 Cumulative print the recipe (key 2/3)

In printing mode, stop, press the 6 key, and enter the total batch interface. Press the number 2 key, selected recipe cumulative print, press $\sim$ or $\curvearrowright$ Key to switch the selected recipe.

Press 3 to print all formulations (1 to 40) is accumulated, the meter will automatically skip the target value 0 is not printed formulations. Format is as follows:

English 24 print formats are as follows:

Recipe cumulative report

Time: 2017/12/19 13:29

Unit: kg

Recipe Number: 20

The cumulative number of recipes: 18

Recipe cumulative weight: 84.16

English 32 print formats are as follows:

Recipe cumulative report

Time: 2017/12/19 13:36

Unit: kg

```
-----  
Recipe Number:                20  
The cumulative number of recipes:    24  
Recipe cumulative weight:          129.40  
-----
```

6.1.4 User cumulative print (4/5 button)

In printing mode, stop, press the 6 key, and enter the total batch interface. press>User interface switch to the total, press the number 4 key, print the selected user has been accumulated in ~ or ~ Key to switch the selected user.

Press button 5, print all users (0-9) is accumulated, the meter will automatically skip the user's cumulative user 0 is not printed. Format is as follows:

English 24 print formats are as follows:

Cumulative User Report

Time: 2017/12/19 13:29

Unit: kg

```
-----  
User Number:                  9  
User cumulative number:       16  
User cumulative weight:       72.26  
-----
```

English 32 print formats are as follows:

Cumulative User Report

Time: 2017/12/19 13:37

Unit: kg

```
-----  
User Number:                  9  
The cumulative number of users:    22  
User cumulative weight:          117.50  
-----
```

6.2 Continuous mode

A continuous manner, the meter sends the meter serial port results in outward selected serial communication port 1 or 2 selected

6.2.1 Continuous mode data frame format is as follows:

STX	Scale	R	T	SP	SP	The cumulative	,	Cumulative	CRC	CR	LF
-----	-------	---	---	----	----	----------------	---	------------	-----	----	----

	request	
--	---------	--

6.3.2 MODBUS transmission mode

The transmission mode is MODBUS RTU mode.

When communication with the RTU mode, information of each 8-bit byte is divided into two 4-bit transmission character hexadecimal.

Data Format: **8**Data bits,**1**Stop bit, even parity (**8-E-1**)

8Data bits,**1**Stop bits, no parity (**8-N-1**)

Baud rate:**9600/19200/38400/57600/115200**(Choose one)

Code: RTU

6.3.3 MODBUS address assignment

Protocol address	PLC address	Meaning	Description	
Read only register				
0000	40001	Scale A present weight	Digit	Description
0001	40002			
0002	40003	Scale A present weight state	.0	Unstable weight: 0. Stable: 1.
			.1	Non-zero:0. Zero: 1.
			.2	Symbol of present weight: +/- Positive: 0. Negative: 1.
			.3	Overflow
			.4	Positive overflow
			.5	Negative overflow
			.6	Load cell positive overflow
			.7	Load cell negative overflow
0003	40004		.8	Stable millivolt: 1. Unstable: 0.
			.9 ~ 31	Reserve
0004	40005	Scale B present weight	Referring to Scale A present weight state	
0005	40006			
0006	40007	Scale B present weight state	.0	Unstable weight: 0. Stable: 1.
			.1	Non-zero:0. Zero: 1.
			.2	Symbol of present weight: +/- Positive: 0. Negative: 1.
			.3	Overflow

			.4	Positive overflow
			.5	Negative overflow
			.6	Load cell positive overflow
			.7	Load cell negative overflow
0007	40008		.8	Stable millivolt: 1. Unstable: 0.
			.9 ~ 31	Reserve
0008	40009	Scale A & Scale B control state	.0	0: Stop. 1: Run.
			.1	Alarm
			.2	Batch completed
			.3	Bag locked
			.4	Upper level
			.5	Under Level
			.6	Feeding material
			.7	Lack material
			.8	Pat bag
0009	40010		.9	Conveyor output (without hopper)
			.10	Coding output
			.11	Sewing machine output
			.12	Cutting machine output
			.13	A bracket upward
			.14	B bracket upward
			.15 ~31	Reserve
0010	40011	Scale A control state	.0	Before scale A feeding
			.1	Scale A Coarse Flow
			.2	Scale A Medium Flow
			.3	Scale A Fine Flow
			.4	Scale A value
			.5	Scale A discharge
			.6	Scale A zero zone
			.7	Scale A overlimit
			.8	Scale A underlimit
			.9	Scale A qualified
			.10	Scale A over/under pause
			.11	Scale A bag locked (without hopper)
0011			.12	Scale A pat bag

	40012		.13	Scale A coding output
			.14	Gross weight: 0. Net weight: 1.
			.15	A Discharge patting
			.16~31	Reserve
0012	40013	Scale B control state	Referring to Scale A control state	
0013	40014			
0014	40015	Total accumulated weight	0~999999999	
0015	40016			
0016	40017	Total accumulated bags	0~999999999	
0017	40018			
0018	40019	The current recipe cumulative weight	0~999999999	
0019	40020			
0020	40021	The current recipe cumulative bags	0~999999999	
0021	40022			
0022	40023	User accumulated weight	0~999999999	
0023	40024			
0024	40025	User cumulative bags	0~999999999	
0025	40026			
0026	40027	Scale A previous weight value		
0027	40028			
0028	40029	Scale B previous weight value		
0029	40030			
0030	40031	Scale A alarm information	0. No alarm 1. Unable to start for unreasonable recipe setting. 2. Unable to start as the maximum capacity of the hopper is 0. 3. Weight value exceeds zero range when zeroing; 4. Weighing value is unstable when zeroing. 5. Over/Under alarm. 6. The target value of single scale can not be set as 0 or the full capacity is too large. 7. The target value is bigger than maximum capacity value. 8. Weight value or load cell is overlimit when start. 9. Discharge gate is sepearated from limit digit. 10. Not bag locked. 11. Zeroing in the process of running. 12. Zeroing over range in the process of running.	
0031	40032	Scale B alarm information		

			13. Zeroing is not unstable in the process of running. 14. The motor parameters is unreasonable (normal motor) 15. Reserved
0032-0033	40033-40034	Normal alarm information (Need to be manually cleared)	0- No alarm; 1- Batch completed; 2- Scale A Over/Under pause 3- Scale B Over/Under pause 4- Motor feeding gate of scale A closed over time alarm 5- Motor feeding gate of scale B closed over time alarm 6- Scale A bag locked over time alarm 7- Scale B bag locked over time alarm 8- Scale A bag unlocked over time alarm 9- Scale B bag unlocked over time alarm 10- Scale A discharge gate closed over time alarm 11- Scale B discharge gate closed over time alarm 12- Scale A discharge gate opened over time alarm 13- Scale B discharge gate opened over time alarm 14- Scale A feed gate not closed in place alarm. 15- Scale B feed gate not closed in place alarm. 16- Scale A discharge gate not closed in place alarm. 17- Scale B discharge gate not closed in place alarm. 18- The communication is abnormal of main board and addition board. 19- A discharge patting overtime alarm 20- B discharge patting overtime alarm
0034	40035	Scale A & Scale B calibration alarm	0- No alarm 1- Maximum range is too small 2- Maximum range is too large 3- Zero voltage is too high 4- Zero voltage is too low 5- Unstable zero point 6- Gain voltage is too large 7- Gain voltage is too small 8- Scale platform is unstable 9- Weight value input is error 10- Resolution is low after calibration. 11-12:Reserved
0035 ~ 0049	40036-40050	Reserved	
Allow to read & write register			
Calibration parameter			
0050	40051	Unit	Initial value: 1.

			0-g, 1-kg, 2-t, 3-lb	
0051	40052	Decimal point	Initial value: 2 0-0 bit, 1-1 bit, 2-2 bits, 3-3 bits, 4-4 bits.	
0052	40053	Division	Initial value: 1, (1/2/5/10/20/50)	
0053	40054	Maximum range	Initial value: 10000. The write range (maximum range value ≤ minimum division*100000, not more than 999999.)	
0054	40055			
0055	40056	Scale A calibration with weights	Zero calibration with weights	If write in 1, the present weight will be set as zero point, which is allow to write in when weigher platform is stable. Return to present zero voltage when read.
0056	40057			
0057	40058		Gain calibration with weights	Input standard weight value(≤ maximum range); Read relative zero millivolt of present load cell.
0058	40059			
0059	40060	Scale A calibration without weights	Zero calibration without weights	Write millivolt value which is calibrated as zero. Return to present zero millivolt when reads.
0060	40061			
0061	40062		Gain calibration with weights (gain millivolt value)	Write in millivolts of gain weight and save it. Returns to absolute millivolt of present weight when reads. (If present millivolt is too small or too large can not be calibrated then returns 0XFFFF.).
0062	40063			
0063	40064		Gain calibration without weights(gain weight value)	Write in weight value of gain millivolt, user must write in gain millivolt before write in this value. Return to 0000H when reads.
0064	40065			
0065	40066	Scale B calibration with weights		Referring to Scale A zero calibration with weights.
0066	40067			
0067	40068			Referring to Scale A gain calibration with weights
0068	40069			
0069	40070	Scale B calibration without weights		Referring to Scale A zero cali-

0070	40071		bration without weights
0071	40072		Referring to Scale A gain calibration without weights (gain millivolt value)
0072	40073		
0073	40074		Referring to Scale A gain calibration without weights (gain weight value)
0074	40075		
0075	40076	Filling time	Initial value:0.0s
0076	40077		Range:0~99.9s
0077	40078	Material Calibration A	Write the weight value corresponding to the gain millivolts;Press "manual discharge A" to record the current relative millivolt, and use the two to calibrate the gain when writing this register; Return 0000H on read.
0078	40079		
0079	40080	Material Calibration B	Write the weight value corresponding to the gain millivolts;Press "manual discharge B" to record the current relative millivolt, and use the two to calibrate the gain when writing this register; Return 0000H on read.
0080	40081		
0081-0099	40082-40100		Reserved
Other parameters			
0100	40101	Recipe No.	Initial value: 1, range:1-40
0101	40102	Batches	Initial value: 0, range: 0~9999
0102	40103	Accumulative batches	Read-only
0103	40104	Controller locked	0- unlocked; 1- locked
0104	40105	Year	0-99
0105	40106	Month	1-12
0106	40107	Day	1-31
0107	40108	Time	0-23

0108	40109	Minute	0-59
0109	40110	Second	0-59
0110 ~ 0119	Reserved		
Recipe parameters-quantity controlling			
0120	40121	Total target value	Weight value writing range: ≤ Maximum range
0121	40122		
0122	40123	Scale scale A target	With hopper: Weight value writing range: ≤ The maximum capacity of single hopper Without hopper: Weight value writing range: ≤ The maximum full capacity
0123	40124		
0124	40125	Scale scale B target	
0125	40126		
0126	40127	Scale A Coarse Flow leading quantity	
0127	40128		
0128	40129	Scale A Medium Flow leading quantity	
0129	40130		
0130	40131	Scale A free fall value	
0131	40132		
0132	40133	Scale B Coarse Flow leading quantity	
0133	40134		
0134	40135	Scale B Medium Flow leading quantity	
0135	40136		
0136	40137	Scale B free fall value	
0137	40138		
0138	40139	Zero zone value	
0139	40140		
Recipe parameters-time controlling			
0140	40141	Delay before feeding	Initial value: 0.5s Range: 0.0～99.9s.
0141	40142	Scale A Coarse Flow inhibit comparison timer	Initial value: 0.9s Range: 0.0~99.9s
0142	40143	Scale A Medium Flow inhibit comparison timer	Initial value: 0.9s Range: 0.0~99.9s
0143	40144	Scale A fine feeding inhibit comparison timer	Initial value: 0.9s Range: 0.0~99.9s
0144	40145	Scale B Coarse Flow inhibit comparison timer	Initial value: 0.9s Range: 0.0~99.9s

0145	40146	Scale B Medium Flow inhibit comparison timer	Initial value: 0.9s Range: 0.0~99.9s
0146	40147	Scale B Fine Flow inhibit comparison timer	Initial value: 0.9s Range: 0.0~99.9s
0147	40148	Over/Under detection time	Initial value: 0.5s Range: 0.0~99.9s.
0148	40149	Value holding time	Initial value: 0.5s Range: 0.0~99.9s.
0149	40150	Discharge delay time	Initial value: 0.5s Range: 0.0~99.9s.
0150	40151	Discharge interlock time	Initial value: 0.5s Range: 0.0~99.9s.
0151	40152	Bag locked delay time	Initial value: 0.5s Range: 0.0~99.9s.
0152	40153	Bag unlocked delay time	Initial value: 0.5s Range: 0.0~99.9s.
0153	40154	Under level effective signal delay time	Initial value: 0.5s Range: 0.0~99.9s.
Recipe parameters-Over/Under detection time controlling			
0154	40155	Over/Under detection switch	
0155	40156	Over/Under pause switch	
0156	40157	Over value Under value	Weight value writing in range ≤ maximum range
0157	40158		
0158	40159		
0159	40160		
0160	40161	Under supplementary switch	Initial value: 0. 1: ON. 0: OFF
0161	40162	Under supplementary times	Range: 1 ~ 99. Initial value: 1
0162	40163	Effective feeding time	Initial value: 0.5s. Range: 0.0~99.9s
0163	40164	Ineffective feeding time	Initial value: 0.5s. Range: 0.0~99.9s
Recipe parameters - free fall correction controlling parameters			
0164	40165	Free fall correction switch	Initial value: 0, 1: ON. 0: OFF
0165	40166	Free fall correction times	Range: 1 ~ 99. Initial value: 1.
0166	40167	Free fall correction range	Range: 2.0, range: 0.0~9.9, unit:%

0167	40168	Free fall correction percentage	Initial value: 1. 0--100% cor- rection; 1--50% correction; 2-25% correction.
0168	40169	A. Unlock Bag Pre-Delay Timer	Initial Value: 0.5s, range: 0.0~ 99.9s
0169	40170	B. Unlock Bag Pre-Delay Timer	Initial Value: 0.5s, range: 0.0~ 99.9s
0170	40171	Bracket upward delay timer	Initial Value: 5.5, range: 0-99.9 unit:s
0171	40172	Bracket downward delay timer	Initial Value: 5.5, range: 0-99.9 unit:s
Working parameters - basic parameters			
0200	40201	Power up auto-zero switch	Initial value: 0, 1: ON, 0: OFF
0201	40202	Zero range	Initial value: 50, range: 1-99 Unit: %
0202	40203	Stable range	Initial value: 2, stable range: 0 ~ 99d optional, Unit: d
0203	40204	Stable time	Initial value: 0.3s; range: 0.1~9.9 s
0204	40205	Zero tracking range	Initial value: 0, range: 0-9, unit: d.
0205	40206	Zero tracking time	Initial value: 2.0; range: 0.1~99.9s. (Unit: 0.1s).
0206	40207	Digital filtering level	Initial value: 7, range: 0-9
0207	40208	Secondary filter switch	Initial value: 1, 1: ON, 0: OFF.
0208	40209	AD sampling rate	Initial value: 2, 0: 120 times/sec.; 1: 240 times/sec.; 2: 480 times/sec.; 3: 9600 times/sec.
0209 ~ 0214			
Operating parameters - Advanced parameter			
0215	40216	Auto-zero interval	Initial value: 0, range: 0-99. To enter zeroing after several packagings completed.
0216	40217	Valuing mode	Initial value: 0 (range: 0, 1.) 0: stable and value. 1: value delay.
0217	40218	Weight value holding with hopper	Initial value: 0; range: 0-1 (0:

		switch	OFF; 1: ON)
0218	40219	Manual discharge accumulated switch	Initial value: 0; range: 0-1 (0: OFF; 1: ON)
0219	40220	Manual discharge bag locked adjustment switch	Initial value: 0; range: 0-1 (0: OFF; 1: ON)
0220	40221	Discharge real-time detection switch	Initial value: 0; range: 0-1 (0: OFF; 1: ON)
0221	40222	Gross/Net weight packaging mode (without hopper)	Initial value: 1 (NW) 0: Gross weight packaging mode-without hopper(feeding after bag locked) 1: Net weight packaging mode-without hopper(stable and tare after bag locked, then enter feeding)
0222	40223	Dynamic filter switch	Initial value: 0; range: 0-1 (0: OFF; 1: ON) Parameters are valid when set ON.
0223	40224	Feeding filter parameters	Initial value: 4, range: 1~9
0224	40225	Value filter parameters	Initial value: 7, range: 1~9
0225	40226	Discharge filter parameters	Initial value: 3, range: 1~9
0226 ~ 0229	Reserved		
Operating parameters - parameters structure			
0230	40231	Scale structure	Initial value: 0 0: with hopper, 1: without hopper
0231	40232	Working mode	Initial value: 0 0: scale A&scale B, 1: scale A, 2: scale B, 3 scale A& scale B without hopper, 4: scale A+scale B without hopper. With hopper: 0-2. Without hopper: 3-4.
0232	40233	Scale A & Scale B target value setting separately	Initial value: OFF. OFF: same target value ON: different target value
0233	40234	Feeding mode	Initial value: 1 0: solo, 1: combination

0234	40235	Dual scale bag unlocked mode (with-out hopper)	Initial value :: 0 0: closed; 1: bag unlocked simultaneously normal mode 2. bag unlocked simultaneously fast mode
0235	40236	Maximum capacity of solo hopper	The written range of weight values:≤maximum range
0236	40237		
0237 ~ 0249		Reserved	
Peripheral parameters-pat bag parameters(1)			
0250	40251	Pat bag mode	Initial value: 0. With hopper: 0/1. Without hopper: 0/1/2/3. 0: Closed. 1: Pat bag in feeding. 2: Pat bag after valuing 3: Pat bag in feeding and after valuing
0251	40252	Pat bag times in feeding	Initial value: 0, range: 00-99
0252	40253	Pat bag times after valuing	Initial value: 4, range: 00-99
0253	40254	Pat bag before delay	Initial value: 0.5s. Range: 0.0 -99.9s
0254	40255	Pat bag effective time	Initial value: 0.5s. Range: 0.0 to 99.9s. Pat bag output effective time in the meantime.
0255	40256	Pat bag ineffective time	Initial value: 0.5s. Range: 0.0 to 99.9s. Pat bag output ineffective time in the meantime.
0256	40257	Pat bag extra effective time	Initial: 0.0, range: 0.0 to 99.9s
0257	40258	Pat bag started weight	Weight value written range:≤maximum capacity
0258	40259		
Peripheral parameters - coding parameter (2)			
0259	40260	A code switch	Initial value: 0; range: 0-1 (0: OFF; 1: ON)
0260	40261	Coding start-up delay	Initial value: 0.5s, range: 0.0 to 99.9s

0261	40262	Coding output effective time	Initial value: 0.5s, range: 0.0 to 99.9 s
0262	40263	Allow to feed/discharge in coding	Initial value: 0 0: Allow to enter discharging output or feeding output in coding. 1: Not allow to enter discharging output or feeding output in coding.
Peripheral parameters-conveyor parameter without hopper(3)			
0263	40264	Conveyor switch	Initial value: 0; range: 0-1 (0: OFF; 1: ON)
0264	40265	Conveyor start-up delay	Initial value: 0.5s, range 0-99.9s
0265	40266	Conveyor running time	Initial value: 4.0s, range 0-99.9s
0266	40267	Scale B delay start feeding time (without hopper)	Initial value: 2.0s, range 0-9.9s
Peripheral parameters-print parameters (4)			
0267	40268	Auto print switch	Initial value: 0. 1: ON, 0: OFF
0268	40269	Print format	Initial value: 0 0: 24 lines 1: 32 lines
0269	40270	Print language	Initial value: 0.1: English: 0: Chinese
0270	40271	Print lines	Initial value: 3, 0-9
Peripheral discharge patting Parameter(s)			
0271	40272	Discharge patting ON/OFF	Initial value: 0; 1: ON; 0: OFF
0272	40273	Discharge valid timer	Initial value: 2.0; Range: 0~9.9。 (Unit:s)
0273	40274	Discharge patting valid timer	Initial value: 0.5; Range: 0~9.9。 (Unit :s)
0274	40275	Discharge patting invalid timer	Initial value: 0.5; Range: 0~9.9。 (Unit :s)
0275	40276	Discharge patting times	Initial value: 10; Range: 0~99。
0276	40277	Sewing machine start delay	Initial value: 0.5; Range: 0~9.9。 (Unit :s)

0277	40278	Sewing machine output time	Initial value: 0.5; Range: 0～9.9。 (Unit :s)
0278	40279	Cutting machine start delay	Initial value: 0.5; Range: 0～9.9。 (Unit :s)
0279	40280	Cutting machine output time	Initial value: 0.5; Range: 0～9.9。 (Unit :s)
0280	40281	Sewing machine stop delay	Initial value: 0.5; Range: 0～9.9。 (Unit :s)
0281 ~ 0299	Reserved		
Communication parameters - serial port1 parameters (1)			
0300	40301	ID No.	Scale no., Broadcast (0xFF) may modify the current ID.
0301	40302	Communication mode	Initial value: Modbus-RTU Modbus-RTU /Print/Continuous mode
0302	40303	Baud rate	Range: 0-4 (0: 9600; 1: 19200; 2: 38400; 3: 57600; 4: 115200) Default: 2 (38400)
0303	40304	Data format	Communication data format option (start bit, data bit, parity bit, stop bit. E : even parity; N : no parity) Range: 0-3 (0: 18E1; 1: 18N1; 2: 17E1; 3: 17N1) Default: 0 (18E1)
0304	40305	Hi-Lo digit	MODBUS double word register storing order. Range: 0-1 (0: Hi-Lo; 1: Lo-Hi) Default: 0 (Hi-Lo)
Communication parameters – serial port 2 parameters (2)			
0305	40306	ID	Scale no., Broadcast (0xFF) may modify the current ID.
0306	40307	Communication mode	Initial value: Modbus-RTU Modbus-RTU /Print/Continuous mode
0307	40308	Baud rate	Range: 0-4 (0: 9600; 1: 19200; 2: 38400; 3: 57600; 4: 115200) Default: 2 (38400)
0308	40309	Data format	Communication data format option (start bit, data bit, parity bit, stop bit. E : even parity; N : no parity) Range: 0-3 (0: 18E1; 1: 18N1; 2: 17E1; 3: 17N1)

			Default: 0 (18E1)
0309	40310	Hi-Lo digit	MODBUS double word register storing order. Range: 0-1 (0: Hi-Lo; 1: Lo-Hi) Default: 0 (Hi-Lo)
Cumulative print			
0310	40311	Print accumulated	Read 0. Write 1, print accumulated.
0311	40312	Print recipe accumulated	Read 0. Write 0: print present recipe accumulated Write 1-40 print the corresponding accumulated recipes Write 41, print all accumulated recipes
0312	40313	Print user accumulated	Read 0. Write 100, print current user accumulated. Write 0-9, print corresponding user accumulated. Write 101, print all user accumulated.
0312 ~ 0319	Reserved		
Scale factory reset			
0320	40321	Reset	8800 All parameters restore factory settings 8801 Calibration recovery 8802 Recovery parameters 8803 Recovery formula 8804 IO definition of recovery 8805 Perform backups 8806 Implementation of recovery Read returns 0
Switch Test Parameter			
0321	40322	Start/Stop I/O test	Write: Stop state before writing. Writing in 1 to start I/O test. In the state of I/O module test, it will not execute define function.

			In the state of I/O module test, exit when write 0. Both in-put/output ports execute define function. Read: Returns to current state of the I/O test.
0322	40323	Input test	Write: not allowed. Read: IN1~12 matches with Lo-Hi. 1: valid input, 0: invalid input.
0323	40324	Output test	Write: OUT1~16 matches with Lo-Hi, could be written when set ON. 1: valid output, 0: invalid output. Read: return to I/O module state, OUT1~16 matches with Lo-Hi. 1: valid output, 0: invalid output.
0324-0349	Reserved		
I/O Module Parameters			
0350	40351	Input port 1 is defined.	Write: Write function corresponding to the value. If defined IN as running, user has to write 1 in according register of IN. Read: Returns to I/O module state.
0351	40352	Input port 2 is defined.	
0352	40353	Input port 3 is defined.	
0353	40354	Input port 4 is defined.	
0304	40355	Input port 5 is defined.	
0355	40356	Input port 6 is defined.	
0356	40357	Input port 7 is defined.	
0357	40358	Input port 8 is defined.	
0358	40359	Input port 9 is defined.	
0359	40360	Input port 10 is defined.	
0360	40361	Input port 11 is defined.	
0361	40362	Input port 12 is defined.	
0362	40363	Output port 1 is defined.	Write: Write function corresponding to the value. If defined OUT as running, user has to write 1 in ac-
0363	40364	Output port 2 is defined.	
0364	40365	Output port 3 is defined.	
0365	40366	Output port 4 is defined.	

0366	40367	Output port 5 is defined.	cording register of OUT. Read: Returns to I/O module state.
0367	40368	Output port 6 is defined.	
0368	40369	Output port 7 is defined.	
0369	40370	Output port 8 is defined.	
0370	40371	Output port 9 is defined.	
0371	40372	Output port 10 is defined.	
0372	40373	Output port 11 is defined.	
0373	40374	Output port 12 is defined.	
0374	40375	Output port 13 is defined.	
0375	40376	Output port 14 is defined.	
0376	40377	Output port 15 is defined.	
0377	40378	Output port 16 is defined.	
0378	40379	Output port 17 is defined.	
Target value of 40 recipes parameters (read and write)			
0400	40401	Target value of recipe 1	Initial value: 0
0401	40402		
0402	40403	Target value of recipe 2	Initial value: 0
0403	40404		
0404	40405	Target value of recipe 3	Initial value: 0
0405	40406		
0406	40407	Target value of recipe 4	Initial value: 0
0407	40408		
...			
0478	40479	Target value of recipe 40	Initial value: 0
0479	40480		
0480-0499	Reserved		
Scale A target value parameters of 40 recipes (read and write)			
0500	40501	Target value of recipe 1A	Initial value: 0 (Read only)
0501	40502		
0502	40503	Target value of recipe 2A	Initial value: 0
0503	40504		
0504	40505	Target value of recipe 3A	Initial value: 0

0505	40506		
0506	40507	Target value of recipe 4A	Initial value: 0
0507	40508		
...			
0578	40579	Target value of recipe 40A	Initial value: 0
0579	40580		
0580-0599	Reserved		
Scale B target value parameters of 40 recipes (read and write)			
0600	40601	Target value of recipe 1B	Initial value: 0
0601	40602		
0602	40603	Target value of recipe 2B	Initial value: 0
0603	40604		
0604	40605	Target value of recipe 3B	Initial value: 0
0605	40606		
0606	40607	Target value of recipe 4B	Initial value: 0
0607	40608		
...			
0678	40679	Target value of recipe 40B	Initial value: 0
0679	40680		
0680-0699	Reserved		
Accumulated weight parameters of 40 recipes.			
0700	40701	Accumulated weight of recipe 1	Written 0 to clear accumulated weight and bags of the recipe.
0701	40702		
0702	40703	Accumulated weight of recipe 2	Written 0 to clear accumulated weight and bags of the recipe.
0703	40704		
0704	40705	Accumulated weight of recipe 3	Written 0 to clear accumulated weight and bags of the recipe.
0705	40706		
0706	40707	Accumulated weight of recipe 4	Written 0 to clear accumulated weight and bags of the recipe.
0707	40708		
...			
0778	40779	Accumulated weight of recipe 40	Written 0 to clear accumulated

0779	40780		weight and bags of the recipe.
0780-0799	Reserved		
Accumulated bags parameters of 40 recipes.			
0800	40801	Accumulated bags of recipe 1	Written 0 to clear accumulated weight and bags of the recipe.
0801	40802		
0802	40803	Accumulated bags of recipe 2	Written 0 to clear accumulated weight and bags of the recipe.
0803	40804		
0804	40805	Accumulated bags of recipe 3	Written 0 to clear accumulated weight and bags of the recipe.
0805	40806		
0806	40807	Accumulated bags of recipe 4	Written 0 to clear accumulated weight and bags of the recipe.
0807	40808		
....			
0878	40879	Accumulated bags of recipe 40	Written 0 to clear accumulated weight and bags of the recipe.
0879	40880		
0880-0899	Reserved		
10 users cumulative weight			
0900	40901	User 0 accumulated weight	Written 0 to clear accumulated weight and bags of the user.
0901	40902		
0902	40903	User 1 accumulated weight	Written 0 to clear accumulated weight and bags of the user.
0903	40904		
0904	40905	User 2 accumulated weight	Written 0 to clear accumulated weight and bags of the user.
0905	40906		
0906	40907	User 3 accumulated weight	Written 0 to clear accumulated weight and bags of the user.
0907	40908		
0908	40909	User 4 accumulated weight	Written 0 to clear accumulated weight and bags of the user.
0909	40910		
....			
0918	40919	User 9 accumulated weight	Written 0 to clear accumulated weight and bags of the user.
0919	40920		
0920-0949	Reserved		

10 users cumulative number of times			
0950	40951	User accumulated times 0	Written 0 to clear accumulated weight and bags of the user.
0951	40952		
0952	40953	User accumulated times 1	Written 0 to clear accumulated weight and bags of the user.
0953	40954		
0954	40955	User accumulated times 2	Written 0 to clear accumulated weight and bags of the user.
0955	40956		
....			
0968	40969	User accumulated times 9	Written 0 to clear accumulated weight and bags of the user.
0969	40970		
0970-0999		Reserved	
1000	41001	Feeding mode	
1001	41002	Motor group number	
1002	41003	Feeding stepper motor frequency of scale A	Stepper motor
1003	41004	Pulses quantity required when scale A feeding closed to Fine Flow.	
1004	41005		
1005	41006	Pulses quantity required when scale A feeding closed to Medium Flow.	
1006	41007		
1007	41008	Pulses quantity required when scale A feeding closed to Coarse Flow.	
1008	41009		
1009	41010	The motor rotation direction signal of scale A feed gate switch	
1010	41011	Feeding stepper motor frequency of scale B	
1011	41012	Pulses quantity required when scale B feeding closed to Fine Flow.	
1012	41013		
1013	41014	Pulses quantity required when scale B feeding closed to Medium Flow.	
1014	41015		
1015	41016	Pulses quantity required when scale B feeding closed to Coarse Flow.	
1016	41017		
1017	41018	The motor rotation direction signal of scale B feed gate switch	
1018	41019	Scale A feeding motor start fre-	

		quency	
1019	41020	Scale A feeding motor acceleration time	
1020	41021	Scale A feeding motor deceleration time	
1021	41022	Scale B feeding motor start frequency	
1022	41023	Scale B feeding motor acceleration time	
1023	41024	Scale B feeding motor deceleration time	
1024	41025	The running time of scale A feeding gate opens to Coarse Flow.	Normal motors
1025	41026	The running time of scale A feeding gate opens to Medium Flow.	
1026	41027	The running time of scale A feeding gate opens to Fine Flow.	
1027	41028	The running time of scale B feeding gate opens to Coarse Flow.	
1028	41029	The running time of scale B feeding gate opens to Medium Flow.	
1029	41030	The running time of scale B feeding gate opens to Fine Flow.	
1030	41031	Feeding gate closed timeout	
1031	41032	Motor feeding gate opened anti logically	
1032	41033	Bag locked mode	
1033	41034	Bag locked frequency of scale A	Stepper motor
1034	41035	Bag unlocked frequency of scale A	
1035	41036	Pulses quantity required that state of bag unlocked state turns to bag locked state of scale A motor	
1036	41037		
1037	41038	The motor rotation direction signal of scale A bag locked	
1038	41039	Motor frequency of scale B bag locked	
1039	41040	Motor frequency scale B bag unlocked	

1040	41041	Pulses quantity required that state of bag unlocked turns to bag locked of scale B motor	
1041	41042		
1042	41043	The motor rotation direction signal of scale B bag locked	
1043	41044	Scale A bag locked motor start frequency	
1044	41045	Scale A bag locked motor acceleration time	
1045	41046	Scale A bag locked motor deceleration time	
1046	41047	Scale B bag locked motor start frequency	
1047	41048	Scale B bag locked motor acceleration time	
1048	41049	Scale B bag locked motor deceleration time	
1049	41050	Bag unlocked time	Normal motor
1050	41051	Bag unlocked timeout	
1051	41052	Bag locked timeout	
1052	41053	Motor bag locked anti logically switch	
1053	41054	Discharge mode	
1054	41055	Scale A discharge gate opened motor frequency	Stepper motor
1055	41056	Scale A discharge gate closed motor frequency	
1056	41057	Pulses quantity required that state of closed turns to opened of scale A motor	
1057	41058		
1058	41059	The signal of motor rotation direction of scale A discharge gate opened	
1059	41060	The motor frequency of scale B discharge gate opened	
1060	41061	The motor frequency of scale B discharge gate closed	
1061	41062	Pulses quantity required that state	

1062	41063	of closed turns to opened of scale B motor	
1063	41064	The signal of motor rotation direction of scale B discharge gate opened	
1064	41065	Scale A discharge motor started frequency	
1065	41066	Scale A discharge motor acceleration time	
1066	41067	Scale A discharge motor deceleration time	
1067	41068	Scale B discharge motor started frequency	
1068	41069	Scale B discharge motor acceleration time	
1069	41070	Scale B discharge motor deceleration time	
1070	41071	Scale A discharge motor gate opened signal output time	Normal motors
1071	41072	Scale B discharge motor gate opened signal output time	
1072	41073	Discharge gate closed timeout	
1073	41074	Discharge gate opened timeout	
1074	41075	Motor discharge switch anti logically	
1075	41076	Discharge limit digit real-time detection switch	
1076	41077	Motor group no. of present recipe	
Compile information (front and back)			
9000	49001	Background version number	For example: 010000
9001			
9002	49003	Background compilation date	For example: 161201
9003			
9004	49005	Background compilation time	For example: 130805
9005			
9006	49007	Additional version number	For example: 200000

9007			
9008-9011		Reserved	
The following is a read-write bits (reading function codes: 0x01, writing function code: 0x05)			
Coil switch of M04-D controlling function			
Coil switch of M04-D controlling function operation			
0000	00001	Power up auto-zero	Write 1 on, 0 is written off. Each switching state is read out
0001	00002	Secondary filter switch	
0002	00003	Weight value holding switch	
0003	00004	Manual discharge accumulated switch	
0004	00005	Manual discharge adjusted bag locked and bag unlocked switch	
0005	00006	Gross/Net weight without hopper	
0006	00007	Dynamic filter switch	
0007	00008	Target value of scale A & scale B setting individually	
0008	00009	Over/Under detection switch	
0009	00010	Over/Under pause switch	
0010	00011	Under supplementary switch	
0011	00012	Free fall correction switch	
0012	00013	Coding switch	
0013	00033	Allow to feed/discharge in coding switch	
0014	00034	Conveyor switch	
0015	00035	Print switch	
0016	00017	Print switch	

0017	00018	Sewing machine start	
0018	00019	Sewing machine E stop	
Reserved			
0020	00021	Scale A zeroing	The address can write in 1 only, read out 0.
0021	00022	Scale A manual discharge	
0022	00023	Scale A manual Fine Flow	
0023	00024	Scale A bag locked/unlocked	
0024	00025	Scale A manual feeding	
0025	00026	Manual Flow A	
0026	00027	Manual Disc A	
0027-29	Reserved		
0030	00031	Scale B zeroing	The address can write in 1 only, read out 0.
0031	00032	Scale B manual discharge	
0032	00033	Scale B manual Fine Flow	
0033	00034	Scale B bag locked/unlocked	
0034	00035	Scale B manual feeding	
0035	00036	Manual Flow B	
0036	00037	Manual Disc B	
0037	00038	A Bracket upward	
0038	00039	B Bracket upward	
0039		Reserved	
0040	00041	Run	
0041	00042	Emergency stop	
0042	00043	Slow stop	
0043	00044	Select recipes	
0044	00045	Clear alarm	
0045	00046	Clear present user accumulated	

0046	00047	Clear all users accumulated	This address can be written only 1. Read as 0
0047	00048	Clear present recipe accumulated	
0048	00049	Clear all recipes accumulated	
0049	00050	Clear accumulated total	
0050	00051	All reset	
0051	00052	Calibration reset	
0052	00053	Working parameters reset	
0053	00054	Recipe parameters reset	
0054	00055	Peripheral parameters reset	
0055	00056	I/O module parameters reset	
0056	00057	Execution parameter backup	
0057	00058	Restore backup parameters	
0058	00059	Delete backup parameters	The address can write in 1 to delete backup parameters. If reads out 1, means backup parameter is available. If reads out 0, means without backup parameters.
0059	00060	Motor parameters reset	
0060-0079	Reserved		
Controlling function coil IO test			
0080	00081	I/O module test switch: to enter I/O module test by writing 1, exit by writing 0. Not allow to write when running.	
0081	00082	Read out 1 when input port 1 is valid. If invalid, will read out 0.	Do not take effect during writing.
0082	00083	Read out 0 when input port 2 is valid. If invalid, will read out 0.	
0083	00084	Read out 1 when input port 3 is valid. If invalid, will read out 0.	

0084	00085	Read out 1 when input port 4 is valid. If invalid, will read out 0.	
0085	00086	Read out 1 when input port 5 is valid. If invalid, will read out 0.	
0086	00087	Read out 1 when input port 6 is valid. If invalid, will read out 0.	
0087	00088	Read out 1 when input port 7 is valid. If invalid, will read out 0.	
0088	00089	Read out 1 when input port 8 is valid. If invalid, will read out 0.	
0089	00090	Read out 1 when input port 9 is valid. If invalid, will read out 0.	
0090	40091	Read out 1 when input port 10 is valid. If invalid, will read out 0.	
0091	40092	Read out 1 when input port 11 is valid. If invalid, will read out 0.	
0092	40093	Read out 1 when input port 12 is valid. If invalid, will read out 0.	
0093	40094	Read out 1 when output port 1 is valid. If invalid, will read out 0.	
0094	40095	Read out 1 when output port 2 is valid. If invalid, will read out 0.	
0095	00096	Read out 1 when output port 3 is valid. If invalid, will read out 0.	
0096	00097	Read out 1 when output port 4 is valid. If invalid, will read out 0.	
0097	00098	Read out 1 when output port 5 is valid. If invalid, will read out 0.	
0098	00099	Read out 1 when output port 6 is valid. If invalid, will read out 0.	
0099	00100	Read out 1 when output port 7 is valid. If invalid, will read out 0.	
0100	00101	Read out 1 when output port 8 is valid. If invalid, will read out 0.	
0101	00102	Read out 1 when output port 9 is valid. If invalid, will read out 0.	
0102	00103	Read out 1 when output port 10 is valid. If invalid, will read out 0.	
0103	00104	Read out 1 when output port 11 is valid. If invalid, will read out 0.	
0104	00105	Read out 1 when output port 12 is valid. If invalid, will read out 0.	
0105	00106	Read out 1 when output port 13 is valid. If invalid, will read out 0.	
0106	00107	Read out 1 when output port 14 is valid. If invalid, will read out 0.	
0107	00108	Read out 1 when output port 15 is valid. If invalid, will read out 0.	
0108	00109	Read out 1 when output port 16 is valid. If invalid, will read out 0.	
0109	00110	Read out 1 when output port 17 is valid. If invalid, will read out 0.	

6.3.4 Modbus-RTU protocol

example: Read the dual register command:

Read scale A weight:

Command function (single/double) bytes	Communication ID	Fuction code	Data address	Read data No.	CRC check code	
Read value (double)	01	03	00 00	00 02	C4	0B

Controller returned:

01 03 04 00 00 **18 D6** 71 AD

The 18 D6 returned represents the current weight value returned, which is directly converted to base 10, which is 6358.

Read dual register command:

Read scale A target value:

Command function (single/double) bytes	Communication ID	Fuction code	Data address	Read data No.	CRC check code	
Scale A target value(double)	01	03	00 7A	00 02	E5	D2

Controller returned:

01 03 04 00 00 **00 64** FA 33

The returned 00 64 represents the current weight value returned, which is converted directly to a base 10, which is 100.

Write the dual register command

Write scale A target value:

Command function (single/double) bytes	Communication ID	Fuction code	Data address	Write register number	Write byte No.	Write data	CRC check code	
Write target value(double)	01	10	00 7A	00 02	04	00 00 00 C8	75	62

Controller returned:

01 10 00 7A 00 02 60 11

Controller write success.

Controller Calibration:

Mark zero, write 1 at the calibration address of zero with weight:

Command function (single/double) bytes	Communication ID	Fuction code	Data address	Write register number	Write byte No.	Write data	CRC check code
--	------------------	--------------	--------------	-----------------------	----------------	------------	----------------

Zero calibration (double)	01	10	00 37	00 02	04	00 00 00 01	7 0	9 D
---------------------------	----	----	-------	-------	----	----------------------	--------	--------

Controller returned:

01 10 00 37 00 02 F0 06

Controller write success.

Mark the gain point. After adding the weight on the weighing table, write the corresponding weight at the calibration address of the weight gain, such as 1000:

Command function (single/double) bytes	Communication ID	Fuction code	Fuction code	Write register number	Write byte No.	Write data	CRC check code	
Gain calibration (double)	01	10	00 39	00 02	04	00 00 03 E8	30	6F

Controller returned:

01 10 00 39 00 02 91 C5

Controller write success.

Write coil command

Write coil ZERO:

Command function single/double bytes	Communication ID	fuction code	data address	write data	CRC check code	
ZERO(coil)	01	05	00 14	FF 00	CC	3E

Controller returned:

01 05 00 14 FF 00 CC 3E

Controller zero success.

7. Automatic packaging process

M04-D The controller in the packaged state can be automatically controlled automatic packaging coarse, medium and fine flow, and discharge of all the packaging process. Supports hopper, no hopper scale structure, a variety of modes are available. Scale structure and mode can be selected in the operating parameters.


7.1 Dual scale with hopper mode packaging

1) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is dual scale with hopper AB, AB individually set to off target, target value is set greater than the hopper volume, if the target value is a hopper volume integral multiple of "the number of discharge calculated automatically" as a target value / hopper volume. Otherwise, "the number of discharge calculated automatically" as a target value / hopper volume +1 single hopper, and single scale target value is target value / unloading times automatically calculated. After starting the main interface can see A, B and the target value, then A, B parallel hopper discharge, who measure who discharge first. A total discharge "Automatic counting of discharge times" unlocks bag only once.

2) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is dual scale with hopper AB, AB individually set to off target, single target value is set equal to less than the hopper volume, then the "number of discharge automatically calculated" is 1, single hopper target is a target value. In this case A, B are alternately discharge, discharge once unlock bag once.

3) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is dual scale with hopper AB, AB target value is set to on separately, In AB scale independent mode, need to set A or B target value, but single hopper can not exceed the hopper volume, the largest capacity of single hopper can not exceed the volume; Do not set target value at this time, even if setted is meaningless. Scale A and scale B respectively complete the quantitative process according to the target value of A or target value of B set respectively, and the unloading process of the two scales is separate, that is, when scale A is unloading, scale B needs to wait for the unloading completion of scale A even if the feeding is completed, and then the unloading can be done after the bag is lock again.

Process Description:



※In stop state, the external "start up" input signal is valid, the scale starts to detect whether the set target value and the volume of a single hopper. If set to complete the work properly, otherwise it will prompt "target weight unreasonable" message, not start.

※ Over/Under Judgment:

When the "OVER/UNDER ON/OFF" turn on, in a packaging process, upon completion of the last weighing process, system will detecting over/under testing , .when the weight is stable, it will output over/under alarm signal.

When over/under is "ON", if this occurs the packaging tolerance over or under, the scale will automatically pause quantitative process, the buzzer sounds, the pop-up window displays

the error message "A / B over/under pause" alarm information, the processing waits for the user, then press "enter" key or switch input "Clear alarm" effectively remove the alarm signal, said alarm clears scale and continue. User can also enter the emergency stop signal back to the stop state.

※*Unlock bags:*

Instrument judge the last scale, "discharge delay" time after closing the discharge at the same time start "unlock bags start delay", after the delay to take the bag if completed will unlock bag if the bag is not completed will wait to unlock bags upon completion of pat bags.

In operation, if stop input is valid, when the scale completes the operation it will unlock bag return to stop state.

7.2 Scale A with hopper mode packaging

Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is single scale with hopper A, since the method is applicable to the case of a mechanical failure or other reasons can only work for a scale.

1) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is single scale with hopper A, AB individually set to off target, target value is set Target>Hopper Volume, if the target value is volume of a single hopper integral multiple of "the number of discharge calculated automatically" as a target value / volume of a single hopper. Otherwise, "the number of discharge calculated automatically" as a target value / single hopper volume +1, and the single hopper target is target value / unloading times automatically calculated. Only the scale A work alone, a total of unloading "discharge automatically calculates the number of" unlock bag only once.

2) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale with hopper A, AB individually set to off target, single target value is set equal to less than the hopper volume, then the "number of discharge automatically calculated" is 1, single hopper target is target value. Only scale A work separately at this time, discharge material once and lock the bag once, scale B does not work.

3) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale A with hopper, AB individually set to on target, but can not exceed the volume of hopper, single hopper can not exceed volume; do not set target value at this time, even if you set is meaningless. Scale A completes the quantitative process according to target value A, discharge material once and lock the bag once, scale B does not work.

7.3 Scale B with hopper mode packaging

Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is single scale with hopper B, since the method is applicable to the case of a mechanical failure or other reasons can only work for a scale.


1) Weigher structure choose with weighing hopper, the mode selection parameter for the

scale body is single scale with hopper B, AB individually set to off target, target value is set $\text{Target} > \text{Hopper Volume}$, if the target value is volume of a single hopper integral multiple of "the number of discharge calculated automatically" as a target value / volume of a single hopper. Otherwise, "the number of discharge calculated automatically" as a target value / single hopper volume +1, and the single hopper target is target value / unloading times automatically calculated. Only the scale B work alone, a total of unloading "discharge automatically calculates the number of" unlock bag only once.

2) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale with hopper B, AB individually set to off target, single target value is set equal to less than the hopper volume, then the "number of discharge automatically calculated" is 1, single hopper target is target value. Only scale B work separately at this time, discharge material once and lock the bag once, scale A does not work.

3) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale B with hopper, AB individually set to on target, but can not exceed the volume of hopper, single hopper can not exceed volume; do not set target value at this time, even if you set is meaningless. Scale B completes the quantitative process according to target value B, discharge material once and lock the bag once, scale A does not work.

Its structure is shown below:



7.4 Dual scale without hopper mode packaging

No hopper mode, material from the material tank through the feeding mechanism feeding directly to the bag (coarse, medium, fine flow), controlling weight metering process sampling is complete (processing load cells mounted on the hopper) in a packaging bag. After the completion of metering, controller controls to unlock bag. The difference between no hopper packing and with hopper packing process is that the sensor is mounted on the hopper. After starting, after complete lock bag operation, it starts filling delay process.

Weigher structure choose no hopper packaging, the mode selection parameter choose AB Comb No Hopper. 1) If AB target value is set to Off separately , the target value is the target value of A and B scale; 2) If AB target value is set to On separately, the target values of A

and B are respectively the targets of A and B. All are independent of the volume, but can not exceed the volume.


After starting, scale B bag begins to fill, scale A bag begins to fill, and waits for the A and B unlock bags, controller control conveyor started, transport the finished packaging bag, start the next process.

7.5 Dual scale without hopper individual packaging

Weigher structure choose no hopper packaging, the mode selection parameter choose AB Separate No Hopper. 1) If AB target value is set to Off separately , the target value is the target value of A and B scales; 2) If AB target value is set to On separately, the target values of A and B are respectively the targets of A and B. All are independent of the volume, but can not exceed the volume.

After start, any scale finish filling then unlock bag, the controller will start transporting conveyor.

Its structure is shown below:



8. Motor Work Process

8.1 Motor Filling Portion

8.1.1 Step Motor Drive Filling

Step motor drive control filling door switch: I/O Module involved are: **O31 (A Filling O/P PU) / O32 (A: Filling O/P DR) / O33 (B Filling O/P PU) / O34 (B Filling O/P DR), I31 (A Filler Gate Closed)/ I32 (B Filler Gate Closed). (I31 / I32-The signal is determined by the type of signal in place).**

Take scale A Coarse flow, Medium flow, Fine flow for example:

- Coarse flow process: controller control O32 (motor rotational direction signal) to ensure the gate opening direction to the direction of motor rotation, then O31 (A Filling O/P PU) according to the A: filler motor frequency output pulse to control the stepping motor rotate to the gate opening direction, O31 (A Filling O/P PU) stop the output pulse after the number reaches the set value, the filler gate stops rotating, this is coarse flow state. Then controller Change O32 (motor rotational direction signal) output as closing gate direction.
- Medium flow process: O31 (A Filling O/P PU) according to the A:filler motor frequency output pulse to control the stepping motor rotate to the gate closing direction, O31 (A Filling O/P PU) stop the output pulse after the number reaches the set value, the filler gate stops rotating, this is medium flow state.
- Fine flow process: O31 (A Filling O/P PU) according to the A:filler motor frequency output pulse to control the stepping motor continuing rotate to the gate closing direction, O31 (A Filling O/P PU) stop the output pulse after the number reaches the set value, the filler gate stops rotating, this is fine flow state.
- Filling closing: O31 (A Filling O/P PU) according to the A:filler motor frequency output pulse to control the stepping motor continuing rotate to the gate closing direction, until detecting I31 (A:Filler Gate Closed) value input, then it stop output pulse signal, the filler gate stops rotating, filling is completely closed.
- Note: in case filling time exceeds the filler gate close overtime, controller has not detected I31 (A: Filler Gate Closed), then controller will stop O31 (A Filling O/P PU), and alarm scale A closing overtime.

8.1.2 Motor Drive Filling

Motor drive mode control filler gate switch: I/O Module involved are: scale A O43 (A filler open) / O45 (A filler open), **I31 (A: Filler Gate Closed), scale B O44 (B filler open) / O46 (B filler close), I32 (B: Filler Gate Closed).**

Take scale A Coarse flow, Medium flow, Fine flow for example:

- Coarse flow process: scale A begins filling after a delay time t1. Controller first controls scale A **O43 (A filler open)** signal output valid, the effective time is **A: Co-F, Gate Open Time**, start coarse flow process.

- Medium flow process: weight of the material in the scale $A \geq$ single scale target value-scale A coarse flow remains, scale A **O45(A filler open)** signal output is valid, the valid time is "scale A Coarse flow Gate Open Time – scale A Medium Flow Gate Open Time "
- Fine flow process: weight of the material in the scale $A \geq$ single scale target value-scale A medium flow remains, A **O45(A filler open)** signal output is valid, the valid time is "scale A Medium Flow Gate Open Time – scale A Fine Flow Gate Open Time "
- Flow off: weight of the material in the scale $A \geq$ single scale target value-scale A fine flow remains, scale A **O45(A filler open)** signal output is valid, until detecting **A filler gate limit signal I31 (A:Filler Gate Closed)**.
- note:in case closing process is longer than the filler gate close overtime, controller has not yet detected I31 (A loading door closed in place),Then the controller will stop O45 (A closed feed),and alarm scale A filler gate close overtime.
- Note: When controller started, it is necessary to detect whether filler gate and discharge gate are in the limit, if not, controller will alarm and cant’be started.

8.2 Motor lock Bag Portion

8.2.1 Step Motor Drive lock/unlock bag

Step motor drive controls bag lock/unlock: I/O Module involved are: **O35 (A: Bag Clutch O/P PU) / O36 (A: Bag Clutch direction signal) / O37 (A: Bag Clutch O/P PU) / O38 (A: Bag Clutch direction signal), I33 (A: Bag Released)/ I34 (B: Bag Released)**. (I37/I38 signal is determined by the limited signal type.)

Take binyES with metering hopper mode, bag lock/unlock clutch process for sample:

- Lock bag process: controller control **O36 (A: Bag Clutch direction signal)** output, ensure motor rotating direction is lock bag direction, then **O35 (A: Bag Clutch O/P PU)** according to the **A clutch motor frequency** to output pulse, control lock/unlock step motor rotating to lock bag direction, **O35 (A:Bag Clutch O/P PU)** number reach setted **scale A clutch pulse number** it will stop output pulse signal, at this time lock/unlock mode is in the lock bag state. Then controller change **O36 (A: Bag Clutch direction signal)** output to unlock direction.
- Unlock bag process: **O35 (A:Bag Clutch O/P PU)** according to the setted **scale A clutch motor frequency** to output pulse, control clutch step motor rotating to unlock direction, until detecting **I33(A:Bag Released)** input valid then stop output pulse signals, this is unlock state. Note: if unlock bag process time more than **Bag Release Overtime**, controller has not yet detected **I33 (A: Bag Released)**, then the controller will stop output **O35 (A: Bag Clutch O/P PU)**, and alarm scale A: **Bag Unlock overtime**.

8.2.2 Motor Drive Dual-Limit lock/unlock bag

Motor drive dual-limit controls bag lock/unlock: I/O Module involved: **O9 (A lock bag) / O47 (A unlock bag)/ O12 (B lock bag)/ O48 (B unlock bag), I23 (A Bag Locked) / I33 (A**

Bag Released) / I24 (B Bag Locked) / I34 (B Bag Released). (I33/I34 signal is determined by the Limit signal type).

Take binyES with metering hopper mode, bags lock/unlock process for sample:

- Lock bag process: controller output lock bag signal (O9) to control lock/unlock bag motor rotating to lock bag direction, until detecting bag locked signal (I23) input valid then stop output lock bag signal (O9), at this time lock bag mode is in the lock state. Note: in case lock bag process time exceeds the setted **Bag Lock Overtime**, controller has not yet detected bag locked signal (I23), then controller stops output lock bag signal (O9), and alarm **scale A lock bag process overtime**.
- Unlock bag process: controller output unlock bag signal(O47) to control lock/unlock bag motor rotating to unlock bag direction, until detecting bag released signal(I33)input valid then stop output unlock bag signal(O47), at this time lock/unlock mode is in the unlock state. Note: in case unlock bag process time exceeds the setted **Bag Unlock Overtime**, controller has not detected bag released signal (I33), then controller stop output unlock bag signal (O47), and alarm **scale A unlock bag process overtime**.

8. 2. 3 Motor Drive Single-Limit lock/unlock bag

Motor drive dual-limit controls lock/unlock bags: I/O Module involved: **O9 (A lock bag) / O47 (A unlock bag)/ O12 (B lock bag)/ O48 (B unlock bag), I23 (A Bag Locked) / I24 (B Bag Locked)**

Take binyES with metering hopper mode, bags lock/unlock process for sample:

- Lock bag process: controller control O9 I/O module output signals, output signal until detecting bag locked signal I23 input is valid, this output signal output is invalid, lock bag.
- Unlock bag process: controller control O47 I/O module output signals, in order to unlock bag, output signal time of duration is for unlock bag output, this output signal is invalid.
- Note: in case lock bag time of duration exceeds setted **Bag Lock Overtime**, controller has not detected A Bag Locked (I23), then controller will stop output O9, and alarm **scale A lock bag overtime**.

8.3 Motor Discharge Portion

8.3.1 Step Motor Drive Discharge

Step motor control discharge: I/O Module involved are: **scale A O39 (A: DISC O/P PU), O40 (A: DISC O/P DR), I35 (A: DISC O DR), scale B O41 (B DISC pulse output), O42 (B: DISC O/P DR), I36 (B DISC O DR).**

Take scale A discharge for sample:

- Discharge gate opening process: controller control **O40 (A: DISC O/P DR)**output, to ensure that the motor rotating direction is gate opening direction,then **O39 (A: DISC O/P PU)** according to the set **Discharge Gate Opened Motor Frequency** output pulse, to control the discharge step motor rotating to discharge opening gate direction, **O39 (A:**

DISC O/P PU) number reaches setted **A discharge pulse needed number**'s value then stop output pulse signals, at this time discharge mode is in the open state.

- Discharge gate closing process: after the discharge gate opened, if controller detecting hopper weight lower than **Near Zero Value**, then start the **Discharge Delay Time**, when the discharge delay time is finish, controller change **O40 (A: DISC O/P DR)** as the closing direction, **O39 (A: DISC O/P PU)** according to the setted **Discharge Gate Opened Motor Frequency** to output pulse, to control the discharge step motor rotating to closing gate direction, until detecting **I35 (A: DISC O DR)** input value then stop output pulse signals, at this time is closing gate state. Note: in case closing process time exceeds setted **DISC Gate Close Overtime**, controller has not yet detecting closing gate signal **I35 (A: DISC O DR)**, then controller will stop output **O39 (A: DISC O/P PU)**, and alarm **scale A discharge gate close overtime**.

8.3.2 Motor Drive Single-Limit Discharge

Motor positive and negative rotation single-limit mode control discharge: I/O Module involved are: **O11 (A DISC Gate Open) O14 (B DISC Gate Open) O49 (A DISC Gate Close) O50 (B DISC Gate Open), I25 (A DISC Gate Close)/ I26 (B DISC Gate Close)**.

Take scale A discharge process for sample:

- Discharge gate opening process: when discharge process begins, controller output discharge signal (**O11**) to control discharging motor rotating to discharge gate open direction, and continuing setting **scale A discharge gate open output valid time** setted discharge motor open gate signal output time, then close discharge signal (**O11**) output.
- Discharge gate closing process: after the discharge gate open, if controller detecting hopper weight lower than **Near Zero Value**, then start the **Discharge Delay Time**, when the discharge delay time is finish, it output discharge gate close signals (**O49**), to control discharge motor rotating to discharge gate closing direction, until detecting discharge gate close signal (**I25**) input valid then stop output discharge gate close signal (**O49**), at this time discharge gate is closed. **Note:** in case discharge gate close process time exceed setted **A Discharge gate close overtime**, controller has not yet detecting discharge gate close signal (**I25**), then controller will stop output (**O49**), and alarm **scale A discharge gate close overtime**.

8.3.3 Motor Drive Dual-Limit Discharge

Motor positive and negative rotation dual-limit mode control discharge: I/O Module involved are: **O11 (A discharge) / O14 (B discharge) / O49 (A DISC Gate Close) / O50 (B DISC Gate Close), I25 (A DISC Gate Close)/ I35 (A DISC Gate Open) / I26 (B DISC Gate Close) / I36 (B DISC Gate Open)**.

Take scale A discharge process for sample:

- Discharge gate opening process: when discharge process begins, controller output discharge signal (**O14**) to control discharging motor rotating to discharge gate open direction, until detecting DISC Gate Open (**I35**) input valid then stop output dis-

charge signal (O14), at this time discharge gate is open state. Note: in case discharge gate open process time exceeds the settled **A discharge gate open overtime**, controller has not yet detected DISC Gate Open (I35), then controller stop output (O11), and alarm **scale A discharge gate open overtime**.

- Discharge gate closing process: After the discharge gate open, if controller detecting hopper weight lower than **Near Zero Value**, then start the Discharge Delay Time, when the discharge delay time is finish, controller output discharge gate close signal (O11), to control the discharge motor rotating to close gate direction, until detecting DISC Gate Close (I25) input value then stop output discharge gate close signal (O11), at this time is discharge gate close state. Note: in case discharge gate close process time exceeds settled **A discharge gate close overtime**, controller has not yet detecting DISC Gate Close signal(I25), then controller will stop output (O11), and alarm **A discharge gate close overtime**.

8.3.4 Motor Drive Rotating Discharge


Motor drive rotating discharge control discharge: I/O Module involved are: **O11 (A discharge) / O14 (B discharge), I25 (A DISC Gate Close)/ I35 (A DISC Gate Open)**.

Take scale A discharge process for sample:


- Discharge gate opening process: when discharge process begins, controller output discharge signal (O11) to control discharging motor rotating to discharge gate open direction, and continuing setting **discharge motor gate open signals output time**, then close discharge signal(O11)output.
- Discharge the closing process: After the discharge gate open, if controller detecting hopper weight lower than **Near Zero Value**, then start the Discharge Delay Time, when the discharge delay time is finish, controller output discharge signal (**O11**), to control the discharge motor rotating to discharge gate close direction, until detecting DISC Gate Close (I25) input value then stop output discharge signal (O11), at this time is discharge gate close state.
- Note: in case discharge gate close process time exceeds **discharge gate close overtime**, controller has not yet detecting DISC Gate Close signal (**I25**), and then controller will stop output (**O11**), and alarm **scale A discharge gate close overtime**.

9. Dimension (mm)

The front frame size



Side dimension



Mounting hole size

