



GMT-P1

—PN/EIP/EtherCAT/CCLINK

User's Manual

110611010012
v30.02.09

©2021, Shenzhen General Measure Technology Co., Ltd reserves all copyright.


Without permission from Shenzhen General Measure Technology Co., Ltd.,

Any corporations or person must not copy, spread, record or translate into other language by any forms.

Our company reserved the right to update user's manual without additional notice to customers by reason of update, so please visit our website or contact with our service person to get update information.

Website: <http://www.gmweighing.com>

Product Performance Standards: GB/T 7724—2008



CONTENTS

1 General Description	1
1.1 Functions and Characteristics	1
1.2 Front Panel.....	2
1.3 Rear Panel.....	4
1.4 Technical Specifications	4
1.4.1 Common.....	4
1.4.2 Analog.....	5
1.4.3 Digital	5
2 Installation and Wiring.....	6
2.1 Connection of Power Supply	6
2.2 Connection of Load Cell.....	6
2.2.1 6 wires connection	7
2.3 I/O terminals	8
2.4 BUS Port connection	10

3 Calibration	12
3.1 Instruction	12
3.2 Flow Chart of Calibration	12
3.3 Millivolt Value Display.....	17
3.4 Calibration with Weights	18
3.5 No weight calibration.....	18
3.5.1 No weight zero Calibration.....	18
3.5.2 No weight gain Calibration.....	19
Historical gain calibration.....	20
Sensitivity and gain calibration range.....	21
3.6 Remote calibration switch.....	22
3.7 Explanation for Calibration Parameters.....	22
4 Working Parameters Setting.....	24
4.1 Flow Chart of Working Parameters Setting	24
4.2 Parameter Setting Method.....	25
4.3 Descriptions of Operation Parameters	26
4.4 Set point parameters.....	30

5 I/O Definition.....	33
5.1 I/O Definition.....	33
5.2 I/O testing	35
6 Communication.....	37
6.1 PROFINET Communication.....	37
6.1.1 I/O Status	37
6.1.2modbus read write operate address sheet.....	46
6.1.3 Device Description file GSD	52
6.1.4 Profinet master configuration GMT-P1.....	52
6.2 Ethernet-IP communication	64
6.2.1 IO status	64
6.2.2 Device description file EDS.....	71
6.3 EtherCAT Communication.....	71
6.3.1 Compact Version Parameter address	72
6.3.2 Device description file ESI	74
6.4 CCLINK IE Communication	74
6.4.1 Compact Version Parameter address	75

6.4.2 Acyclic parameter lists	78
6.4.3 Device Description File CSP	79
7 Password Input and Setting Reset.....	80
7.1 Password Input.....	80
7.2 Password Setting.....	80
7.3 Factory Reset	81
8 Display Testing	83
9 Errors and Alarm Messages	84
10. Indicator model user-defined function.....	85
11 Dimension of Indicator	86


1 General Description

GMT-P1 digital indicator is specially designed for weight transmitting in industrial fields. Support **Profinet, Ethernet IP, EtherCAT, CCLINK IE**. The digital indicator is a small weight display which is specially designed and produced for the occasion of weight transmit industrial. The indicator has the features of compact size, stable performance, simple operation. Can be widely used in: cement mixing and asphalt mixture equipment, metallurgical blast furnace, converter and chemical industry, feed weight control and other occasions.

1.1 Functions and Characteristics

- Small volume, unique design, easy operation
- Applicable to all kinds of resistance strain gauge bridge load cell
- Front panel numerical calibration
- Multilevel of digital filter
- Automatic zero -tracking
- Automatically zero when powered on
- **PROFINET** fieldbus interface
- Support **Ethernet IP** communication, can access **Ethernet IP** network
- Support **EtherCAT** real-time Ethernet technology, high data synchronization accuracy, flexible topology
- Support **CCLINK IE** field infrastructure technology, high-speed and large-capacity field network
- Weight display can be remotely calibrated (remote calibration ON/OFF turned on)

1.2 Front Panel



Main Display: 6 digits, for displaying weight and the information of parameters.

Status Indicator Lamp:

- **ZERO:** Light on when present weight is within $0 \pm 1/4d$.
- **STAB:** Light on when changes of weight values are within the range of motion detecting during motion detecting time.
- **NET:** Light on when indicator is in gross/net weight status and communication indicator.

Keypad:

ZERO
ESC ■: Exit from current operation or go previous. Long press the ZERO button to calibrate the ZERO point function. (Limited by the ZERO clearing range, but it is not limited by calibration lock)


TARE
OPTION ▲: Scroll optional values of parameter and to make flashing digit increase 1 while data inputting. Long press Tare key will switch F1.8 parameters, that is, to switch the NET indicator content.

MODE ►: Function selecting key, make flashing position move to the right digit when data inputting.

W/A
ENTER ●: Confirming Key. Confirm setting parameters or calibration and input data.

Note: Under the status of gross weight, user could remove tare by pressing OPTION key. After tare, it automatically switches to the NET weight display, and the NET indicator lights up. In the state of net weight, press ESC to operate tare. In the state of gross weight, press the ESC key is still zeroing.

1.3 Rear Panel



※ PN/EIP/EtherCAT indicator, light blinks when bus communication normal.

1.4 Technical Specifications

1.4.1 Common

Power supply: DC24V±5%

Working temperature: -10 ~ 40°C

Max humidity: 90%R.H without dew

Power consumption: **About 10W**

Dimension: **105×89×57 (mm)**

1.4.2 Analog

Load cell power: **DC5V 200mA (MAX)**

Input impedance: **10MΩ**

Zero steady range: **0.00 ~ 15mV(Load cell 3mV/V)**

Input sensitivity: **0.01uV/d**

Input range: **0.00 ~ 15mV(Load cell 3mV/V)**

Transfer mode: **Sigma - Delta**

A/D conversion speed: **30, 60, 120, 240, 480, 960 times/sec**

Non-linearity: **0.01% F.S**

Gain drift: **10PPM/°C**

Display Precision: **1,000,000d**

1.4.3 Digital

Weight display: **6 digits red high-brightness LED**

Minus display: **“-”**

Overload display: **“OFL”**


Decimal point: **5 kinds (optional)**

Function keys: **4 keys sound keypad**

2 Installation and Wiring

2.1 Connection of Power Supply

GMT-P1 digital indicator connects DC24V power supply as follows:



※ Please pay attention to the positive and negative polarity of the power supply.

Power supply connection

2.2 Connection of Load Cell


GMT-P1 digital indicator connects bridge type resistance strain gauge load cells by 6 wires or 4 wires as follows. When you use 4-wired load cells, you must bridge the SN+ with EX+ and bridge the SN- with EX-.

The signal definition of each port of the load cell connector is as follows:

EX+: Excitation+ EX-: Excitation- SN+: Sense+ SN-: Sense- SIG+: Signal+ SIG-: Signal-

6 wires	EX+	SN+	EX-	SN-	SIG+	SIG-	Shield
4 wires	EX+		EX-		SIG+	SIG-	Shield

2.2.1 6 wires connection




Note:

1. As load cell output sensitive analog signal, please use shield cable to separate with other cables, especially AC power.
2. 4 wires connection is suitable for short distance and stable temperature or low precision field, otherwise use 6 wires connection.
3. For more load cells parallel connection, their sensitivity (mV/V) should be same.

2.3 I/O terminals


The I/O of GMT-P1 weight display can be customized by the user (see Chapter 5 for details) to facilitate user wiring and some special applications. The driving current of each channel is 200mA. When the product leaves the factory, the default definition is as follows.




I/O tolerant definition as follows:

Output		Input	
OUT1	O1 Stable	IN1	I6 Reset all
OUT2	O2 OFL		

Indicator input terminal connection:




Indicator output terminal connection:



2.4 BUS Port connection

GMT-P1 supports **Profinet, Ethernet IP, EtherCAT, CCLINK IE Base** bus protocol communication (**the above three are optional functions, order need to declare**). Note: **When** EtherCAT communication, Port1 is used as the entrance. When connecting with multiple devices, the devices should be connected serially to distinguish the entrance and exit order.



Internal communication indicator: Hardware connection is normal, the internal communication indicator is ON.

Connector indicator: cable connection is normal, connection light is flashing.

Communication indicator: When PN, EIP and EtherCAT,CCLINK IE Base are communicating normally, the communication indicator is blinking.

3 Calibration

3.1 Instruction

- (1) When **GMX-T1** weight transmitter or any part of the weighing system is changed for the first time and the current equipment calibration parameters can't meet the user's requirements, the display shall be calibrated. Calibration can determine the system zero and gain of the weighing system.
- (2) If you want to set only one parameter, please press $\frac{W/A}{ENTER}$  to save parameter's value and then press $\frac{ZERO}{ESC}$  to exit.
- (3) Please see section 3.7 for parameters' instruction.
- (4) Please record each value in the blank table in section 3.4 during calibration for the emergency use in future.
- (5) See chapter 9 for error alarm message that may be displayed during calibration.

3.2 Flow Chart of Calibration



Normal Status



Password input




Decimal point

1. Under this status, press **MODE** (twice), indicator will display **CAL**, then press **W/A ENTER** to enter password input.

2. After enter correct password, the indicator will display **CALON** for one second, then go to set decimal point.

3. Press **TARE OPTION** to select a desired value for decimal point among 0,0.0, 0.00, 0.000 and 0.0000, and then press **W/A ENTER** to save it and enter next step. If there's no need to change the value, press **W/A ENTER** directly to enter next step.



4. Press **TARE** **OPTION**  to select a desired value for min. division among **1,2,5,10,20** and **50**, and then to save it and enter next step.

If there's no need to change the Min,division, then press **W/A** **ENTER**  directly to enter next step.

5. Input max. capacity($\leq \text{min. division} \times 1000000$), press **W/A** **ENTER**  to save it and enter Millivolt value display interface.

If there's no need to change the max. capacity value, then press **W/A** **ENTER**  directly to enter Millivolt display interface.

6. Under this status, press **W/A** **ENTER**  to enter zero calibration.

Display value near the output value in millivolt between **SIG+/SIG-** of load cell.

See section **3.3** for details about this function.




Zero calibration

7. Unloaded scale first, when **STAB** lamp is on, press $\frac{W/A}{ENTER}$  to finish zero calibration. If there's no need to calibrate zero, press $\frac{ZERO}{ESC}$  directly to enter gain calibration.

8. The process of gain calibration is as follows. If there's no need to do gain calibration, press $\frac{ZERO}{ESC}$  directly to enter serial ports calibration switch setting.

Gain calibration



Load the weights onto the scale table. Display millivolt value.




$\frac{W/A}{ENTER}$ 



Input the value of loaded weight.



$\frac{W/A}{ENTER}$ 



Remote
calibration
switch



588888

Password
setting



PASS88

Normal
status

PASS88

9. Press $\frac{W/A}{ENTER}$  to enter remote calibration ON/OFF, press $\frac{TARE}{OPTION}$  to choose ON/OFF. press $\frac{W/A}{ENTER}$  to set password. If don't need to set switch position, then press $\frac{ZERO}{ESC}$  to enter password setting.

10. Refer to section 7.2 to set password. If there's no need to set password, press $\frac{ZERO}{ESC}$  directly to go back to normal status.

3.3 Millivolt Value Display

This function is mainly used for system test, position-error test for weighing mechanism and linearity test for load cell.

1. System Test

(1) If display data changes with loaded weight changes, it shows that connection of load cell is correct and weighing mechanism works well.

(2) If display value is OFL (or -OFL), it means that loaded weight on load cells is too large (or too small). Please unload the weight (or load more), if display value is still OFL (or -OFL), the possible reasons are as follows:

- a. There is something wrong with weighing mechanism, please check and clear.
- b. The connection of load cell is incorrect, please check and clear.
- c. Load cells may be damaged, please replace.

2. Position-error Test for Weighing Mechanism

Load a same weight on each corner of weighing mechanism and record displayed millivolt value respectively. If differences among these values are obvious, please adjust weighing mechanism.

3. Linearity Test for Load Cell

Load same weight for several times, and record displayed value every time. If one or two values are obviously much larger or smaller than any others, it means that the linearity of load cell is bad. Please change the sensor.

3.4 Calibration with Weights

In Chapter 3.2, steps 7 and 8 in the calibration flow chart are operation instructions of zero calibration and gain calibration with weights.


During calibration with weight, please record the zero millivolt value, gain millivolt value and the loaded weight value in the blank table below. If it is not convenient to load a weight to calibrate, these values can be used for calibration without weights.

	Zero millivolt value(mV)	Gain millivolt value(mV)	Loaded Weight	Date	Remarks
1					
2					
3					

3.5 No weight calibration

3.5.1 No weight zero Calibration

When the mechanism is calibrated with weights, the millivolt value corresponding to the empty balance should be recorded. Zero calibration is accomplished by manually entering historical values.




3.5.2 No weight gain Calibration

There are two methods for weighting - free calibration gain


- 1) Historical calibration: Gain calibration by entering historical record values.
- 2) Theoretical calibration: Calibrate through sensor sensitivity and maximum range value of input mechanism (the sum of the average value of input sensitivity and maximum range when multiple sensors are connected)

Historical gain calibration



- 1) In gain calibration interface, press **TARE / OPTION** ▲, and the interface displays 1. Press **W/A / ENTER** ● to enter the manual gain millivolt input interface and enter the historical millivolt value.
- 2) Press **W/A / ENTER** ● save to enter the weight input interface and enter the weight value corresponding to the millivolt number.
- 3) Press **W/A / ENTER** ● save to complete gain calibration and enter the remote calibration switch.

Sensitivity and gain calibration range



- 1) In gain calibration interface, press twice **TARE** / **OPTION** (up arrow) to enter and choose "2" press enter interface for manual input of sensor sensitivity and input the sensitivity of the actual sensor.
- 2) Press **W/A** / **ENTER** (down arrow), enter the maximum range input interface and input sensor range.

- 3) Press **W/A** **ENTER** , complete gain calibration and enter serial port calibration switch.

3.6 Remote calibration switch

When calibrate the transmitter over **PN/EIP/EtherCAT** communication, the remote calibration switch must be “ON” ,otherwise sending the calibration command will return an error.

3.7 Explanation for Calibration Parameters


Symbol	Parameter	Types	Value of parameter	Default
Pt	Decimal Point	5	0 0.0 0.00 0.000 0.0000	0
1d	Min. Division	6	1 2 5 10 20 50	1
CP	Max. Capacity		$\leq \text{Min. Division} \times 1000000$	10000
t	Millivolt Value			
o	Zero			
C	Gain			
SIOCAL	Remote calibration switch			OFF
PASS	Password Setting			000000

Annexed Table for Calibration Parameters


Parameter	Calibrated Value	Date	Remarks
Decimal Point			
Min. Division			
Max. Capacity			
Load cell sensitivity			
Password			

4 Working Parameters Setting

4.1 Flow Chart of Working Parameters Setting



1. Use **MODE ►** to select between the same level. Switch from display **F1** to **F2**, press **MODE ►**.



2. Press **W/A ENTER** to enter into sub-selection, press **ZERO ESC** to return back to previous menu.


When it displays **F2**, press **W/A ENTER** to enter into **F2.1**.

4.2 Parameter Setting Method

GMT-P1 has 2 kinds of working parameters: Selection type and data type. For selection type parameters, press **TARE OPTION** to choose. For data type parameter in parameter interface, press **MODE** to choose digit position, press **TARE OPTION** to choose value.

Selection:





4.3 Descriptions of Operation Parameters

Code	Default	Description
F1	Null	The first major term of working parameter.
F1.1	OFF	Switch for Auto-Zeroing when power-on(met the zeroing range condition), OFF: disabled; ON1: the transmitter automatically performs zero-clearing after power-on. ON2: Restore zero before power failure after power-on.
F1.2	0	Zero-tracking Range (0 to 9d optional). This parameter is used to automatically calibrate the slight drift of zero due to a small amount of material remaining

		on the scale body. When set to 0, the zero-tracking function is disabled.
F1.3	1	Stable Range (0 ~ 9d optional) It is stable if the change is within range.
F1.4	50	Zeroing Range (00% to 99% of Maximum capacity) If the current weight > maximum range*zero range,the display “Error2”.
F1.5	5	Digital filtering parameter: (0-9 as optional) 0: without filtering 9: strongest digital filtering
F1.6	0	Defibrillation filtering 0: without filtering 9: strongest digital filtering(0-9 as optional)
F1.7	0	A/D conversion rate: 120,240,480,960, 30,60 as optional
F1.8	OFF	NET indicator switch OFF:NET indicating gross/net weight, the indicator is on for net weight and off for gross weight. ON:NET indicating communication of the front and rear panels. When normal, the indicator keeps blinking.
F1.9	OFF	Parameter remote edit ON/OFF If this parameter set to ON, then work parameters and part of calibration parameters can be modified through the

		master station during bus communication. If this parameter set to OFF, the modified parameters on the primary site do not take effect.
F1.10	GSD1/ EDS1	Parameters are available only when the PN/EIP function is configured . PN Parameters: GSD1 (silver standard)- Supports full parameter INPUT and OUTPUT (80 bytes INPUT, 48 bytes OUTPUT) and acyclic parameters.For details,see section 6.1.1.1 GSD1. GSD2(silver compact)- Support key parameter INPUT and OUTPUT (9 bytes INPUT, 1 bytes OUTPUT) and acyclic parameters. For details, see section 6.1.1.2 GSD2. GSD3(blue compact)- Support key parameter INPUT and OUTPUT (9 bytes INPUT, 1 bytes OUTPUT), do not support acyclic parameters. For details,see section 6.1.1.2 GSD2. EIP Parameters: NULL; EDS1 (standard)- For details, see section 6.2.1.2 EDS1. EDS2(compact)- For details, see section 6.2.1.2 EDS2.

F1.11	OFF	PN communicates weight status with a seventh-bit heartbeat packet and tare instability alarm switch. (This parameter setting is only effective when PN communication is selected) OFF: Tare alarm is displayed when unstable . ON:The heartbeat packet is displayed.
F1.12	Int	PLC displays weight floating-point and integer switches. (Optional PN communication, this parameter setting is effective) Int: integer display; Float: floating-point is displayed.
F2	Null	The second largest term of the argument
F2.1 - F2.4	192.168.001.001	IP address ,ranges from 0.0.0.0 to 255.255.255.255.
F2.5 - F2.10	BC. 66.41.92.2 d. 12	MAC address , read only.
F3	Null	Parameter setting the third item
F3.1	OFF	Parameter password setting switch. ON/OFF.

F3.2	000000	Parameter password setting; This parameter is valid when F3.1 is ON
F4	Null	The fourth major term of working parameter.
F4.1	1.00000	Weight correction factor K, weight correction factor K = Expected weight/current weight range: 0-9.99999 When the weight is calibrated (gain) or the calibration parameter is reset, the value changes to the default value of 1.00000
F5	Null	Parameter setting refer the 5 th term
F5.1	0	EtherCAT site alias Settings. The changes take effect immediately. Range: 0 to 65535

4.4 Set point parameters

Press the key **MODE** ► 3 times in the main display interface, the instrument will display **SPoint**, under this interface, press $\frac{W/A}{ENTER}$ ● key, if the working parameter **F3.1** item is **ON**, then you need to enter the working parameter password, if it is **OFF**, then you can enter the set point parameter setting **P1** item without entering the password, press $\frac{W/A}{ENTER}$ ● key to enter the **P1.1** item, then the key parameter blinking, In this interface can modify the parameter value (see section [4.2](#) parameter Settings), after the modification is completed, press $\frac{W/A}{ENTER}$ ● to save, then

press the key **ZERO**
ESC ■ to exit to **P1** item, press **MODE** ► key to the next parameter setting. In the same way, other parameters can be set.

Note: There are four setpoints in total. Set point **X** indicates "set point **1** to **4**", which can be set by users according to their needs.

Code	Default	Description
P1-P4	Null	The first term of working parameters
PX.1	OFF	After meeting the comparison condition of PX.3, whether it is necessary to wait for the weight to stabilize before changing the output set point X state of the switching quantity (set point X state
PX.2	0.0	After the continuous time and the PX.3 comparison condition is satisfied, the output set point X state of the switching quantity is changed (set point X state is divided into valid and invalid); Range: 0 to 99.9s
PX.3	P1.3 = 1 P2.3 = 5 P3.3 = 0 P4.3 = 0	Condition of validity: 0: forbid; 1: < Less than; when the weight is less than Px.4, the output is valid, otherwise it's invalid 2: <= Less than or equal to; when the weight is less than or equal to Fx.4, the output is valid; otherwise, it is invalid.

		3: == Equal; when the weight is equal to Px.4, the output is valid; otherwise, it is invalid 4: >=; Bigger than or equal to; when the weight is greater than Px.4, the output is valid, otherwise, it is invalid 5: > Bigger than; when the weight is greater than Px.4, the output is valid, otherwise, it is invalid 6: != not equal to; when the weight is not equal to Px.4, the output is valid, otherwise, it is invalid 7: _◇_ Outside the interval, When the weight is less than Px.4 or more than Px.5, the output is valid, otherwise, it is invalid 8: =<_>= In the interval, when the weight is bigger than or equal to Px.4 and less than or equal to Px.5, the output is valid, otherwise, it is invalid 9: external trigger. If it's IO, trigger once converts a valid state to an invalid state, if it's command, it is determined by accepting a valid or invalid command.
PX.4	0	Set value 1; 0 ~ 999999 can be set
PX.5	0	Set value 2; 0 ~ 999999 can be set

Set point has 4 major terms which are user defined.

5 I/O Definition

5.1 I/O Definition

In the main display interface, press **MODE** ► 4 times to display **io dEF** in the indicator. In this interface, press **W/A** **ENTER** ● to enter the interface of custom setting of I/O module. If the password switch of working parameter F3.1 is set as ON, the password of working parameter needs to be entered before entering the custom setting of I/O module.

Operation steps of I/O module customization: After entering the interface of I/O module customization,

- 1) Press **W/A** **ENTER** ● to modify the definition of **OUT1**
- 2) Press **TARE** ▲ to select the meaning code of I/O module
- 3) Press **W/A** **ENTER** ● to confirm and return to the **OUT1** interface
- 4) Press **MODE** ► to define the next I/O module, then press **MODE** ► to skip the current I/O module definition (keep the original definition) to set the next I/O module. The definition method is the same as the above three steps, which will not be repeated here. Press **ZERO** **ESC** ■ to exit when the

setup is complete.

Output/Input code table:

Output		
Code	Definition	Description
00	None	No definition
01	Stable	Effective output in stable status.
02	Overflow	Effective output when the weight overflow.
03	SP1	Effective output when set point 1 status output.
04	SP2	Effective output when set point 2 status output.
05	SP3	Effective output when set point 3 status output.
06	SP4	Effective output when set point 4 status output.
Input		
Code	Definition	Description
I0	None	No definition
I1	Zeroing	Effective input for zeroing, pulse input signals
I2	SP1	If this signal is valid, Sp 1 status will be regarded as invalid. Output valid state when comparison condition turns to invalid, and be effective again.

I3	SP2	If this signal is valid, Sp2 status will be regarded as invalid. Output valid state when comparison condition turns to invalid, and be effective again.
I4	SP3	If this signal is valid, Sp3 status will be regarded as invalid. Output valid state when comparison condition turns to invalid, and be effective again.
I5	SP4	If this signal is valid, Sp4 status will be regarded as invalid. Output valid state when comparison condition turns to invalid, and be effective again.
I6	Reset all	Reset all parameter value when this signal is valid.
I7	Tare/ Clear tare	Tare when the first valid signal. Add tare when second.
I8	Tare	Tare when the signal is valid.
I9	Add tare	Add tare when the signal is valid.
I10	I/O define	IO calibration lock, when I10 is defined, cannot be calibrated if the input is invalid.


5.2 I/O testing



Under weighing status, press **MODE** ► (5 times), then display **TEST io**, press **W/A** **ENTER** ● enter into I/O testing interface.



Normal Status



Press **TARE** **OPTION** ▲ **OUT1** status flash, press **MODE** ► **OUT2** status flash.



This interface shows: **IN1** input valid, **OUT1** output

6 Communication

6.1 PROFINET Communication

GMT-P1 display has two PROFINET-IO bus connections, Port1 and Port2, and can be used as a PROFINET-IO slave station to connect to the PROFINET bus.

IP address can be set and viewed in Setup parameters F2.1 to F2.4; MAC address in F2.5~F2.10 to view.

6.1.1 I/O Status

GMT-P1 provides multi-byte, IO output in two modules, through which the master station can read and control the status of the weighing display.

6.1.1.1 GSD1

Module 1: Weight and status parameter (read register)

Offset	Parameter	Data type	Description
0	Weight display	DInt	Current display weight, integer
4	Weight status marker	Duint	D4-D15 Reserved
			D3: Weight marker
			D2: ZERO, (weight is in 0+/-1/4d range)
			D1: Weight overflows bit

			D0: Weight stable marker
8	Gross weight	DInt	Gross weight (signal integer)
12	Net weight	DInt	Net weight (signal integer)
16	Tare weight	DInt	Tare weight (signal integer)
20	Current weight	Float	Current weight, floating-point type
24	Gross weight	Float	Gross weight, floating-point type
28	Net weight	Float	Net weight, floating-point type
32	Tare weight	Float	Tare weight, floating-point type
36	Preset point status area	Word	D5-D15 Reserved
			D3: Preset point 4 status area
			D2: Preset point 3 status area
			D1: Preset point 2 status area
			D0: Preset point 1 status area
38	Heartbeat communication	Word	After the connection is established, the value of the communication heartbeat of the PN will also be converted between 0 and 1 at the frequency of 1 Hz.

Module 2: Calibration parameter (read/ write register)

Offset	Parameter	Data type	Description	Read register
Weight calibration				
0	Weight ZERO calibration	DWord	Read absolute millivolts	
4	Weight gain calibration	DWord	Read relative millivolts	
No weight calibration				
8	No weight ZERO calibration	DWord	Read Zero calibration millivolt	
12	No weight gain calibration voltage value	DWord	Read gain calibration millivolt	
16	No weight gain calibration weight	DWord	Read gain calibration weight	
Theoretical value calibration				
20	Load cell sensitivity	DWord	Load cell sensitivity	
24	Load cell full range	DWord	Load cell full range	
28	Weight correction	DWord	used to correct the weight	

	factor		value factor	
Weight calibration				Write register
0	Weight ZERO calibration	DWord	Write 1 to automatically calibrate zero	
4	Weight gain calibration	DWord	Enter weight value	
No weight calibration				
8	No weight ZERO calibration	DWord	write Zero calibration millivolt	
12	No weight gain calibration voltage value	DWord	write gain calibration millivolt	
16	No weight gain calibration weight	DWord	write gain calibration weight	
Theoretical value calibration				
20	Load cell sensitivity	DWord	Write load cell sensitivity	
24	Load cell full range	DWord	Write load cell full range	

28	Weight correction factor	DWord	used to correct the weight value factor
Function operation			
32	Function operation	Byte4	D4-D7 reserved
			D3: GS/NT
			D2: Clear tare
			D1: Tare
			D0: zero
		Byte3	D7: Reset IO
			D6: Reset All
			D5: Reset Calibration
			D4: Reset All
			D0~ D3 reserved
		Byte2	D0-D7 reserved
		Byte1	D0-D7 reserved

Module 3: Parameters revise (read/ write register)

Custom read				Read register
0	Read out value	DWord	The master station requests the data returned by the meter, the value obtained according to the "request read address".	
4	Write status	Word	Write data return status 0: no error 1: register address illegal 2: parameter error	
6	Read status	Word	Read data return status 0: no error 1: register address illegal 2: parameter error	
Custom write				Write register
0	The request to write value of the modbus address	DWord	Write value address.	
4	Input value	DWord	Input value to the request to write value of the modbus address	

8	The read request of the modbus address	DWord	Read address	
---	--	-------	--------------	--

6.1.1.2 GSD2

Offset	Parameter	Data type	Description
Weight, millivolt and state parameters (Read Only, address)			
0	Weight display	DInt	Current display weight, integer INPUT[0] : indicates The highest byte of the current weight value INPUT[1] : The second highest byte of the current weight value. Input [1] : The second highest byte of the current weight value INPUT[2] :The sub lowest byte of the current weight value. Input [1] : The sub lowest byte of the current weight value INPUT[3]:The lowest byte of the current weight value. Input [2] : The lowest byte of the current weight value

4	Weight status marker	Byte	D7: If F1.11 for 0 tare alarm display, ERROR6 alarm state (when taring, current weight unstable):0 invalid, 1 valid; If F1.11 is displayed as 1 heartbeat packet, it switches between 0 and 1 at 1HZ frequency
			D6: ERROR3 alarm state (when taring, current weight unstable) : 0 invalid, 1 valid
			D5: ERROR2 alarm state (when zeroing, current weight over zeroing range) : 0 invalid, 1 valid
			D4: Gross/Net (0 Gross; 1Net)
			D3: Weight marker, 0 positive, 1 negative
			D2: ZERO, 0 Non zero, 1ZERO
			D1: weight display overflow state, 0 normal, 1 OFL
			D0: Weight stable marker, 0 :STAB, 1:

			UnSTAB
5	Load cell millivolt	Dint	4 bytes sensor millivolt data, read absolute millivolt INPUT[5]:The highest byte of the current millivolt INPUT[6]:The second highest byte of the current millivolt. INPUT[7]:The sub lowest byte of the current millivolt INPUT[8]:The lowest byte of the current millivolt.
Function operate (write only, address)			
0	function parameter	Byte	D3-D7 reserved
			D2: clear tare (1 valid)
			D1: tare (1 valid)
			D0: zero (1 valid)

PN non-cyclic parameters list

Parameters	Description
------------	-------------

Power-Up Zero ON/OFF	range: 0-1, 0: OFF 1: ON; initial value: 0
Zero track range	range: 0-9; initial value: 0
Stable range	range: 0-9; initial value: 1
Zero range	range: 0-99; initial value: 50
Digital Filter	range: 0-9; initial value: 5
Defibrillate Filter Level	range: 0-9; initial value: 0
Decimal Point	range: 0-4; initial value: 0
Resolution	range: 1,2,5,10,20,50; initial value: 1
Full Scale	range: 1-Resolution*1000000; initial value: 10000
Zeroing/tare password protect ON/OFF	range: 0-1, 0: OFF 1: ON; initial value: 1

6.1.2modbus read write operate address sheet

Register address	Means	Description	Read/write
0000-0001	Current absolute	Read current absolute millivolts	Read Only

	millivolts		
0002-0003	ZERO calibration millivolts	Read ZERO calibration millivolts	
0004-0005	Current relative ZERO millivolts	Read current relative ZERO millivolts	
0006-0007	gain calibration millivolts	Read gain calibration millivolts	
0008-0009	gain calibration weight	Read gain calibration weight	
0010-0011	load cell sensitivity	Read load cell sensitivity	
0012-0013	load cell full range	Read load cell full range	
0014-0015	Weight Correction coefficient	Read weight Correction coefficient	
0016-0017	Transmit weight state data to PN	D4 to D15: reserved D3: tare weight UnSTAB D2: Zeroing UnSTAB D1: zeroing over range D0: net/gross weight	Read Only

0018 ~ 0019	reserved		
0020	Power-Up Zero ON/OFF	Power-Up Zero ON/OFF (0: OFF; 1: ON)	read /write (Note: remote edit ON/OFF when I can write)
0021	Zeroing range	ZERO track range (0-99d)	
0022	ZERO track range	Stable range (0-9d)	
0023	Stable range	Zeroing range(0-9d)	
0024	Digital Filter	digital filter parameter (0-9)	
0025	Defibrillate Filter Level	defibrillate filter parameter (0-9)	
0026	AD sample frequency	AD sample frequency: 0:30time/s 1:60time/s 2:120time/s 3:240 time/s 4:480time/s 5:960time/s	
0027	communication light ON/OFF	NET light ON/OFF; 0: NET/gross; 1: communication indicate	Read Only
0028	remote edit ON/OFF	When turn ON, The parameters can be set through the	

		communication port. Otherwise Read Only.	
0029	remote calibration ON/OFF	When turn ON, Calibration parameters can be set through the communication port. Otherwise Read Only.	Read/write (Note: remote edit ON/OFF when 1 can write)
0030	Decimal Point	Decimal Point address (0:0byte; 1:1byte; 2:2byte; 3:3byte; 4:4byte)	Read/write (Note: remote calibration ON/OFF when 1 can write)
0031	Division value	Resolution value(1/2/5/10/20/50)	
0032-0033	Full Scale	write range (Full Scale≤Resolution×1000000)	
0034 ~ 0039	reserved		
0040	File type	For PN communication: 1:GSD1(standard); 2:GSD2(compact). For EIP communication:	Read/write

		0: NULL; 1: EDS1(standard); 2: EDS2(compact)	
0041	Shift ON/OFF	PN communication weight state byte No.7 byte heart beat and tare alarm unstable shift ON/OFF 0: tare alarm display 1: heart beat display	
0041 ~ 0049	reserved		
0050	Set Point1 if stable	0: No; 1: Yes	Read/write (Note: remote edit ON/OFF when 1 Can write)
0051	Set Point1 mini duration time	0-999:0-99.9s	
0052	Set Point1 valid condition		
0053-0054	Set Point1 value1		
0055-0056	Set Point1 value2		
0057	Set Point2 if stable	0: No; 1: Yes	
0058	Set Point2 mini duration time	0-999:0-99.9s	

0059	Set Point2 valid condition		
0060-0061	Set Point2 value1		
0062-0063	Set Point2 value2		
0064	Set Point3 if stable	0: No; 1: Yes	
0065	Set Point3 mini duration time	0-999:0-99.9s	
0066	Set Point3 valid condition		
0067-0068	Set Point3 value1		
0069-0070	Set Point3 value2		
0071	Set Point4 if stable	0: No; 1: Yes	
0072	Set Point4 mini duration time	0-999:0-99.9s	
0073	Set Point4 valid condition		
0074-0075	Set Point4 value1		
0076-0077	Set Point4 value2		
0078	IO output1	I/O module output define	
0079	IO output2	I/O module output define	

0080	IO input1	I/O module input define	
0081~ 0089	reserved		
0090	IP1	Ethernet IP address (Note: PN mode do not support modify; only in EIP mode support modify, valid only after modify need re-power up)	Read/write
0091	IP2		
0092	IP3		
0093	IP4		
0093 ~ 8999	reserved		


6.1.3 Device Description file GSD

GMT-P1 description file and connection method can download at www.gmweighing.com


6.1.4 Profinet master configuration GMT-P1

Taking Siemens 1200 as the master station as an example, GMT-P1 is briefly configured as the slave station.


- 1) Open the Botu management software and create a new project





- 2) Click "Add New Device" on the left and select "Controller" to select the model to use the corresponding PLC




- 3) Double-click the PLC device in the left "Local Module", and select " Manage general station description files (GSD)" from the menu bar.







- 5) Set the IP address and name. In the device view, double-click the PLC module/double-click the network port to Settings




Under the device view, double-click the PLC mode/
double click the Ethernet

Choose Ethernet address

Full in the IP address assigned to PLC, after the assignment, the IP address of the indicator will automatically be in the same network segment with PLC.

Add the name assigned to indicator PS, the device name, not the IP address, is the most unique identifier of the PROFINET device.


6) Assign device names. Device view as below, right-click and select assign device Name.



- 7) Configure indicator parameters and operate them. In the Device view, click "Ungrouped Device → Parameter Modify Interface _1 → Property" on the left.


Note:

- ✧ The remote calibration ON/OFF is required to be ON to modify the calibration parameters.
- ✧ After modifying the parameters, need to recompile and download to PLC, the parameters take effect.



- 8) IO loop data operation. In the device view, view the IO address assigned to the module by the PLC. Assign I address and Q address according to IO status table. Modify

corresponding parameter values by monitoring table.



After assigning the addresses needed to view and operate, go online, and then click "Monitor" to see the changes in these values.

Name	Data type	Address	Retain	Access...	Write...	Visible...	Monitor value
present weight	DInt	%ID68	☐	☒	☒	☒	-4970
weight status	UDInt	%ID72	☐	☒	☒	☒	9
Gross	DInt	%ID76	☐	☒	☒	☒	-4970
Net	DInt	%ID80	☐	☒	☒	☒	-4970
Tare	DInt	%ID84	☐	☒	☒	☒	0
COMHeartbeat	ULint	%IW104	☐	☒	☒	☒	1
LC mVIV	UDInt	%ID128	☐	☒	☒	☒	20000
LC Capacity	UDInt	%ID132	☐	☒	☒	☒	100000
<Add new>			☐	☒	☒	☒	

Click here to add tag

Here is the name assigned to each table in the PN protocol address table.

- 9) Compile, download and online. After downloading, switch to online, open the monitoring table, you can view and modify the parameters of the indicator.

Siemens - C:\Users\jgin\Desktop\GMT-P1\PROFINET\GMT-P1\GMT-P1

Project Edit View Insert Online Options Tools **Click compile** Window Help

Save project Go online Go offline <Search in project>

Project tree GMT-P1 > PLC_1 [CPU 1214C DC/DC]

Click download

PLC_1 [CPU 1214C]

Devices & networks

- GMT-P1
 - Add new device
 - Devices & networks
 - PLC_1 [CPU 1214C DC/DC...]
 - Device configuration
 - Online & diagnostics
 - Program blocks
 - Technology objects
 - External source files
 - PLC tags
 - Show all tags
 - Add new tag table
 - Default tag table [26]
 - PLC data types
 - Watch and force tables
 - Add new watch table
 - Force table
 - Online backups
 - Device proxy data
 - Program info
 - PLC alarm text lists

Rack_0

	103	102	101	1	2	3	4	5	6
									

Click PLC or other device, the compiler button will turn from dark to bright

6.2 Ethernet-IP communication

You can set and view the **IP** address of the indicator in the second major item of the parameter. After setting, it will take effect only after re-powering. You can also view the **MAC** address.

6.2.1 IO status

GMT-P1 provides multi-byte **IO**, through these I/O enable the master station to read and control the status of the weighing display

6.2.1.1 EDS1

Module 1: weight, calibration and status parameters (read register)

Offset	Parameter	Data type	Description
0	Weight display	DInt	Current display weight, integer
2	Weight status marker	Duint	D4-D31 Reserved
			D3: Weight marker
			D2: ZERO, (weight is in 0+/-1/4d range)
			D1: Weight overflows marker
			D0: Weight stable marker
4	Gross weight	DInt	Gross weight (signal integer)

6	Net weight	DInt	Net weight (signal integer)
8	Tare weight	DInt	Tare weight (signal integer)
10	Current weight	Float	Current weight, floating-point type
12	Gross weight	Float	Gross weight, floating-point type
14	Net weight	Float	Net weight, floating-point type
16	Tare weight	Float	Tare weight, floating-point type
18	Preset point status area	Word	D4-D15 Reserved
			D3: Preset point 4 status area
			D2: Preset point 3 status area
			D1: Preset point 2 status area
			D0: Preset point 1 status area
19	Heartbeat communication	Word	The communication light flashes at 1 Hz, and the communication heartbeat switches between 0 and 1 at 1 Hz
Weight calibration			
20	weight zero calibration	DWord	Read absolute millivolts
22	weight gain calibration	DWord	Read relative millivolts
No weight calibration			

24	No weight zero calibration	DWord	Read zero calibration millivolt
26	No weight gain calibration voltage value	DWord	Read gain calibration voltage value
28	No weight gain calibration weight value	DWord	Read gain calibration weight
Theoretical value calibration			
30	Load cell sensitivity	DWord	load cell sensitivity
32	Load cell full range	DWord	load cell full range
34	Weight correction factor	DWord	used to correct the weight value factor
Self-defined read			
36	Modbus read value	DWord	The master station requests the data returned by the meter, the value obtained according to the "request read address".
38	Modbus write status	Word	Write data return status , 0: no error 1: register address illegal 2: parameter error
39	Modbus read status	Word	Read data return status 0: no error 1: register address illegal 2: parameter error

Module 2: calibration and operation parameters (write register)

Weight calibration			
0	Weight ZERO calibration	DWord	Write 1 auto zeroing
2	Weight gain calibration	DWord	Write weight value
No weight calibration			
4	No weight ZERO calibration	DWord	Write Zero millivolt
6	No weight gain calibration voltage value	DWord	Write gain millivolt
8	No weight gain calibration weight	DWord	Write gain weight
Theoretical value calibration			
10	Load cell sensitivity	DWord	Write load cell sensitivity
12	Load cell full range	DWord	Write load cell full range
14	Weight correction factor	DWord	used to correct the weight value factor
Function operation			
16	Function operation	Duint	D15: I/O module reset
			D14: Parameter reset

			D13: Calibration reset
			D12: Reset all
			D4-D11: Reserved
			D3: GS/NT
			D2: Clear tare
			D1: Clear Tare
			D0: Zero
18	The request to write value of the modbus address	DWord	Write value address, refer to section 6.1.2 modbus address sheet .
20	Input value	DWord	Input value to the request to write value of the modbus address, refer to section 6.1.2 modbus address sheet .
22	The read request of the modbus address	DWord	Read address, refer to section 6.1.2 modbus address sheet .

6.2.1.2 EDS2

EIP cycle parameter list

offset	Parameter	Data type	Description
0	Weight display	DInt	Current display weight, integer

2	Weight status marker (Read Only)	Duint	D4-D31: Reserved
			D03: Weight marker
			D02: ZERO, (weight is in 0+/-1/4d range)
			D01: Weight overflows bit
			D00: Weight stable marker: 0:STAB,1:UnSTAB
4	absolute millivolts (Read Only)	DWord	Read absolute millivolts
6	read value	DWord	Get the value by writing the address to read
8	Write status	Word	Write the returned status of data. 0: no error. 1: Register address is invalid 2: data error
9	Communication heartbeat	Word	After the connection is established, the value of the communication heart beat is converted from 0 to 1 at the frequency of 1 Hz
function operate			
0	Function parameter	Duint	D15: I/O module reset

	(can write)		D14: Parameter reset
			D13: Calibration reset
			D12: All reset
			D4-D11 reserved
			D3: Gross/net
			D2: Clear tare
			D1: Ttare
			D0: Zeroing
2	The request to write value of the modbus address	DWord	Write value address, refer to section 6.1.2 modbus address sheet .
4	Input value	DWord	Input value to the request to write value of the modbus address, refer to section 6.1.2 modbus address sheet .
6	The read request of the modbus address	DWord	Read address, refer to section 6.1.2 modbus address sheet .

EIP Non-cyclic parameters list

Parameters		Description
Power-Up Zero ON/OFF		range: 0-1; initial value: 0; 0: OFF; 1: ON
Zero-tracking Range		range: 0-9; initial value: 0

Stable range	range: 0-9; initial value: 1
Zeroing range	range: 0-99; initial value: 50
Digital Filter	range: 0-9; initial value: 5
Defibrillate Filter Level	range: 0-9; initial value: 0
Decimal Point	range: 0-4; initial value: 0
Resolution value	range: 1,2,5,10,20,50; initial value: 1
Full Scale	range: 1-Resolution*1000000; initial value: 10000

6.2.2 Device description file EDS

GMT-P1 device description file and connection method can down load at www.gmweighing.com

6.3 EtherCAT Communication

GMT-P1 has two bus connection ports: **Port1** and **Port 2**, with **Port1** as the entry when **EtherCAT** is connected. Any computer with a network interface card and embedded devices with Ethernet control can be used as a master station for **EtherCAT**, such as devices such as Huichuan PLC. The instrument can also be connected via **Twincat** software on a PC computer, in any case within the same local area network as the instrument. The following parameter table can be operated if the connection is successful.

6.3.1 Compact Version Parameter address

6.3.1.1 Circular Parameter List

Data Types	Parameter names	Parameter Description
REAL	Current weight (Read only)	Weight currently displayed, single precision floating point type
DINT	Weight status bit (Read only)	D9-D31: Reserved D8: Communication heartbeat The communication light blinks at 1HZ and the communication heartbeat switches between 0 and 1 at 1 Hz D7: ERROR6 alarm status (when peeling, the current weight display is unstable) D6: ERROR3 alarm status (when clearing, the current weight is not stable) D5: ERROR2 alarm status (when clearing, the current weight is out of the clearing range) D4: Gross/net weight D3: Weight symbol bit D2: Zero point (weight in the range of 0+/- quarter d) D1: overflow state (abnormal weight or sensor)

		D0: Weight stability marker
DINT	Sensor millivolts (Read only)	4 bytes of sensor millivolts data
DINT	Read out values (read only)	The master station requests the data returned by the meter, and obtains the value according to the "address requested to read".
DINT	Functional operation (writable only)	D15: IO reset D14: Parameter reset D13: Calibration reset D12: Reset all D4-D11: Hold D3: Gross net weight switch D2: Skin clearing D1: Remove the skin D0: Zero
DWord	The request to write value of the modbus address	Write value address, refer to section 6.1.2 modbus address sheet .
DWord	Input value	Input value to the request to write value of the modbus address, refer to section 6.1.2 modbus address sheet .

UDINT	The read request of the modbus address	Read address, refer to section 6.1.2 modbus address sheet .
--------------	--	---

6.3.1.2 Acyclic Parameter list

Parameter Names	Parameter Description
Other parameters refer to section 6.2.1.2 EIP Non-cyclic parameters list .	
AD Sampling Rate	Range: 0-5 Initial value: 2
NET indicator function switch	Range: 0-1 Initial value: 0
Remote calibration switch	Range: 0-1 Initial value: 0

6.3.2 Device description file ESI

The GMT-P1 equipment description file and the **detailed steps for using PLC and Twincat** can download at www.gmweighing.com

6.4 CCLINK IE Communication

When CCLink IE Field Basic is selected for extended communication, it can communicate with PLC. At this time, the instrument IP, PC and PLC must be in the same LAN. The instrument IP address can be set and viewed in SETUP working parameters F2.1~F2.4; the MAC address

can be viewed in F2.5~F2.10. After the project connection is successfully established, the parameters can be configured according to the following parameter addresses

This instrument occupies one link station, and each link point can reach up to 4K words. It can be applied to small-scale equipment that does not require high-speed control. CC-Link IE cyclic communication is realized by software, and the communication speed reaches 100Mbps.

6.4.1 Compact Version Parameter address

Offset	Parameter	Data type	Description
Weight and status parameters (read register, I address)			
RWr0- RWr1	Currently show weight	DWord	Weight currently displayed, 999999, -9999999 when positive and negative overflow
RWr2- RWr3	Weight status flag bit	Word	D4 to D15: Reserved
			D3: Displayed weight symbol, (1 shows the weight is negative)
			D2: Zero, (weight in the range of 0+/- quarter d)
			D1: Weight overflow flag position
			D0: Stable

RWr4- RWr5	Loadcell voltage value data	DWord	Signed numbers, integers, four decimal points
RWr6- RWr7	Read out value	DWord	The master station requests the data returned by the meter, the value obtained according to the "address requested to read"
RWr8- RWr9	Write the status of modbus	DWord	Write data Return status 0: No error 1: register address illegal 2: parameter error
RWr10- RWr11	Communication heartbeat	DWord	After the connection is established, the value of the communication heartbeat switches between 0 and 1 at a frequency of 1 Hz
Function operation parameters (write register, Q address)			
RY0	Function operation	DWord	D15: IO module reset
RY1			D14: parameter reset
RY2			D13: Calibration reset
RY3			D12: Reset all
RY4- RYB			D4~D11: reserved

RYC			D3: Gross/net weight switch
RYD			D2: Clear tare
RYE			D1: Tare
RYF			D0: Zero
RWw0- RWw1	Request written value modbus address	DWord	Write operation address for Modbus, refer to 6.1.2 Register Read/Write Operation Address table
RWw2- RWw3	Input data	DWord	Modbus write operation value, write this data to "modbus address of the value requested to write", refer to 6.1.2 Register Read/Write operation address table
RWw4- RWw5	Address of the request to read	DWord	Read operation address for Modbus, refer to 6.1.2 Register Read and Write Operation Address table

6.4.2 Acyclic parameter lists

CCLink IE Field Basic **non-cyclic parameters list**

Parameters	Description
Power-Up Zero ON/OFF	range: 0-1, 0: OFF 1: ON; initial value: 0
Zero track range	range: 0-9; initial value: 0
Stable range	range: 0-9; initial value: 1
Zero range	range: 0-99; initial value: 50
Digital Filter	range: 0-9; initial value: 5
Defibrillate Filter Level	range: 0-9; initial value: 0
Decimal Point	range: 0-4; initial value: 0
Resolution	range: 1,2,5,10,20,50; initial value: 1
Full Scale	range: 1-Resolution*1000000; initial value: 10000
Zeroing/tare password protect	range: 0-1, 0: OFF 1: ON; initial value: 1

ON/OFF	
--------	--

6.4.3 Device Description File CSP

The device description file and connection method of GMT-P1 can be downloaded from the website of Shenzhen German Technology Co., Ltd. (www.szgmt.com)

7 Password Input and Setting Reset

7.1 Password Input


- (1) Calibration and working parameters setting default password: **000000**.
- (2) User can set password in parameters when **F3.1** is "ON".
- (3) When display is "PASS", need to input correct password to enter parameters.

Note:

- (1) When input password, if first time wrong, it will go to the second chance for password input(display from **0 - - - - -** turn to **0 _ _ _ _ _**).
- (2) If second input wrong, it will enter into interface for inputting password the third time. (1)
When input password wrong, it will enter into interface for inputting password the third time
(Display change from **0 _ _ _ _ _** to **0 _ _ _ _ _**).
- (3) If Input wrong for three times, main display show "**Error4**" and self-lock, but user can operate when power on again.

7.2 Password Setting

- (1) User can set password in parameters when **F3.1** is "ON".
- (2) User must input same new password twice in setting password,If not same, if not same, main display show"**Error**",one second and return to **PASS** again.




7.3 Factory Reset

Note: Factory reset is only for special technicians, which will reset all of parameters and

will maybe cause not working.

Note: In all reset interfaces, press $\frac{\text{ZERO}}{\text{ESC}}$ to exit and return to weighing interface.



Take reset all for 'e':

Press **MODE** and $\frac{\text{W/A}}{\text{ENTER}}$ the same time to display 'PASS', then password input.

Password input interface, input fixed password **880202**, then press $\frac{\text{W/A}}{\text{ENTER}}$ save password and enter parameter reset.

1) In **F SEt** interface, press to reset working parameters, enter into reset calibration parameters interface.

2) In **F SEt** interface, press **MODE**, not to make working parameter reset, enter into calibration para. Reset interface.


1) In **F CAL** interface, press $\frac{\text{W/A}}{\text{ENTER}}$ to reset calibration para., enter into reset all interface.

2) In **F CAL** interface, press **MODE**, not to make calibration para. reset, enter into reset all interface.

1) In **F ALL** interface, press $\frac{\text{W/A}}{\text{ENTER}}$ to make reset all of the parameters (including working para., calibration para., I/O etc...)

8 Display Testing

The following flow chart is to test lights on main-display and status lights.



9 Errors and Alarm Messages

Error ① Input error.

② wrong data beyond parameter range.

Error2 The current weight value is out of zeroing range.

Error3 Current weight is not stable when zeroing.

Error4 Input wrong password more than 3 times.

Error5 Overlimit when tare.

Error6 Weight value is not stable when tare.

Error7 Calibration lock defined, wait for this signal to be valid

OFL Weighing value is positive overflow.

-OFL Weighing value is negative overflow.

10. Indicator model user-defined function

You can customize the model content displayed on the instrument by performing relevant operations on the instrument,. The steps are as follows.

After powering on, flash 8 twice, and then display the model. After displaying the model for 3 seconds, enter the menu interface. Long press the MODE key to display the "LOGO" in the menu interface,. You can customize the 6-digit main display character, and use the MODE key to adjust and select a certain character.After saving the changes, the instrument will display the changed model when booting up; If no modifications are made to the instrument model, the instrument will default to GMT-P1 (note: resetting does not reset the instrument model)

Displays character comparison table

a	b	c	d	e	f	g	h	i	j	k	l	m
A	b	C	d	E	F	G	H	I	J	K	L	M
n	o	p	q	r	s	t	u	v	w	x	y	z
n	o	P	q	r	S	t	U	v	w	x	y	z

11 Dimension of Indicator

