



杰 • 曼 • 科 • 技

GMC-X1LF

Communication

Manual

110612010004
V01.10.10_01

Directory


Chapter 1 Communication Connection	- 1 -
1.1 Serial Port Connection	- 1 -
1.1.1 Troubleshooting Serial Port Faults	- 1 -
1.2 Network Port Connection	- 2 -
1.2.1 Network port troubleshooting.....	- 2 -
Chapter 2 Data-Trans	- 3 -
2.1 Data-Trans parameter	- 3 -
2.2 Network Port Communication Parameters	- 4 -
2.2.1 Parameter Description	- 4 -
2.3 Communicate the floating-point switch	- 4 -
2.4 Print Edit	- 5 -
2.5 Communication Set Password and reset	- 5 -
Chapter 3 Communication Protocol and Address	- 6 -
3.1 Modbus Protocol	- 6 -
3.1.1 Function code and Exception code Description	- 6 -
3.1.2 Transmission mode.....	- 6 -
3.1.3 Modbus Communication Address Table.....	- 6 -
3.2 Cont-A (continuous send -CB920)	- 21 -
3.3 Cont-B (Continuous transmission -tt)	- 22 -
3.4 r-Cont	- 22 -
3.5 rE-Cont	- 23 -
3.6 YH(Protocol)	- 24 -
3.7 PROFINET Communication	- 24 -
3.7.1 I/O Status	- 24 -
3.7.2 Device Description file GSD.....	- 31 -
3.8 EtherNet-IP Communication	- 31 -
3.8.1 I/O Status	- 31 -
3.8.2 Device description file EDS	- 36 -
3.9 EtherCAT Communication	- 37 -
3.9.1 Bus Settings.....	- 37 -
3.9.2 Cyclic parameter address.....	- 37 -
3.9.3 Acyclic parameter addresses.....	- 42 -
3.9.4 Device description file ESI.....	- 42 -

Chapter 1 Communication Connection


1.1 Serial Port Connection

GMC-X1LF instrument is equipped with 2 serial ports as standard: 1 RS485 port, 1 RS232/485 serial port (software parameter selection).


COM0: Instrument standard serial port.




COM1: Instrument standard serial port, RS485/RS232 mode is optional (serial port mode is selected in serial port parameters)



RS232 connection mode:



RS485 connection mode:



※ In **RS485** mode, **GND** is the signal ground. In the case of serious interference, low resistance wires should be used to connect the signal ground, so that the ground potential of each node is equal, which can significantly improve the communication quality.

※ The **GND** must be connected in **RS232** mode.

1.1.1 Troubleshooting Serial Port Faults

If the serial port is not communicating, check:

- Click the figure above to check the wirings connection. Make sure the wiring is correct.

The **RS232** interface must be connected to **all three wires, Rx, Tx, GND**.

The **RS485** interface must be connected to **A and B** wires.

- Make sure connecting port parameters are the same to computer.

Slave number, baud rate, data format and communication protocol must be consistent with the host computer and PLC.


1.2 Network Port Connection

GMC-X1LF products support ordinary network port communication and bus communication (bus communication is an optional function, order need to declare). Support **TCP** protocol (**Modbus/TCP**, **Cont-A/TCP**, **Cont-B/TCP**, **r-Cont/TCP**, **rE-Cont/TCP**, **YH/TCP**) and **EIP/PN/EtherCat** bus protocol.

1) Dual network port option, network port built-in switch, easy to cascade, support **TCP** protocol.

2) When PN/EIP communication, it can connect to any network port of the instrument for communication.

3) When communicating with Ethernet CAT, Net2 serves as the entry point. When connecting to multiple devices, the devices must be connected in series to distinguish the order of entry and exit. For specific parameter settings, please refer to the communication manual of EtherCAT Communication.



1.2.1 Network port troubleshooting

If the network port is not communicating, check:

- Check network port indicators.

The hardware connection is normal, and the internal indicator of the instrument is steady on.

The network wiring is properly connected and the connection indicator is blinking.


- Check whether the communication protocol is consistent with that of the host computer and **PLC**.

○ Confirm that **GMC-X1LF** can be pinged by the network. If not, check the hardware interface section.

- Check whether **IP** conflicts exist.
- Restart the instrument.

Chapter 2 Data-Trans

GMC-X1LF has rich communication function interface: **1 RS485** (serial port **0**), **1** RS232/485 (serial port **1**), **1** network port communication interface (support **TCP**, **PN/IEP** **EtherCAT** bus function).



2.1 Data-Trans parameter

GMC-X1LF instrument provides standard configuration of **1 RS485** (serial port **0**), **1** RS232/485 (serial port **1**), two serial port parameters as follows:

Parameters	Initial value	Instructions
COM0/COM1 ID	01	Range: 01-99
Baudrate	38400	Range: 1200,2400,4800,9600,19200,38400,57600,115200
Protocol	Modbus RTU	Range: Modbus RTU, Modbus ASCII, Cont-A (continuous transmit-CB920), Cont-B (continuous transmit-TT), r-Cont, rE-Cont, YH(protocol), Print(print)
Data Format	8-E-1	Range: 8-N-1, 8-e-1, 8-o-1, 7-e-1, 7-o-1 (Note: Only 8-bit data bits are supported when modbus protocol)
DwordFormat	AB-CD	Range: AB-CD (high word in front), CD-AB (low word in front)
Send Gap	20ms	The time interval between frames under the continuous send protocol. The value ranges from 0 to 1000ms . Default: 20ms
RS485/RS232	485 mode	Range: 485 mode, 232 mode optional. ※ This parameter is available only under COM1

2.2 Network Port Communication Parameters

2.2.1 Parameter Description

Parameters	Initial value	Instructions
Protocol	Modbus/TCP	When selecting a common network port, the protocols are: Modbus/TCP, Cont-A/TCP, Cont-B/TCP, r-Cont/TCP, rE-Cont/TCP, YH/TCP , Default: Modbus/TCP
DwordFormat	AB-CD	Range: AB-CD (high byte in front), CD-AB (low byte in front); This parameter is visible when Modbus/TCP PN/EIP/EtherCat is selected to send.
Send interval	20ms	Range: 0-1000ms; When the communication mode is Cont-A/TCP, Parameters are visible when Cont-B/TCP, r-Cont/TCP, rE-Cont/TCP, YH/TCP , and are used to control the time interval between frames.
IP Config	192.168.0.100	Range of each IP segment: 0 to 255 ; This parameter is available for network port communication and PN/EIP communication.
Socket	502	Range: 1-65535 ; This parameter is available for network port communication and PN/EIP communication.
Write Enable	Disable	Range: Disable, Enable; (This parameter is visible when selecting PN/EIP attachment board) Enable: When PN/EIP communication, the instrument parameters are controlled by the "module parameters" in the master station configuration, and the parameters set in the "module parameters" are automatically written to the instrument when the instrument is powered on. Disable : When PN/EIP communication, instrument parameters are not controlled by "module parameters" of the master station.
GSD Type	Standard	If the option is PN bus, this parameter can be seen. Standard /Simple is optional

2.3 Communicate the floating-point switch

Parameters	Initial value	Instructions
Float Data SW	Disable	When turned on, the corresponding parameter will become a floating point number read and write type (serial and network port communication)

2.4 Print Edit

When the serial port parameter is selected as "**Print**", when input print signal, the instrument data can be printed.

Parameter		Initial value	Instructions
HeaderLines		1	Choose how many header lines to use, Range: 0 to 4
EndLines		1	Choose how many tailer lines to use, Range: 0 to 4
Ticket Gap		2	The number of lines between each print, Range: 0 to 99
Content		Display weight	Optional: DisplayWt, Gross Wt, Net Wt,, Net+Tare (two lines), All Info. (Gross weight + Net weight + Tare) (print includes units)
Print Lang		English	Chinese/English
Header Edit	HeaderLines1	-----	Header information line, 16 English characters can be edited
	HeaderLines2	-----	
	HeaderLines3	-----	
	HeaderLines4	-----	
Ender Edit	EnderLines1	-----	Tailer Information line, 16 English characters can be edited
	EnderLines2	-----	
	EnderLines3	-----	
	EnderLines4	-----	

Example of print format applications:

Parameter setting		Print Content (English)
Header Lines	2	-----
EnderLines	1	-----TEST-----
Ticket Gap	3	No. Xxxxxxxx1
Content	Display weight	Display weight
Print Lang	Chinese	NT -X.XXXX kg
HeaderLine1	-----	-----END1-----
HeaderLine 2	-----TEST-----	
EnderLine 1	-----END1-----	
		----- (Print 2rd)

2.5 Communication Set Password and reset

PWD.&Reset		
COM Reset	//	Restore communication parameters to factory Settings.
Remote Edit	Enable	After turn on, the formula parameters can be set through the communication port. Otherwise, the communication port is read-only to the basic parameters.
PWD. Protect	Disable	Range: Enable, Disable; Password is required to enter the Modify parameter setting option after it is on.
PWD. Edit	000000	modify the password. The password must be 6 characters.

Chapter 3 Communication Protocol and Address

3.1 Modbus Protocol

3.1.1 Function code and Exception code Description

The function code supported by the instrument

Function code	Name	Instructions
03	Read register	Read up to 125 registers at a time
06	Write single register	
16	Write multiple registers	This instrument command only supports writing double registers, the address must be aligned when writing, only a part of the double register is not allowed to be written, and read part is allowed when reading.
01	Read Coil	Note that this length is in bits.
05	Write Coil	

Note: This instrument only supports the above **MODBUS** function codes, the instrument will not respond when sending other function codes to the instrument.

Exception Code response

Code	Name	Meaning
02	Illegal data address	For this instrument, this error code indicates that the received data address is an disallowed address.
03	Illegal data value	The data written is not within the allowed range.
04	Slave machine failure	An unrecoverable error occurs when the instrument is attempting to perform the requested operation.
07	Unsuccessful programming request	For the instrument, the command received cannot be executed under the current conditions.

3.1.2 Transmission mode

RTU mode

(1) When communicating in **RTU** mode, every **8** bits (**1** byte) in the message is divided into two **4-bit hexadecimal** characters.

(2) The end of a frame must be more than 3.5 characters apart. **For a more reliable end, it is recommended to use an interval of more than 4.0 characters.**

The specific protocol is as follows:

Supported data formats: 8-bit data bit, 1-bit stop bit, parity check (**8-E-1**)

8-bit data bit, 1-Stop Bit, Odd check (**8-O-1**)

8-bit Data bits, 1-Stop Bit, no check (**8-N-1**)

Code: Binary

3.1.3 Modbus Communication Address Table

PLC address	Display address	Meaning	Instructions
Weight status information parameters			
40001-40002	0000-0001	Current weight value (4 bytes signed integer) (when communication floating-point switch is turned on, displayed floating-point number)	

40003-40004	0002-0003	Decrement mode: The weight of using the decrement method Other modes : reserved		
40005	0004	Weight status flag bit	Bit	Instructions
			D13-15	reserve
			D12	Bipolar
			D11	Calculate weight by using theoretical value
			D10	ADC Failure
			D9	Current display net weight
			D8	Millivolt stable
			D7	Loadcell negative overflow
			D6	Loadcell positive overflow
			D5	Weight negative overflow
			D4	Weight positive overflow
			D3	Overflow status
			D2	Display weight negative sign
			D1	Zero
			D0	Stable
40006	0005	Error Code 1	D13-15	Reserve
			D12	Perform Remote calibration when prohibited
			D11	In hardware protection during calibration
			D10	The previous weight point is not calibrated
			D9	Out of mini resolution
			D8	Weight input exceeds max range
			D7	The weight input cannot be zero
			D6	Weight calibration is less than zero or the previous calibration point
			D5	Loadcell positive overflow when Weight calibrating
			D4	Loadcell negative overflow when weight calibration
			D3	Weight calibration is unstable
			D2	Loadcell positive overflow when zero calibration
			D1	Loadcell negative overflow when zero calibration
			D0	Zero calibration is unstable

※ Indicates the weight status of the instrument, when it is the current state, the status bit shows "1".
If the current weight is zero and stable, the address **D0D1** status bit is "1"

40007	0006	Error Code 2	D15	Hold
			D14	Prohibit zero when running
			D13	Remote tare operation allow switch is not enabled during remote tare operation
			D12	Does not allow taring in net weight status
			D11	The weight is negative when taring
			D10	Loadcell positive overflow when taring
			D9	loadcell negative overflow when taring
			D8	Unstable when taring
			D7	Does not allow zeroing in net weight status
			D6	The remote zero switch is not enabled during remote zero
			D5	Loadcell positive overflows when zeroing
			D4	Loadcell negative overflow when zeroing
			D3	Unstable when zeroing
			D2	Zero out of range
			D1	Zero unstable when powered on
			D0	Power-on zero is out of range
40008-40010	0007-0009	Reserve		
40011	0010	Process status flag bit	D10-15	Reserve
			D9	IO test status
			D8	Printing, (valid when the instrument perform the print operation)
			D7	Reserve
			D6	Simulated operating condition
			D5	Pause
			D4	Slow Stop
			D3	Supply Material
			D2	Lack Material
			D1	Lower level
			D0	Upper level
40012	0011	Process status flag bit	D15	Wait for stop signal
			D14	Zero zone
			D13	0:Nozzle Up; 1: Nozzle Down
			D12	Push bucket
			D11	Normal feed bucket completed (valid after waiting, zero after starting filling bucket again)
			D10	Alarm
			D9	Weigh OK
			D8	Waiting

			D7	Under Replenish
			D6	Under
			D5	Over
			D4	Fine Feed
			D3	Medium Feed
			D2	Coarse Feed
			D1	Before Feed
			D0	0: Stop; 1: Run
40013	0012	Reserve		
40014	0013	Status Tips	0- No action; 1- Raise Bucket; 2- Wait for start signal; 3- Wait for lower material level; 4- Delay; 5- Coarse Feed; 6- Medium Feed; 7- Fine Feed; 8- Free Fall delay; 9- Free Fall correction; 10- Over/Under; 11- Under feed 12- Over/Under pause; 13- Raise nozzle; 14- Waiting; 15- Weigh OK; 16- Push bucket; 17- Wait stop; 18- Pause; 19- Batches complete	
40015	0014	Process alarm 1	D12 Batches Complete Alarm D11 Do not allow filling liquid (reduction scale, current weight below lower limit of material level, in supplying material state) D10 Material level parameters are not reasonable D9 Decrement protection D8 Leakage, when the coarse feed flow rate is lower than the lower limit of the coarse feed flow rate, the instrument default contain leakage, the instrument output buzzer alarm, the main interface prompts the leakage, and stops D7 Over/under Pause D6 Over/under D5 Tare detection error D4 Bump Bucket D3 OFL when starting	

			D2	Do not define the lower nozzle/raise nozzle function, use the step raise nozzle function
			D1	There is an undefined IO in the IO module that must be defined
			D0	The formula setting is not reasonable alarm
40016-40018	0015-0017	Reserve		
40019-40020	0018-0019	Gross weight value (4 bytes of signed integer)	Read only (floating-point numbers are displayed when the communication switch is turned on)	
40021-40022	0020-0021	Net weight value (4 bytes of signed integer)		
40023-40024	0022-0023	Tare(4 bytes signed integer)		
40025-40026	0024-0025	Reserve		
40027-40028	0026-0027	Display weight value (float point type)	Read Only	
40029-40030	0028-0029	Gross weight value (4 bytes signed float point number)		
40031-40032	0030-0031	Net weight value (4 bytes signed float point number)		
40033-40034	0032-0033	Tare (4 bytes signed float point number)		
40035-40036	0034-0035	Reserved		
40037-40038	0036-0037	Code inside AD after filtering	Read Only	
40039-40040	0038-0039	Loadcell voltage value		
40041-40042	0040-0041	Relative zero voltage value		
40043-40044	0042-0043	System cumulative weight (high 6 digits)		
40045-40046	0044-0045	System cumulative weight (low 9 digits)		
40047-40048	0046-0047	System cumulative frequency		
40049-40050	0048-0049	Cumulative weight(high 6 bit)		
40051-40052	0050-0051	Cumulative weight(low 9 bit)		
40053-40054	0052-0053	Cumulative Batches(high 6 bit)		
40055-40056	0052-0053	Cumulative Batches(low 9 bit)		
40057 ~ 40058	0054 ~ 0055	Waiting weight (previous weight)		
40059 ~ 40090	0056 ~ 0089	Reserve		

40091	0090	Input status Reserve, readable, read:all 0		
40092	0091	Input status area	Bit	Instructions
			D5- D15	Reserve
			D4	Input 5 status (extended Input 2)
			D3	Input 4 states (extended input 1)
			D2	Input 3 status
			D1	Input 2 status
			D0	Input 1 status
40093	0092	Output status reserve, readable, read out data as 0		
40094	0093	Output status area	Bit	Instructions
			D9-15	Reserve
			D8	Output 9 status (extended output 4)
			D7	Output 8 status (extended output 3)
			D6	Output 7 status (extended output 2)
			D5	Output 6 status (extended output 1)
			D4	Output 5 status
			D3	Output 4 status
			D2	Output 3 status
			D1	Output 2 status
			D0	Output 1 status
40095 ~ 40100	0094 ~ 0099	Reserve		
Basic parameters area, remote editing parameters set to read-write when enabled, otherwise read-only				
40101-40102	0100-0101	PWR-On Zero	0%-99% of the maximum range; Initial value: 0% (off)	
40103-40104	0102-0103	Remote Zero	Range: 0 (off), 1 (on); Initial value: 1 (on)	
40105-40106	0104-0105	Zero range	1%-99% of the maximum range; Initial value: 20%	
40107-40108	0106-0107	Remote Tare	Range: 0 (off), 1 (on); Initial value: 1 (on)	
40109-40110	0108-0109	Tare Record	Range: 0 (off), 1 (on); Initial value: 0 (off)	
40111-40112	0110-0111	NetSign COR	Range: 0 (off), 1 (correct tare), 2 (returned gross weight); Initial value: 0 (off)	
40113-40114	0112-0113	Basic tare	Write tare,read the current tare. Range: 0~full scale; Initial value: 0	
40115-40116	0114-0115	STAB Range	Range: 0-99, initial value: 1.	
40117-40118	0116-0117	STAB Timer	Range: 1-5000ms, initial value: 1000ms.	
40119-40120	0118-0119	TrZero Range	Range: 0-99, initial value: 1.	
40121-40122	0120-0121	TrZero Time	Range: 1-5000 milliseconds, Initial value: 1000	
40123-40124	0122-0123	Digit-Filter	Range: 0-9, initial value: 4	
40125-40126	0124-0125	Adv. Filter	Range: 0-99D, initial value: 0	
40127-40128	0126-0127	AD Sample Rate	Range: 0-9 (corresponds to 0-50; 1-60; 2-100; 3-120; 4-200; 5-240; 6-400; 7-480; 8-800; 9-960) Initial value: 200Hz	
40129-40130	0128-0129	Input range	Range: 0-5 (corresponds to 0:0-5mV; 1:0-10mV; 2:0-15mV,) Initial value: 1 (0-10mV)	

40131 ~ 40200	0130 ~ 0199	Reserve		
Weight and calibration area, the weight parameters and calibration can be set after the remote calibration be On, otherwise read only				
40201-40202	0200-0201	Unit	Range: 0-3; 0-t, 1-kg, 2-g, 3-lb	
40203-40204	0202-0203	Decimal	Range: 0-4; 0-0, 1-0.0, 2-0.00, 3-0.000, 4-0.0000	
40205-40206	0204-0205	Division	Range: 1,2,5,10,20,50,100,200,500	
40207-40208	0206-0207	Full scale	Range: 0- division *200000	
40209-40210	0208-0209	Reserve		
40211-40212	0210-0211	Auto Capture	Write 1 only; Write 1 to calibrate zero. Read: Current millivolts of the loadcell. Fixed 4 decimal points.	
40213-40214	0212-0213	Key In mV	Range: 0-150000; Write millivolts	
40215-40216	0214-0215	Weight CP1	Write weight value to calibrate weight calibration point 1	Read as the relative millivolts of the calibration point.
40217-40218	0216-0217	Weight CP2	Write the weight value to calibrate weight calibration point 2	
40219-40220	0218-0219	Weight CP3	Write the weight value to the calibration weight point 3 calibration	
40221-40222	0220-0221	Weight CP4	Write the weight value to calibrate weight calibration point 4	
40223-40224	0222-0223	Weight CP5	Write the weight value to calibrate weight point calibration 5	
40225-40226	0224-0225	LC mV/V	Write using the actual sensitivity of the loadcell for theoretical value calibration	
40227-40228	0226-0227	LC Capacity	Write the total loadcell range for theoretical calibration	
40229-40230	0228-0229	Use T-CAL	Write 1 to enable theoretical calibration, write 0 to use calibration data	
40231-40232	0230-0231	CAL Correct	Write coefficient to correct calibration, write data integer, the system default wrote data with 5 decimal points	
40233 ~ 40500	0232 ~ 0499	Reserve		
Recipe parameter area, read and write after remote editing is turned on				
40501-40502	0500-0501	Recipe ID	Initial value 1; Range: 1 to 20	
40503-40504	0502-0503	Target	Weight value write range: ≤ maximum range (communication floating-point switch is turned on, floating-point number is displayed)	
40505-40506	0504-0505	Co-F Remain		
40507-40508	0506-0507	Me-F Remain		
40509-40510	0508-0509	Free Fall		
40511-40512	0510-0511	NearZero Band		
40513-40514	0512-0513	Over Value		
40515-40516	0514-0515	Under Value		
40517-40518	0516-0517	Decrement		

		protection threshold	
40519-40520	0518-0519	Co-Fi Mini-Flow	
40521-40522	0520-0521	Nozzle Up SP1	
40523-40524	0522-0523	Nozzle Up SP2	
40525-40526	0524-0525	Supply Empty	
40527-40528	0526-0527	Supply Full	
40529-40530	0528-0529	Fast Wt Refresh	
40531-40550	0548-0549	Reserve	
40551-40552	0550-0551	Tare PDLY	Initial value: 0.5; Range: 0 to 99.9 (s)
40553-40554	0552-0553	Co-F Inhibit T	Initial value: 0.9; Range: 0 to 99.9 (s)
40555-40556	0554-0555	Me-F Inhibit T	Initial value: 0.9; Range: 0 to 99.9 (s)
40557-40558	0556-0557	Fi-F Inhibit T	Initial value: 0.9; Range: 0 to 99.9 (s)
40559-40560	0558-0559	FreeFall DLY	Initial value: 0.5; Range: 0 to 99.9 (s), valid in multi decrement mode
40561-40562	0560-0561	Result Wait T	Initial value: 0.5; Range: 0 to 99.9 (s)
40563-40564	0562-0563	Nozzle Up PDLY	Initial value: 0.5; Range: 0 ~ 99.9(s),single increments, valid in multi increment mode
40565-40566	0564-0565	Nozzle Up DLY	Initial value: 0.5; Range: 0 ~ 99.9 (s), single increments, multi increments are valid
40567-40568	0566-0567	Move Bucket DLY	Initial value: 0.5; Range: 0 to 99.9 (s), valid for single- increment
40569-40600	0568-0599	Reserve	
40601-40602	0600-0601	Ref. Counts	Initial value: 0; Range: 1 to 99.
40603-40604	0602-0603	CORR. Range	Initial value: 2.0; Range: 0 to 9.9 (unit: %)
40605-40606	0604-0605	CORR.Degree	Initial value: 1; Optional: 0:100% correction; 1:50% correction; 2:25% correction
40607-40608	0606-0607	Result Detect	Initial value: 0; Optional: 0: off; 1: Detection not paused; 2: Detect and Pause
40609-40610	0608-0609	O/U Alarm T	Initial value: 2.0; Range: 0.0 to 99.9 (s)
40611-40612	0610-0611	Max. Counts	Initial value: 1; Range: 1 to 99.
40613-40614	0612-0613	Under Replenish valid time	Initial value: 0.5; Range: 0 to 99.9 (s)
40615-40616	0614-0615	Fill-ON T	Initial value: 0.5; Range: 0 to 99.9 (s)
40617 ~ 40618	0616 ~ 0617	Fill-OFF T	Initial value: 0; Optional: 0: off; 1: On
40619-40620	0618-0619	Tare Detection	Weight written range: ≤ maximum range
40621-40622	0620-0621	Tare Up Limit	Weight written range: ≤ maximum range
40623-40624	0622-0623	Tare Low Limit	Initial value: 0; Optional: 0: off; 1: On
40625-40626	0624-0625	Bucket Tare	Weight writing range: ≤ maximum range
40627-40628	0626-0627	B Nozzle PROT	Initial value: 0; Optional: 0: off; 1: On
40629-40630	0628-0629	Bump Weight	Weight written range: ≤ maximum range
40631-40632	0630-0631	Bump Alarm T	Initial value: 2.0; Range: 0 to 99.9 (s)
40633-40700	0632-0699	Reserve	

40701-40702	0700-0701	Fill Speed CTR.	0: Single Ctrl; 1: Single Ctrl
40703-40704	0702-0703	Result Check	0: Stable Mode; 1: Delay Mode; 2: Stable&Delay:
40705-40706	0704-0705	Filling mode	0: Gross Filling 1: Net Filling
40707-40708	0706-0707	Fill Permit REQ	Initial value: 0; Optional: 0: Disable 1: Enable
40709-40710	0708-0709	Fill 1st Action	Initial value: 0; Optional: 0: tare first; 1: lower nozzle first
40711-40712	0710-0711	M-Fill To ACUM	Initial value: 0; Optional: 0: Disable 1: Enable
40713-40714	0712-0713	Proess FIRs CFG	Initial value: 0; Optional: 0: Disable 1: Enable
40715-40716	0714-0715	Filling FIR	Initial value: 5; Range: 0 to 9.
40717-40718	0716-0717	Wait Result FIR	Initial value: 7; Range: 0 to 9.
40719-40720	0718-0719	Bucket Move FIR	Initial value: 3; Range: 0 to 9.
40721-40722	0720-0721	Feeding Switch	Initial value: 1; Optional: 0: Disable 1: Enable
40723 ~ 40800	0722 ~ 0799	Reserve	
IO parameter setting area, readable-writable			
40801	0800	Input 1 Function definition	0:None; 1: Start; 2: E-Stop; 3: Stop; 4: Pause; 5: Zero; 6: Clear Alarm; 7: Change Recipe; 8: Print; 9: P_EMPTY_LINE r; 10: Bucket ->Permit; 11: Tare/Fill Star; 12: Nozzle Down OK; 13: Supply Full; 14: Supply NotEmpty; 15: M Co-Fill (LS); 16: M Fi-Fill (LS)); 17: Start/ESop (LS) 18: Start/Stop (LS) 19: Run Once ; 20: Simulation Run
40802	0801	Input 2 Function definition	
40803	0802	Input 3 Function definition	
40804	0803	Input 4 Function Definition	
40805	0804	Input 5 Function definition	
40806	0805	Output 1 function definition	0: None; 1: Running 2: Stopped 3: Co-Fill 4: Me-Fill 5: Fi-Fill 6: Wait Result 7: DONE
40807	0806	Output 2 Function definition	
40808	0807	Output 3 Function	

		definition	8: Supply Empty 9: FILL Supplement 10: Over/Under 11: Alarm 12: NearZero 13: Nozzle Bumped 14: Bucket Push 15: Batch complete 16: Nozzle Down/Up 17: Nozzle Up Step1 18: Nozzle Up Step2 19: COM Heartbeat	
40809	0808	Output 4 Function definition		
40810	0809	Output 5 Function definition		
40811	0810	Output 6 Function definition		
40812	0811	Output 7 Function definition		
40813	0812	Output 8 Function definition		
40814	0813	Output 9 Function definition		
40814-40900	0814-0899	Reserve		
40901	0900-0901	Set batch times	Initial value: 0 ; Range: 0-9999	
40902	0902-0903	Remain batches times		
40903-41000	0904-0999	Reserve		
41001-41002	1000-1001	Target 1	Weight value written range: ≤ maximum range	
41003-41004	1002-1003	Target 2		
.....				
41040	1039	Target 20		
41041-42000	1040-1999	Reserve		
42001-42002	2000-2001	Recipe 1 Cumulative weight (high 6 bit)	Write 1 Clear the current cumulative	
42003-42004	2002-2003	Recipe 1 Cumulative weight (low 9 bit)		
42005-42006	2004-2005	Recipe 1 Cumulative weight		
42007-42008	2006-2007	Recipe 2 Cumulative weight (high 6 bit)		
42009-42010	2008-2009	Recipe 2 Cumulative Weight (low 9 bit)		
42011-42012	2010-2011	Recipe 2 Cumulative weight		
.....				
42115-42116	2114-2115	Recipe 20 Cumulative weight (high 6 bit)		
42117-42118	2116-2117	Recipe 20 Cumulative Weight (high 6 bit)		
42119-42120	2118-2119	Formula 20 cumulative times		
Communication parameter setting area, readable and writable				

48001	8000	COM0 ID	Slave number of serial port 0 ; Range: 01-99
48002	8001	COM0 Baud rate	Initial value: 5-38400 , range: 0-7 corresponding to: 0-1200, 1-2400, 2-4800, 3-9600, 4-19200, 5-38400, 6-57600, 7-115200 ;
48003	8002	COM0 Protocol	Initial value: 0-Modbus RTU , range: 0-Modbus RTU, 1-Modbus Ascii, 2-Cont-A, 3-Cont-B, 4-r-Cont, 5-rE-Cont, 6-YH, 7-Print
48004	8003	COM0 Data Format	Initial value: 1 (8E1) ; Range: 0-8N1, 1-8E1, 2-8O1, 3-7E1, 4-7O1
48005	8004	COM0 DwordFormat	Initial value : 0 (AB-CD) Range: 0-ab-cd, 1-CD-AB .
48006	8005	COM0 Send Gap	Initial value: 20ms , range 0-1000ms
48007	8006	Float Data SW	Initial value: Disable, range: 0: Disable, 1: Enable
48008-48020	8007-8019	Reserve	
48021	8020	COM1 ID	Refer to COM0 parameters
48022	8021	COM1 Baud rate	
48023	8022	COM1 Protocol	
48024	8023	COM1 Data Format	
48025	8024	COM1 DwordFormat	
48026	8025	COM1 Send Gap	
48027	8026	COM1 RS485/Rs232	Initial value: 1-RS485 ; Range: 0-RS232; 1-RS485
48028 ~ 48100	8027 ~ 8099	Reserve	
48101	8100	NetCOM Protocol	The protocols are 0-Modbus/TCP, 1-Cont-A/TCP, 2-Cont-B/TCP, 3-r-Cont/TCP, 4-rE-Cont/TCP , and 5-YH/TCP . When Ethernet/IP or Profinet is selected, this parameter cannot be set
48102	8101	NetCOM DwordFormat	For standard network ports, can set 0-AB-CD, 1-CD-AB When Ethernet/IP or Profinet is selected, this parameter cannot be set
48103	8102	NetCOM Send interval	The communication mode is 1-Cont-A/TCP, 2-Cont-B/TCP, 3-r-Cont/TCP, 4-rE-Cont/TCP, 5-YH/TCP . This parameter is used to set the interval for continuous transmission. Initial value: 20ms , range from 0 to 1000ms
48104-48107	8103-8106	IP COnfig	Initial value: 192.168.0.100 , The order is the first to fourth IP
48108-48111	8107-8110	Target IP	Initial value: 192.168.0.101 , The order is the first to fourth IP
48112	8111	NetCOM	Initial value: 502 , range: 0-65535 , set the

		Socket	network communication port number
48113	8112	Write Enable	Initial value: Disable, range: 0: Disable, 1: Enable
48114-48200	8113-8199	Reserved, readable, read: all 0	
48201	8200	HeaderLines	Range: 0-4 , select how many header lines to use
48202	8201	EnderLines	Range: 0-4 , select how many tailer lines to use
48203	8202	Print interval	Range: 0-99 , the number of lines spaced between each print
48204	8203	Print content	Initial value: 0 . Displayed weight. Range: 0-4 , optional: 0 , displayed weight, 1 , gross weight, 2 , net weight, 3 , net weight + tare (two lines), 4 , all information (gross weight + net weight + tare)
48205	8204	Print language	0 : English 1 : Chinese
48206	8205	Information line selection	Range: 1-8 , corresponding to header information 1-4 and tail information 1-4 . 0 after power-on. After writing, read is the written value
48207-48222	8206-8221	The character content of the printed message (16 characters)	Ascii codes support 0-9 , a-z , A-Z , 'space', and '-'
48221 ~ 48250	8222 ~ 8249	Reserved, readable, read:all 0	
48251-48256	8250-8255	Bluetooth device name 6 characters	Only the Ascii codes of 0-9 , a-z , A-Z , 'space', and '-' are supported
48257 ~ 48280	8256 ~ 8279	Reserved, readable, read:all 0	
48281	8280	Language	0 : Chinese 1 : English
48282	8281	year	
48283	8282	month	
48284	8283	day	
48285	8284	clock	
48286	8285	minute	
48287	8286	second	
48288	8287	ScreenSleep	Initial value: 600; Range: 0-3600s
48289	8288	Standard IO mode	0:low level valid
48290	8289	Extended IO mode	0: Low level valid
48291	8290	Scale Structure	0: Single increment 1: Multi increment 2: Multi decrement
48292 ~ 48300	8291 ~ 8299	Reserve, readable, read: all 0	
I/O test parameters, readale-writable			
48301	8300	I/O test mode	Parameter range: 0-1 , 0: exit I/O test mode, 1: Input serial port I/O test mode , must closed after test completed,then the instrument can enter the normal state.

48302	8301	Input test 1	Read 0 means input invalid, and read 1 means input valid. Writing any value is invalid and only works in IO test mode
48303	8302	Input test 2	
48304	8303	Input Test 3	
48305	8304	Input 1 test	
48306	8305	Input 2 Test	
48307 ~ 48350	8306 ~ 8349	Reserve	
48351	8350	Output 1 Test	Range: 0-1, write: 0: off, 1: output valid(only valid in IO test mode), read as the current IO port status, 0: off, 1: on
48352	8351	Output 2 Test	
48353	8352	Output 3 Test	
48354	8353	Output 4 Test	
48355	8354	Output 5 Test	
48356	8355	Output 1 Test	
48357	8356	Output 2 Test	
48358	8357	Output 3 Test	
48359	8358	Output 4 Test	
48360 ~ 48600	8359 ~ 8599	Reserve	
Function operation class address area (corresponding to coil function), readable-writable			
48601	8600	Zero	Write 1 perform the operation Read:all 0
48602	8601	Tare	
48603	8602	Clear tare	
48604	8603	Gross/net weight switch	
48605	8604	Zero Calibrate	
48606	8605	Print	
48607	8606	Feed Paper	
48608	8607	Start	
48609	8608	Slow Stop	
48610	8609	E-Stop	
48611	8610	Pause	
48612	8611	Clear Alarm	
48613	8612	Select recipe	
48614	8613	Tare/Start Filling	
48615	8614	Lower nozzle	
48616	8615	Manual Coarse Feed	
48617	8616	Manual Fine Feed	
48618	8617	Manual run Once	
48619	8618	Clear accumulation	
48620 ~ 48900	8619 ~ 8899	Reserve	
Reset parameter area			
48901	8900	Reset all parameter	Write 1 perform the corresponding reset
48902	8901	Reset uncalibrated	

		parameters	Operation. Read:all 0
48903	8902	Reset calibration parameters	
48904	8903	Reset Basic parameters	
48905	8904	Reset I/O definition	
48906	8905	Reserve	
48907	8906	Reset apply parameters	
48908	8907	Communication parameter reset	
48909	8908	Reset Recipe parameter	
48910 ~ 48980	8909 ~ 8979	Reserve	
48981-48988	8980-8987	Edit Boot logo characters 1-8 (8 characters)	The order corresponds to the first 1-8 characters of the boot logo, need to write Ascii code, range: 0-9,A-Z,a-z , space, '-'
48989 ~ 49000	8988 ~ 8999	Reserve	
Instrument System information area, read-only area			
410001	10000	Software version (high byte)	
410002	10001	Software version (low byte)	If the read is 10000 , version 01.00.00
410003	10002	Compile time (year)	
410004	10003	Compile time (month day)	
410005-410017	10004-10016	Instrument serial port 13 characters	
410018-410029	10017-10028	Instrument code 12 characters	
410030	10029	Reserve	
410031-410040	10030-10039	Instrument model number 10 characters	
410041	10040	Attach board 01 information	
410042	10041	Attach board 02 information	
410043 ~ 410100	10042 ~ 10099	Reserve	
410101-410106	10100-10105	MAC1 address of instrument	
410107-410112	10106-10111	Reserved	
410113-410118	10112-10117	Bluetooth MAC address	
410119 ~ 410200	10118-10199	Reserve	
410201	10200	Basic parameter remote edit	Switch status bit, read only: Read: 0 , Disable; 1 , Enable
410202	10201	Basic parameter password protection	
410203	10202	Remote Calibration	
410204	10203	Calibration Hardware protection	
410205	10204	Calibrated Password protection	
410206	10205	Recipe parameters remote edit	
410207	10206	Recipe parameters Password protection	
410208	10207	communication	

		parameters remote edit	
410209	10208	Communication parameter password protection switch	
410210	10209	System maintenance parameter remote edit	
410211	10210	System maintenance parameters password protection	
Coil address			
0x0001	0000	Zero	The contents are readable and writable coils Writing ON is valid Read as 0
0x0002	0001	Tare	
0x0003	0002	Clear tare	
0x0004	0003	Gross/Net weight switch	
0x0005	0004	Zero	
0x0006	0005	Print	
0x0007	0006	Print feed paper	
0x0008	0007	Start	
0x0009	0008	Slow Stop	
0x0010	0009	E-Stop	
0x0011	0010	Pause	
0x0012	0011	Clear Alarm	
0x0013	0012	Select recipe	
0x0014	0013	Tare/start filling liquid	
0x0015	0014	Lower nozzle complete	
0x0016	0015	Manual coarse feed	
0x0017	0016	Manual fine feed	
0x0018	0017	Run once manually	
0x0019	0018	Clear accumulations	
0x0020~0x0300	0019 ~ 0299	Reserve	
0x0301	0300	Reset all parameters	This area only writes Write ON to perform reset operation Read 0
0x0302	0301	Uncalibrated parameter reset	
0x0303	0302	Calibration reset	
0x0304	0303	Basic parameters reset	
0x0305	0304	I/O Definition Reset	
0x0306	0305	Reserve	
0x0307	0306	Application parameters reset	
0x0308	0307	Communication parameters reset	
0x0309	0308	Recipe parameters reset	
0x0310~0x0400	0309-0399	reserve	
0x0401	0400	Input 1 status	Read only area
0x0402	0401	Input 2 status	Read Return each input port status

0x0403	0402	Input 3 status	bit 0: invalid; 1 valid
0x0404	0403	Input 1 status	
0x0405	0404	Input 2 status	
0x0406~0x0450	0405 ~ 0449	reserve	
0x0451	0450	Output 1 status	Read only area Read return each output status bit 0: invalid; 1 valid
0x0452	0451	Output 2 status	
0x0453	0452	Output 3 Status	
0x0454	0453	Output 4 Status	
0x0455	0454	Output 5 status	
0x0456	0455	Expand output 1 status	
0x0457	0456	Expand output 2 status	
0x0458	0457	Expand output 3 status	
0x0459	0458	Expand output 4 status	
0x0460~0x0500	0459 ~ 0499	Reserve	
0x0501	0500	Remote Editing (basic parameters)	Read only parameter area
0x0502	0501	Password Protection (basic parameters)	
0x0503	0502	Remote calibration (calibration parameters)	
0x0504	0503	Hardware Protection (calibration parameters)	
0x0505	0504	Password protection (calibration parameters)	
0x0506	0505	Remote Editing (apply parameters)	
0x0507	0506	Password Protection (application parameters)	
0x0508	0507	Remote Editing (communication parameters)	
0x0509	0508	Password Protection (communication parameters)	
0x0510	0509	Remote editing (System maintenance parameters)	
0x0511	0510	Password protection (system maintenance parameters)	
0x0512~0x0800	0511 ~ 0799	Reserve	

3.2 Cont-A (continuous send -CB920)

GMC-X1LF Serial port protocol When "Continuous Send A (CB920)" is selected, data is continuously sent in the following format.

Status	,	Content	0/1	+/-	Display Value	Unit	CR	LF
2-bit	2C	2 bit	30	2B/2D	7-bit	2-bit	0D	0A

Where:

Status -- 2 bits, **OL**(overflow) : **4FH 4CH**; **ST**(stable):**53H 54H**; **US**(unstable):**55H 53H**

Gross weight -- 2 bits, **GS**(gross weight) : **47H 53H**; **NT**(net weight) : **4EH 54H**;

0/1-1 digit, (**30H/31H**) sent alternately.

Units -- 2 bits, such as **kg**: **6BH 67H**; **g**:**20H 67H**, etc

Example: When the instrument automatically sends the following frame of data

53 54 2C 47 53 30 2B 20 20 20 20 32 35 34 33 39 0D 0A

the current instrument status: stable, gross weight, data value is positive, the current weight value is **254** kg

3.3 Cont-B (Continuous transmission -tt)

When the serial port protocol of **GMC-X1LF** is set to "Cont-B (tt)", the collected data will be automatically sent to the host

STX	Status 1	Status 2	Status 3	Display Value	Loadcell voltage	CR	Checksum
02H	1 bit	1 bit	20H	6 bits	6 bits	0D	1 bit

Status 1:

bit7	bit6	bit5	bit4		bit3	bit2		bit1	bit0
Fixed: 0			t	0	0	0	0	1	0
			kg	0	1	0.0	0	1	1
			g	1	0	0.00	1	0	0
			lb	1	1	0.000	1	0	1
						0.0000	1	1	0
			Weight Unit			Decimal point			

Status 2:

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Reserve	Reserve	Reserve	0- Weight	1- Unstable	1- Overflow	1- negative	1- Net weight
Fixed 0	Fixed 1	Fixed 1		0- Stable	0- Normal	0- positive	0- Gross weight

3.4 r-Cont

GMC-X1LF serial port protocol when "r-Cont" is selected, the collected data is automatically sent to the host machine in the following format without sending any commands to the weight transmitter.

STX	Scale No.	Channel No.	Status 1	Status 2	Display Values	CRC	CR	LF
02H	2-bit	31H	1 bit	1 bit	6 bits	2 bits	0D	0A

Instruction:

Scale No. - 2 digits, ranging from **01** to **99**

Status 1 -- 1 bit

bit7	bit6	bit5	bit4		bit3	bit2		bit1	bit0
Fixed:0			t	0	0	0	0	0	0
			kg	0	1	0.0	0	0	1
			g	1	0	0.00	0	1	0
			lb	1	1	0.000	0	1	1

				0.0000	1	0	0
Weight unit				Decimal point			

Status 2--1 bit

D6	D5	D4	D3	D2	D1	D0
Fixed: 1.	Fixed : 0	Gross:0; Net:1;	0: positive 1: negative	0: Non-zero 1: zero	0: Normal 1: Overflow	0: unstable 1: Stable

Weight value - 6 digit unsigned number; Return "Space space **OFL** space" when the weight is positive (negative) overflowed

CRC - 2 digits, checksum

All values before the check digit are added and converted to decimal data, then the last two digits are converted to **ASCII** (tens first, ones after). For example

If you have the following frame of data:

02	30	31	43	47	4F	4B	39	31	0D	0A
----	----	----	----	----	----	----	----	----	----	----

The sum of 02 to 4B is 187 (**Hex**) and **converted to 391 in decimal form**. It can be calculated that the check code for this data frame are **39 and 31**.

For example:

The current instrument automatically returns data: **02 30 31 31 40 41 20 20 20 37 30 30 32 34 0D 0A**

the current status of the instrument: stable, the weight value is positive, and the current weight value is **700**.

3.5 rE-Cont

In this way, there is no need to send any command to the weighing display, and the display automatically sends the collected data to the supremacist.

Return data frame format description:

Status	,	Content	,	+/-	Display Value	Unit	CR	LF
2-bit	2C	2 bit	2C	2B/2D	7-bit	2 bits	0D	0A

Instruction:

Status -- 2 bits, **OL**(overflow):**4FH 4CH**; **ST**(stable):**53H 54H**; **US**(unstable):**55H 53H**

Content -- 2 bits, **GS**(gross weight) : **47H 53H**; **NT**(net weight) : 4EH 54H;

Display value - 7 digits, including a decimal point, the upper part is a space if no decimal point

Unit -- 2 digits, such as **kg**: **6BH 67H**; **g**:**20H 67H**; **t**:**20H 74H**; **lb**:**6CH 62H**

For example:

When the weighing display automatically sends the following frame of data:

53 54 2C 47 53 2C 2B 20 20 20 38 30 38 20 74 0D 0A

Means:the current status is stable, the data value is positive, and the display value is **808t**

3.6 YH(Protocol)

If the serial port protocol of GMC-X1LF is set to **YH**, data is transmitted in the following format. Under this protocol, the data is output in **ASCII code**, and each frame data is composed of 9 groups (including decimal points). Data transmission first low then high, there is a group of delimiter "=" **between each frame data, send data for gross weight, such as the current gross weight 70.15**, continuously send **51.0700=51.0700...**

For example: **123.9**

Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7	Bit8
=	9	.	3	2	1	0	0	0

Where: the high position is insufficient to fill **0**, the decimal point accounts for **1** byte, and **Bit8** is a negative sign "-" when negative.

3.7 PROFINET Communication

The GMC-X1LF display has two PROFINET-IO bus connection ports, NET1 and NET2, which can be connected to the PROFINET bus as a ProFINET-IO slave station.

The instrument IP address can be viewed in the Data-Trans - NetCOM - IP Config; MAC address in the Maintenance - System info -MAC address item to view.

3.7.1 I/O Status

The **GMC-X1LF** provides multi-byte **IO**, output in two modules, through which the master station can **read and** control the status of the weigh display. In PN communication mode, two sets of IO module addresses are provided: standard version and simple version. Through the Data-Trans parameters - the GSD Type can choose corresponding version. The IO module addresses of the two versions are as follows:

11.7.1.1 I/O Module address of the Standard version

Module 1: Weight and status parameters (read register)

Offset	Parameter name	Data type	Parameter Description
0	Displayed weight	DInt	Currently displayed Weight, integer
4	Weight Of Reduction method	DInt	Reduction method running weight, integer type
8	Weight status flag bit	Word	D13-D15 Reserve
			D12: Bipolar
			D11: Calculate weight by using theoretical values, (prompt user when calculating weight using theoretical value)
			D10: ADC failure, (ADC initialization failure or sampling interruption beyond expected)
			D9: Currently displayed net weight, (distinguish which weight is currently displayed)
			D8: millivolt stable,(millivolt stable sign when calibration)
			D7: Loadcell negative overflow, lower than the loadcell voltage allowed range
			D6: Loadcell positive overflow, beyond the loadcell voltage allowable range
			D5: Weight negative overflow, weight less than "- (Max range + 9d)"

			D4: Weight positive overflow, weight greater than "Max range +9d"
			D3: Overflow status, (abnormal weight or loadcell)
			D2: display weight is negative
			D1: zero, (weight in the range of 0+/- 1/4 d)
			D0: Stable
10	Error code 1	Word	D13-D15 Reserved
			D12: Remote calibration When disabled
			D11: In hardware protection during calibration
			D10: The previous weight point is not calibrated
			D9: Beyond minimum resolution (less than 0.1uV per division)
			D8: Weight input exceeds the maximum range
			D7: The weight input cannot be zero
			D6: Weight calibration is less than zero or the previous calibration point
			D5: The loadcell positive overflow during weight calibration
			D4: The loadcell negative overflow during weight calibration
			D3: Weight calibration is unstable
			D2: Loadcell positive overflow during zero calibration
			D1: Loadcell negative overflow during zero calibration
			D0: zero calibration is unstable
12	Error code 2	Word	D15 Reserve
			D14: Disable zero when run
			D13: The remote tare operation allow switch is not enabled during remote tare operation
			D12: The tare is not allowed in the net weight state
			D11: The weight is negative when taring
			D10: The loadcell positive overflow when taring
			D09: The loadcell negative overflow when taring
			D08: Unstable when taring
			D07: Does not allow zero in net weight status
			D06: The remote zero switch is not enabled during remote zero
			D05: The loadcell positive overflow when zeroing
			D04: The loadcell negative overflow when zeroing
			D03: Unstable when zeroing
			D02: Zero out of range
			D01: Power-on zero unstable
			D00: Power-on zero out of range
14	Process status flag bit	Word	D10-D15 Reserve
			D9: IO test status
			D8: Printing, (valid when instrument perform a printing operation)
			D6-D7: Reserved
			D5:1: Pause
			D4:1: Slow Stop
			D3:1: Supply material
			D2:1: Lack material
			D1: Lower level
			D0: Upper level
16	Process status flag bit 2	Word	D15: Wait for the stop signal
			D14: Zero Zone:1

			D13: Nozzle Down; 1 , Nozzle Up: 0 D12: Push bucket D11: normal filling liquid completed (valid after waiting, zero after starting filling liquid again) D10: Alarm D9: Weigh OK D8: Waiting D7: Under Replenish Material D6: Under D5: Over D4: Fine Feed D3: Medium Feed D2: Coarse Feed D1: Before Feeding D0: Run: 1, Stop: 0
18	Status Tips	Word	0- No action 1- Bump bucket 2- Wait for the start signal 3- Wait for the lower level 4- Delay 5- Coarse Feed 6- Medium Feed 7- Fine Feed 8- Free fall delay 9- Free fall correction 10- Over/under 11- Under replenish 12- Over/under Pause 13- Raise nozzle 14- Waiting 15- Weigh OK 16- Pushing bucket 17- Wait for stop 18- Pause 19- Batches completed
20	Process alarm	Word	D13-D15 Reserve D12: Batches complete alarm D11: Do not allow filling liquid (reduction method, the current weight is below the lower limit of the material level, in the supply material state) D10: The material level is not set properly D9: Decrement protection D8: material leakage, when the coarse feeding flow is lower than the lower limit of coarse feeding flow, the instrument has the default material leakage, the instrument output buzzer alarm, the main interface prompts the material leakage, and stops D7: Over/under pause D6: Over/under D5: Tare detection error D4: Bump Bucket D3: OFL when starting D2: The gun/gun lifting function is not defined, use the step raise nozzle function D1: There is an undefined IO in the IO module that must be defined D0: Formula setting unreasonable alarm
24	Gross Weight	DInt	Gross weight value, signed, integer

28	Net weight	DInt	Net weight value, signed, integer
32	Tare	DInt	Tare, signed, integer
36	Current weight	Float	Current weight value, floating point type
40	Gross weight	Float	Gross weight value, floating point type
44	Net weight	Float	Net weight value, floating point type
48	Tare	Float	Tare value, floating point type
52	Code in AD after filtering	DWord	Inside code of the ADC after filtering
56	Loadcell voltage value data	DWord	Signed numbers, integers, four decimal points
60	Relative zero voltage value data	DWord	Signed numbers, integers, four decimal points
64	System accumulates higher 6 digits	DWord	Unsigned number, integer
68	System accumulates lower 9 digits	DWord	Unsigned number, integer
72	System count	DWord	Unsigned number, integer
76	Formula weight 6 point higher	DWord	Unsigned number, integer
80	Formula weight 9 point lower	DWord	Unsigned number, integer
84	Formula ACUM Times	DWord	Unsigned number, integer
88	Waiting weight	DWord	Unsigned number, integer
92	Input status area	Word	D5-D15: Reserved
			D2: Input 5 status (extended input 2)
			D1: Input 4 status (extended input 1)
			D0: Input 3 status
			D1: Input 2 status
			D0: Input 1 status
94	Output status area	Word	D9-D15 Reserved
			D8: Output 9 status (extended output 4)
			D7: Output 8 status (extended output 3)
			D6: Output 7 status (extended output 2)
			D5: Output 6 states (extended output 1)
			D4: Output 5 status
			D3: Output 4 status
			D2: Output 3 status
			D1: Output 2 status
			D0: Output 1 status
96	Communication heartbeat	DWord	When PN communicates, the value of the communication heartbeat is converted between 0 and 1 at a frequency of 1 Hz.

Module 2: Calibration parameters (Read/write register)

Offset	Parameter name	Data type	Instructions
0	Automatically Obtain zero point	DWord	Current Loadcell voltage
4	Gain Calibration point 1	DWord	Relative voltage value 1 (loadcell input - zero point voltage)
8	Gain Calibration point 2	DWord	Relative voltage value 2 (loadcell input - Calibration point 1 voltage)
12	Gain Calibration point 3	DWord	Relative voltage value 3 (loadcell input - Calibration point 2 voltage)

16	Gain Calibration point 4	DWord	Relative voltage value 4 (loadcell input - Calibration point 3 voltage)
20	Gain Calibration point 5	DWord	Relative voltage value 5 (Loadcell input - Calibration point 4 voltage)
0	Automatically Obtain zero point	DWord	Current Loadcell voltage (write 1 to communication address, perform automatic zero calibration)
4	Gain Calibration point 1	DWord	Input gain weight value 1
8	Gain Calibration point 2	DWord	Input gain weight value 2
12	Gain Calibration point 3	DWord	Input gain weight value 3
16	Gain Calibration point 4	DWord	Input gain weight value 4
20	Gain Calibration point 5	DWord	Input gain weight value 5
24	Function operation	DWord	D18-D31 Reserved
			D18: Clear cumulative
			D17: Run once manually
			D16: Manual Fine Feed
			D15: Manual Coarse Feed
			D14: Lower nozzle complete
			D13: Tare and start filling
			D12: Select recipe
			D11: Clear alarm
			D10: Pause
			D9: Emergency stop
			D8: Slow stop
			D7: Start
			D6: Print feed paper
			D5: Print
			D4: Calibrate zero
			D3: Gross/Net weight switch
			D2: Clear Tare
			D1: Tare
			D0: Zero

Module 3: Parameter modification (read/write register)

0	Read out values	DWord	The master station requests the data returned by the instrument, the value obtained according to the "address requested to read"
4	The write status	Word	Write the state of the data return 0: No error 1: Register address is illegal 2: parameter error
6	Read status	Word	Read the status of the data returned 0: No error 1: The register address is illegal 2: parameter error
0	Request to write the value modbus address	DWord	Modbus write operation address (note that no write is written when the address changes), this parameter modifies the range of MODBUS addresses supported by the interface module only to 0100-02119
4	Input data	DWord	Write this data to the "modbus address of the requested value" (note that it will only be written to the instrument if the value has changed)
8	The address of the requested read	DWord	Modbus read operation address (note that you cannot read two-byte addresses, write an odd-numbered address). This parameter modifies the range of MODBUS addresses supported by the interface module only to 0000-02119

11.7.1.2 I/O Module Address Lite

PN Loop parameter list

Offset	Parameter name	Data type	Parameter Description
Read register (I address)			
0	Displayed weight	DInt	Weight currently displayed, integer
4	Weight status flag bit	Word	D13-D15 Reserved
			D12: Bipolar
			D11: Calculate weight using theoretical values, (prompt user when calculating weight using theoretical values)
			D10: ADC failure, (ADC initialization failure or sampling interruption longer than expected)
			D9: Currently displayed net weight, (distinguish which weight is currently displayed)
			D8: millivolt stable, (millivolt stable sign when calibrating)
			D7: loadcell negative overflow, lower than the loadcell voltage allowed range
			D6: loadcell positive overflow, beyond the allowable range of loadcell voltage
			D5: Weight negative overflow, weight less than "-(Max range +9d)"
			D4: Weight positive overflow, weight greater than "Max range +9d"
			D3: Overflow status, (abnormal weight or loadcell)
			D2: Displayed weight is negative,
			D1: zero, (weight in the range of 0+/- quarter d)
			D0: Stable
6	Error code 1	Word	D13-D15 Reserved
			D12: Remote calibration when disabled
			D11: In hardware protection when calibration
			D10: The previous weight point is not calibrated
			D9: Beyond minimum resolution (less than 0.1uV per division)
			D8: Weight input exceeds the maximum range
			D7: The weight input cannot be zero
			D6: Weight calibration is less than zero or the previous calibration point
			D5: The loadcell negative overflow during weight calibration
			D4: The loadcell negative overflow during weight calibration
			D3: Weight calibration is unstable
			D2: Loadcell positive overflow when zero calibration
			D1: Loadcell negative overflow when zero calibration
			D0: zero calibration is unstable
8	Error code 2	Word	D15 Reserved
			D14: Forbid zero when running
			D13: The remote tare operation allow switch is not enabled during remote tare operation
			D12: The tare is not allowed in the net weight state
			D11: The weight is negative when taring
			D10: The loadcell positive overflow when taring
			D09: The loadcell negative overflow when taring
			D08: Unstable when taring
			D07: The net weight status does not allow zeroing

			D06: The remote zero switch is not enabled when remote zero
			D05: The loadcell positive overflow when zeroing
			D04: The loadcell negative overflow when zeroing
			D03: Unstable when zeroing
			D02: Zero out of range
			D01: Unstable when power-on zero
			D00: Power-on zero is out of range
10	Process status flag bit	Word	D15: Wait for the stop signal
			D14: Zero Zone:1
			D13: Lower Nozzle :1, Raise nozzle: 0
			D12: Push the bucket
			D11: normal liquid filling completed (valid after waiting, zero after starting liquid filling again)
			D10: Alarm
			D9: Weigh OK
			D8: Waiting
			D7: Under Replenish
			D6: Under
			D5: Over
			D4: Fine Feed
			D3: Medium Feed
			D2: Coarse Feed
D1: Before feeding			
D0: Run: 1, Stop: 0			
12	Alarm	Word	D15 Reserved
			D14: Write data return status, 0 write success; 1 write failed
			D13: When PN is communicating, the value of the communication heartbeat switches between 0 and 1 at a frequency of 1 Hz.
			D12: Batches completes alarm
			D11: Not allowed to start when Start
			D10: Material level setting is not reasonable
			D9: Decrement protection
			D8: material leakage, when the coarse feeding flow is lower than the lower limit of coarse feeding flow, the instrument has the default material leakage, the instrument output buzzer alarm, the main interface prompts the material leakage, and stops
			D7: Over/under Pause
			D6: Over
			D5: Tare detection error
			D4: Bucket bump
			D3: OFL when starting
			D2: Lower nozzle/Raise nozzle function not defined, use step raise nozzle function
D1: There is an undefined IO in the IO module that must be defined			
D0: Formula setting unreasonable alarm			
14	Read out value	DWord	The master station requests the data returned by the instrument, the value obtained according to the "address requested to read"
Write register (Q address)			
0	Function operation	DWord	D18-D31 Reserved
			D18: Clear cumulative
			D17: Run once manually

			D16: Manual fine feed
			D15: Manual coarse feed
			D14: Lower Nozzle complete
			D13: Taring and liquid filling begins
			D12: Select recipe
			D11: Clear alarm
			D10: Pause
			D9: Emergency stop
			D8: Slow stop
			D7: Start
			D6: Print feed paper
			D5: Print
			D4: Calibrate zero
			D3: Gross/net weight switch
			D2: Clear tare
			D1: Tare
			D0: Zero
4	Request to write the value modbus address	DWord	Modbus write operation address (note that not written when the address changes), this parameter modifies the range of MODBUS addresses supported by the interface module only to 0100-02119
8	Input data	DWord	Write this data to the " modbus address of the requested value" (note that it will only be written to the instrument if the value has changed)
12	The address of the requested read	DWord	Modbus read operation address (note that you cannot read two-word addresses, write an odd-numbered address). This parameter modifies the range of MODBUS addresses supported by the interface module only to 0000-02119

3.7.2 Device Description file GSD

The device description file and connection method of GMC-X1LF can be downloaded from the website of Shenzhen General Measure Technology Co., LTD. (www.gmweighing.com).

3.8 EtherNet-IP Communication

Instrument IP address in the communication setting - network port communication - the local IP address item set and view, after setting to re-power on to take effect. MAC address in the system maintenance - System information -MAC address item to view.

3.8.1 I/O Status

GMC-X1LF provides multi-byte **IO** through which the master station can read and control the status of the weigh display.

Module 1: Read the register area

Offset	Parameter name	Data type	Parameter Description
Weight and status bits, read register			
0	Displyed weight	DInt	Weight currently displayed, integer
2	Displayed running weight	DInt	Decrement method weight

4	Weight status flag bit	Word	D13-D15 Reserved
			D12: Bipolar, (flag bits are valid when bipolar is selected)
			D11: Calculate the weight using the theoretical value, (prompt the user when calculating the weight using the theoretical value)
			D10: ADC failure, (ADC initialization failure or sampling interruption longer than expected)
			D9: Currently displayed net weight, (distinguish which weight is currently displayed)
			D8: millivolt stable, (when calibration millivolt stable sign)
			D7: loadcell negative overflow, lower than the loadcell voltage allowed range
			D6: loadcell positive overflow, beyond the allowable range of loadcell voltage
			D5: Weight negative overflow, weight less than "-(Max range +9d)"
			D4: Weight positive overflow, weight greater than "Max range +9d"
			D3: Overflow status, (abnormal weight or loadcell)
			D2: Displayed weight negative sign, (means weight is negative)
			D1: zero, (weight in the range of 0+/- quarter d)
			D0: Stable
5	Error code 1	Word	D13-D15 Reserved
			D12: Remote calibration when disabled
			D11: In hardware protection at calibration
			D10: The previous weight point is not calibrated
			D09: Beyond minimum resolution (less than 0.1uV per division)
			D08: Weight input exceeds maximum range
			D07: The weight input cannot be zero
			D06: Weight calibration is less than zero or the previous calibration point
			D05: The loadcell is overflowing during weight calibration
			D04: Loadcell negative overflow during weight calibration
			D03: Weight calibration is unstable
			D02: Loadcell overflow during zero calibration
6	Error code 2	Word	D01: Loadcell negative overflow during zero calibration
			D00: zero calibration is unstable
			D14-D15 Reserved
			D13: Remote tare operation allow switch is not turned on during remote tare operation
			D12: Not allow taring in the net weight state
			D11: The weight is negative overflow when the taring
			D10: The loadcell is positive overflow when taring
			D09: The loadcell negative overflow when taring

			D08: Unstable when taring
			D07: Does not allow zeroing in net weight status
			D06: The remote zero switch is not enabled during remote zero
			D05: The loadcell positive overflow when zeroing
			D04: The loadcell negative overflow when zeroing
			D03: Unstable when zeroing
			D02: zero out of range
			D01: power-on zero unstable
			D00: power-on zero out of range
7	Process status flag bit	Word	D10-D15 Reserved
			D9: indicates the I/O test status
			D8: Printing, (valid when the instrument is performing a printing operation)
			D6-D7: reserved
			D5:1: Pause
			D4:1: Pause
			D3:1: Supply Material
			D2:1: Lack Material
			D1: lower level
8	Process status flag bit 2	Word	D0: Upper level
			D15: Wait for the stop signal
			D14: Zone Zero: 1
			D13: Lower Nozzle: 1, lift gun: 0
			D12: Push bucket
			D11: Normal liquid filling completed (valid after waiting, zero after starting filling again)
			D10: Alarm
			D9: Weigh OK
			D8: Waiting
			D7: Under Replenish
			D6: Under
			D5: Over
			D4: Fine Feed
			D3: Medium Feed
			D2: Coarse Feed
9	Status Tips	Word	D1: Before Feeding
			D0: Run :1, Stop :0
			0- No action
			1- Raise bucket
			2- Wait for the start signal
			3- Wait for the Lower level
			4- Delay
			5- Coarse Feed
			6- Medium Feed
			7- Fine Feed
			8- Free Fall delay
			9- Drop correction
			10- Over/Under
			11- Under replenish
			12- Over/under Pause
			13- Raise nozzle

			14- Waiting 15- Weigh OK 16- Pushing bucket 17- Waiting to stop 18- Pause 19- Batches complete
10	Process alarm	DWord	D12-D15 Reserved
			D12: Batch complete alarm
			D11: Do not allow filling (reduction method, the current weight is below the lower limit of the material level, in the feeding state)
			D10: The material level is not set properly
			D9: Decrement protection
			D8: material leakage, when the coarse feeding flow is lower than the lower limit of rapid feeding flow, the instrument has the default material leakage, the instrument output buzzer alarm, the main interface prompts the material leakage, and stops
			D7: Over/under Pause
			D6: Over/Under
			D5: Tare detection error
			D4: Bump Bucket
			D3: OFL when starting
			D2: Lower nozzle/raise nozzle function not defined, use step raise nozzle function
			D1: There is an undefined IO in the IO module that must be defined
			D0: Formula setting unreasonable alarm
12	Gross Weight	DInt	Gross weight value (signed integer)
14	Net weight	DInt	Net weight value (signed integer)
16	Tare	DInt	Tare value (signed integer)
18	Current weight	Float	Weight currently displayed, floating point type
20	Gross weight	Float	Gross weight value, floating point type
22	Net weight	Float	Net weight value, floating point type
24	Tare	Float	Tare value, floating point type
26	Code in AD after filtering	DWord	Inside code of the ADC after filtering,
28	loadcell voltage value data	DWord	Signed numbers, integers, four decimal points
30	Relative zero voltage value data	DWord	Signed numbers, integers, four decimal points
32	System accumulates high 6 digit	DWord	Unsigned number, integer
34	System accumulates low 9 digit	DWord	Unsigned number, integer
36	System ACUM Times	DWord	Unsigned number, integer

38	Formula weight high 6 points	DWord	Unsigned number, integer
40	Formula weight low 9 points	DWord	Unsigned number, integer
42	Recipe ACUM Times	DWord	Unsigned number, integer
44	Waiting weight	DWord	Unsigned number, integer
46	Input status area	Word	D5-D15 Reserved
			D4: Input 5 status (extended input 2)
			D3: Input 4 status (extended input 1)
			D2: Input 3 status
			D1: Input 2 status
			D0: Input 1 status
47	Output status area	Word	D9-D15 Reserved
			D8: Output 9 status (extended output 4)
			D7: Output 8 status (extended output 3)
			D6: Output 7 status (extended output 2)
			D5: Output 6 states (extended output 1)
			D4: Output 5 status
			D3: Output 4 status
			D2: Output 3 status
			D1: Output 2 status
			D0: Output 1 status
48	Communication heartbeat	DWord	After the communication indicator is set to the network port, the communication indicator blinks at 1HZ. When the EIP communicates, the value of the communication heartbeat switches between 0 and 1 at a frequency of 1 Hz.
Calibrate and read the register			
50	Automatic zero acquisition	DWord	Current loadcell voltage
52	Gain calibration point 1	DWord	Relative voltage value 1 (loadcell input - zero point voltage)
54	Gain calibration point 2	DWord	Relative voltage value 2 (loadcell input - calibration point 1 voltage)
56	Gain calibration point 3	DWord	Relative voltage value 3 (loadcell input - calibration point 2 voltage)
58	Gain calibration point 4	DWord	Relative voltage value 4 (loadcel input - calibration point 3 voltage)
60	Gain calibration point 5	DWord	Relative voltage value 5 (loadcell input - calibration point 4 voltage)
Parameter modification, read register			
62	Read value	DWord	The master station requests the data returned by the instrument, the value obtained according to the "address requested to read"
64	Write status	Word	Write the status of the data return 0: No error 1: the register address is invalid 2: the parameter is incorrect
65	Read status	Word	Read the status of the data returned 0: No error 1: The register address is illegal 2: parameter

			error
--	--	--	-------

Module 2: Write register area

Calibration area			
0	Automatically Obtain zero	DWord	Current loadcell voltage
2	Gain calibration point 1	DWord	Input gain weight value 1
4	Gain calibration point 2	DWord	Input gain weight value 2
6	Gain calibration point 3	DWord	Input gain weight value 3
8	Gain calibration point 4	DWord	Input gain weight value 4
10	Gain calibration point 5	DWord	Input gain weight value 5
Function operation			
12	Functional operation	DWord	D18-D31 Reserved
			D18: Clear ACUM
			D17: Run once manually
			D16: Manual Fine feed
			D15: Manual Coarse feed
			D14: Lower nozzle completed
			D13: Taring and filling begins
			D12: Select recipe
			D11: Clear alarm
			D10: Pause
			D9: Emergency stop
			D8: Slow stop
			D7: Start
			D3: Gross/net weight switch
			D2: Clear Tare
D1: Remove the tare			
D0: Zero			
Parameter modification			
14	Request to write the value modbus address	DWord	Modbus write operation address (note that the MODBUS write operation will not be written when the address changes.) This parameter modifies the modbus address range supported by the interface module only from 0100 to 02119
16	Input data	DWord	Write this data to the " modbus address of the requested value" (note that it will only be written to the instrument if the value has changed)
17	The address of the requested read	DWord	Modbus read operation address (note:cannot read two-word addresses, write an odd-numbered address). This parameter modifies the range of MODBUS addresses supported by the interface module only from 0100 to 02119

3.8.2 Device description file EDS

EDS and connection methods of GMC-X1LF can be downloaded from the website of Shenzhen General Measure Technology Co., LTD. (www.gmweighing.com).

3.9 EtherCAT Communication

GMC-X1LF has two bus connection ports: NET1 and NET2. Any computer with a network interface card and embedded devices with Ethernet control can be used as a master station for EtherCAT, such as devices such as Huichuan PLC. The instrument can also be connected via Twincat software on a PC computer, in any case within the same local area network as the instrument. The following parameter table can be operated if the connection is successful.

3.9.1 Bus Settings

When the order is equipped with **EtherCAT** extension, **enter** the menu and press the left button to display the bus setting "EtherCAT", you can set the following parameters

EtherCAT	Initial value	Instructions
Site alias	00001	Range: 0-65535
Write Switch	Disable	Range: Disable/Enable; Acyclic parameters can be written only after they are turned on.

3.9.2 Cyclic parameter address

GMC-X1LF EtherCAT communication provides multi-byte **IO**, output in two modules, through which the master station can read and control the status of the weigh indicator.

Offset	Parameter name	Data type	Parameter Description
Weight and status bits, read register			
0	Displayed weight	Float	Weight currently displayed, floating point type
4	Real-time weight	Float	The weight of the subtractive method run, floating point type
8	Weight status flag bit	Word	D15: Communication heartbeat
			D13-D14 reserved
			D12: Bipolar
			D11: Calculate weight using theoretical values, (prompt user when calculating weight using theoretical values)
			D10: ADC failure, (ADC initialization failure or sampling interruption longer than expected)
			D9: Currently displayed net weight, (distinguish which weight is currently displayed)
			D8: millivolt stable, (when calibration millivolt stable sign)
			D7: loadcell negative overflow, lower than the loadcell voltage allowed range
			D6: loadcell positive overflow, beyond the loadcell voltage allowable range
			D5: Weight negative overflow, weight less than "-(Max range +9d)"
			D4: Weight positive overflow, weight greater than "Max range +9d"
			D3: Overflow condition, (abnormal weight or loadcell)
			D2: Displayed weight negative sign, (Displayed weight negative)

			D1: Zero, (weight in the range of 0+/- quarter d)
10	Error code 1	Word	D13-D15 Reserved
			D12: Remote calibration when disabled
			D11: In hardware protection during calibration
			D10: The previous weight point is not calibrated
			D9: Beyond minimum resolution (less than 0.1uV per division)
			D8: Weight input exceeds the maximum range
			D7: The weight input cannot be zero
			D6: Weight calibration is less than zero or the previous calibration point
			D5: Loadcell positive overflowing during weight calibration
			D4: Loadcell negative overflow during weight calibration
			D3: Weight calibration is unstable
			D2: Loadcell positively overflows during zero calibration
			D1: loadcell negatively overflow during zero calibration
			D0: zero calibration is unstable
12	Error code 2	Word	D15 Reserved
			D14: Run Forbid zero
			D13: The remote tare operation allow switch is not enabled during remote tare operation
			D12: The tare operation is not allowed in the net weight state
			D11: The weight negative overflow when taring
			D10: Loadcell positive overflow when taring
			D09: Loadcell negative overflow when taring
			D08: Unstable when taring
			D07: The net weight status does not allow zeroing
			D06: The remote zero switch is not enabled during remote zero
			D05: The loadcell positively overflow when zeroing
			D04: The loadcell neagatively overflow when zeroing
			D03: Unstable when zeroing
			D02: Zero out of range
			D01: Power-on zero is unstable
14	Process status flag bit 1	Word	D10-D15 Reserved
			D9: IO test status
			D8: Printing, (valid when the instrument is performing a printing operation)
			D6-D7: reserved
			D5:1: Pause
			D4:1: Slow Stop
			D3:1: Supply material
			D2:1: Lack material
			D1: Lower level
			D0: Upper level
16	Flow status flag bit 2	Word	D15: Wait for the stop signal
			D14: Zero Zone:1

			D13: Lower nozzle:1, Raise nozzle: 0
			D12: Push bucket
			D11: normal liquid filling completed (valid after setting value, zeroing after starting filling again)
			D10: alarm
			D9: Weigh OK
			D8: Waiting
			D7: Under Replenish
			D6: Under
			D5: Over
			D4: Fine Feed
			D3: Medium Feed
			D2: Coarse Feed
			D1: Before feeding
			D0: Run: 1, Stop: 0
18	Status Tips	Word	0- No action 1- load bucket 2- Wait for the start signal 3- Wait for the low level 4- Delay 5- Coarse Feed 6- Medium Feed 7- Fine Feed 8- Free Fall delay 9- Free Fall correction 10- Over/under 11- Under Replenish 12- Over/under pause 13- Raise nozzle 14- Waiting 15- Weigh OK 16- Pushing bucket 17- Waiting to stop 18- Pause 19- Batches completed
20	Process alarm	Word	D13-D15 Reserved D12: Batches complete alarm D11: Do not allow filling (reduction method, the current weight is below the lower limit of the material level, in the feeding state) D10: The material level is not set properly D9: Decrement protection D8: material leakage, when the coarse feeding flow is lower than the lower limit of coarse feeding flow, the instrument has the default material leakage, the instrument output buzzer alarm, the main interface prompts the material leakage, and stops D7: Over pause D6: Over/Under D5: Tare detection error D4: Bucket bump D3: OFL when starting

			D2: Lower nozzle/Raise nozzle function not defined, use step raise nozzle function
			D1: There is an undefined IO in the IO Module that must be defined
			D0: Formula setting unreasonable alarm
22	Target Value	Float	Range: 0~ Max range; The measured value per bucket during the cumulative process.
26	Coarse Reserve	Float	Range: 0~ Max range; In the process of measurement, if the weighing value $\geq$ the target value – Coarse Reserve, then close Coarse Feeding
30	Medium Reserve	Float	Range: 0~ maximum range; If the output IO is defined, in the measurement process, if the weighing value $\geq$ the target value – Medium Reserve, then close Medium Feeding
34	Free Fall	Float	Range: 0~ Max range; In the measurement process, if the weighing value $\geq$ the target value – Free Fall, then close fine Feeding
38	Upper limit Material level	Float	Instrument when stopping liquid filling, if feeding, stop feeding when this level is reached. (Note: when the scale structure is multi-head reduction, the parameter can be set)
42	Lower limit of material level	Float	When instrument stopping filling, if the material weight in the storage hopper is less than this lower limit, the feed output is valid (this lower limit must be greater than the filling target value, that means it must supply material when it is insufficient to fill the next bucket). (Note: when the scale body structure is multi-head reduction, the parameter can be set)
46	Read out value	DWord	The master station requests the data returned by the instrument, the value obtained according to the "address requested to read"
22	Target value	Float	Range: 0~ Max range; The measured value per irrigation during the cumulative process.
26	Coarse Reserve	Float	Range: 0~ Max range; In the process of measurement, if the weighing value $\geq$ the target value – coarse reserve, then close the coarse feeding
30	Medium Reserve	Float	Range: 0~ Max range; If the output IO is defined, in the measurement process, if the weighing value $\geq$ the target value – Medium Reserve, then close Medium Feed
34	Free Fall	Float	Range: 0~ Max range; In the measurement process, if the weighing value $\geq$ the target value – Free Fall, then close fine feeding
38	Upper limit of material level	Float	when instrument stopping filling, if feeding, stop feeding when this level is reached. (Note: when the scale body structure is multi-head reduction, the parameter can be set)
42	Lower limit of material level	Float	When instrument stopping filling, if the material weight in the storage hopper is less than this lower limit, the feed output is effective (this lower limit must be greater than the filling target value, that means it must be supply material when it is insufficient to fill the next bucket). (Note: when the scale body structure is multi-head reduction, the parameter can be set)

46	Read out value	DWord	The master station requests the data returned by the instrument, the value obtained according to the "address requested to read"
20	Process alarm	Word	D13-D15 Reserved
40	Formula weight low 9 points	DWord	D12: Batches complete alarm
42	Recipe ACUM Times	DWord	D11: Do not allow filling (decrement method, current weight below lower limit of material level, in feeding state)
44	Waiting weight	DWord	D10: Material level set improperly
Write register (Q address)			
0	Function operation	DWord	D18-D31 Reserve
			D18: Clear cumulative
			D17: Run once manually
			D16: Manual Fine Feed
			D15: Manual Coarse Feed
			D14: Lower Nozzle Complete
			D13: Taring and Start Liquid filling
			D12: Select recipe
			D11: Clear alarm
			D10: Pause
			D9: Emergency stop
			D8: Slow stop
			D7: Start
			D6: Print Feed paper
4	Target value	Float	D5: Print
			D4: Zero Calibration
			D3: Gross/net weight switch
			Range: 0~ Max range; The measured value per bucket during the cumulative process.
			Range: 0~ Max range; In the process of measurement, if the weighing value $\geq$ the target value – coarse reserve, then close coarse feeding
			Range: 0~ Max range; If the output is defined, in the measurement process, if the weighing value $\geq$ the target value – medium reserve, then close medium feeding
			Range: 0~ Max range; In the measurement process, if the weighing value $\geq$ the target value – Free Fall, then close fine feeding
			When the instrument stops filling, if the feed is performed, the feed stops when this level is reached. (Note: when the scale structure is multi-head reduction, the parameter can be set)
			When the instrument stops filling liquid, if the material weight in the storage hopper is less than this lower limit, the feed output is effective (this lower limit must be greater than the filling target value, that means it must be supply material when it is insufficient to fill the next bucket). (Note: when the scale structure is multi-head reduction, the parameter can be set)
8	Coarse Reserve	Float	
12	Medium Reserve	Float	
16	Free Fall	Float	
20	Upper limit of material level	Float	
24	Lower limit of material level	Float	

28	Gain calibration	Float	Write the weight value to the calibration weight calibration point 1
32	Request the written value modbus address	DWord	Modbus write operation address (note that no write is written when the address changes), this parameter modifies the range of MODBUS addresses supported by the interface module only to 0100-02119
36	Input data	DWord	Write this data to the " modbus address of the requested value" (note that it will only be written to the instrument if the value has changed)
40	The address of the requested read	DWord	Modbus read operation address (note that cannot read two-word addresses, write an odd-numbered address). The MODBUS address range supported by the interface module is limited to 0000-02119

3.9.3 Acyclic parameter addresses

Parameter names		Parameter Description	Index
Power on zero range	0	Range: 0~99(* full Scale %)	4000:1
Zero tracking range	1	0-99d	4000:2
Stable range	1	0-99d	4000:3
Zero range	20%	Range: 1~99(* full scale %)	4000:4
Digital filter parameters	4	0-9	4000:5
Steady filtering	0	0-99	4000:6
Units	kg	g,kg,t,lb	4000:7
Decimal point	0	Range: 0; 0.0; 0.00; 0.000; 0.0000	4000:8
Minimum division	d=1	Instrument indicates the minimum change in value	4000:9
Maximum range	10000	Range: 1,2,5,10,20,50,100,200,500	4000:10

3.9.4 Device description file ESI

The Equipment description file of **GMC-X1LF** and the detailed steps for using **PLC** and **Twincat** are available for **download** from the website of Shenzhen General Measure Technology Co., LTD. ((www.gmweighing.com)).