



杰 • 曼 • 科 • 技

GMT-H1

User Manual

110611030004

V03.00.08

Copyright © Shenzhen General Measure Technology Co., Ltd. All Rights Reserved.

Without the permission of Shenzhen General Measure Technology Co., Ltd. no unit or individual shall copy, transmit, transcribe or translate into other languages in any form or by any means.



Warning

The product adopts AC220V power supply.

Please keep the instrument well grounded.

The product is an electrostatic sensitive device. Take anti-static measures during use and maintenance

**Standards &
Certification**

Product standard: GB/T 7724-2008
Verification regulation: JJG 649-2016

CMC Accuracy Class 3;
Guangdong 0000000048;
Safety certification: CE

Content

Chapter 1 Overview	1
1.1 Functions and features	1
1.2 Technical Specifications	1
1.3 Panel Diagram	2
Chapter 2 Installation and Wiring	4
2.1 Connecting Power cables to the controller	4
2.2 Loadcell Connection	4
2.3 Connection of communication Ports	5
2.3.1 Serial port connection	5
2.3.2 Network port connection	6
Chapter 3 Menu overview	7
3.1 Parameters Selection and Setting	7
Chapter 4 Setting parameters of basic Cfg	9
Chapter 5 Calibration parameters	10
5.1 Zero Calibration	11
5.2 CAL Weight	12
5.3 Theory CAL	12
Chapter 6 Filling Function	13
6.1 Interface Description	13
Chapter 7 Application Settings	16
7.1 Application Setting Parameters	16
7.2 IO Description	17
7.3 History Data Parameters	19
Chapter 8 System Maintenance	20
8.1 IO Test	21
8.2 Communication Test	22
Chapter 9 MODBUS communication	23
9.1 Data -Trans Parameters	23
9.2 Modbus protocol	24
9.3 MODBUS Function Code and Exception Code	24

9.4 MODBUS Communication Address.....	25
Chapter 10 Automatic Sending Protocol.....	38
Chapter 11 GPRS Communication	40
11.1 GPRS Communication Parameters.....	40
11.2 GPRS data frame structure description	40
11.3 GPRS protocol	40
11.3.1 The heartbeat packets	40
11.3.2 In&Out materials report frames	42
11.3.3 Setting GPRS Communication Paras	43
11.3.4 Historical data frames	44
11.3.5 SIM card information	46
11.3.6 Clear the data logging.....	48
Chapter 12 YH Protocol	50
Chapter 13 Automatic reporting of the MAC protocol	51
Chapter 14 Product size.....	53

Chapter 1 Overview

1.1 Functions and features


Shell type	Suspension, waterproof housing
Loadcell interface	1 channel 6-wire analog loadcell weighing platform interface, connect up to 8 350 Ω loadcells at most.
Display	LCD Display Screen
Interface	1 channel 485 port (standard configuration); Supports Modbus-RTU and automatic sending protocols.
	1 RJ45 port(standard configuration); Supports Modbus-TCP and automatic sending protocols
	GPRS data transmission function
	Fixed I/O: 3 in and 3 out
	Variable IO: 3-way interface (can be customized for output/input function)
Weight calibration and calculation	Calculate the weight data by collecting the load cell, support the theoretical value calibration and weight calibration of two ways
Material level instrument function	Input scan through IO port to obtain material level information

1.2 Technical Specifications

Power supply	AC90-260 V50Hz (or 60 Hz) plus or minus 2%
Shell size	175*150*75mm
Product weight	750g
Authentication Environment	- 10 ~ 40 °C;90% R.H without dew
Operating environment	- 20 ~ 60 °C;90% R.H without dew
Storage environment	- 40 ~ 60 °C;90% R.H without dew
Power consumption	10W
Excitation voltage of Weighing platform	5V 200mA(MAX)
Weighing platform requirements	1 analog platform interface, connect up to 8 350 Ω loadcells, support 1mV/V, 2mV/V, 3mV/V sensitivity

Sensitivity/Certified sensitivity	0.1 uV/d, 0.5 uV/ d
Non-linearity	0.01% F.S
A/D conversion speed	Default value: 100 times/second (optional)
Maximum display accuracy	1/100000
Keys	4 key audible mechanical keys
Decimal position	0, 0.0, 0.00, 0.000; Four kinds of optional

1.3 Panel Diagram



Status Indicator Light:

POWER: Power indicator.

STABLE: Stability indicator. When the weighing platform or hopper material weight change in the stable range, the indicator light.

COMx: Communication indicator;

GPRS: GPRS communication indicator light;

Keyboard:

ZERO ESC (with a square icon): Zero/Esc key to exit the current operation/return to the previous menu key. Long press to zero (meet the conditions for

zeroing).

OPTION : Parameters selection key. When the main display flashes, press this button to add 1 to the flashing position. If the flashing position is 9, press this button to add 1 to the data. Press this key on the main interface to enter the filling and discharging quantitative operation interface.

MODE : Parameters setting function selection key. During data input operation, the main display flashing digit flashes. Press this key to move the flashing digit to the right. If the current flashing digit is the last digit, press this key to move the flashing digit to the leftmost digit.

ENTER : Confirm key, confirm to enter the current option during calibration or parameters setting; Confirm the entered data and end the operation.

Main interface switch key: Power on, the default display is the incoming and outgoing material content, press **ENTER** , It can switch to display the accumulative content of material in and out on the same day.

Chapter 2 Installation and Wiring

2.1 Connecting Power cables to the controller


The packaging controller uses 220V, 50Hz AC power supply with protective ground. The connection is as shown below:

Power terminal diagram

L-Live line

G-Ground line

N-Neutral line



2.2 Loadcell Connection

GMT-H1 module shall be externally connected with resistance strain bridge loadcell, and the loadcell shall be connected to the module as shown below. When a four-wire loadcell is selected, the SN+ and EX+ of the module must be short-circuited, and the SN- and EX- must be short-circuited. Each port of the loadcell connection terminal is assigned to:


Port	EX+	SN+	EX-	SN-	SIG+	SIG-	SHLD
6 wire	Power positive	Loadcell positive	Power negative	loadcell negative	signal positive	Signal negative	Shielding wire
4 wire	positive		negative		signal positive	Signal negative	Shielding wire

Notice:

1. Because the loadcell output signal is more sensitive to electronic noise analog signal, so loadcell wiring should be shielded cable, and laid separately with other cables, especially away from the AC power supply;

2. For the transmission distance is short and the temperature change is not large occasions or precision requirements are not high occasions can choose the four-wire loadcell; But for the application of long transmission distance or high precision requirements should choose the six-wire loadcell;


3. When multiple loadcells are connected in parallel, ensure that the sensitivity (mV/V) of each loadcell is the same.



2.3 Connection of communication Ports

The product supports one channel 485 and one channel RJ45 network port and **4G** communication, and supports Modbus-RTU/HL Modbus-RTU/Auto Send/ Auto Send (MAC)/YH protocol. The network port communication supports MODBUS-TCP /HL Modbus-TCP / Auto Send/ Auto Send (MAC) protocol. (see Section 9 for settings of communication parameters and communication addresses)

2.3.1 Serial port connection




2.3.2 Network port connection

The instrument is equipped with a network communication interface, which is connected with an RJ-45 crystal head to realize communication with the host computer or PLC.


Modbus/TCP/Auto-Report/Auto-Report_MAC communication protocol is adopted. After inserting the network cable, the green indicator light of the network port slot is always on, indicating that the network cable is connected well, and the orange indicator light flashes, indicating that the network card has received network data.



Chapter 3 Menu overview




3.1 Parameters Selection and Setting



- 1) In the main interface, press **MODE**  enter parameters setting interface.
- 2) Press **OPTION** , **MODE**  to switch selection parameters.
- 3) Press **ENTER**  to complete the parameters settings.
- 4) Press **ZERO**  to exit.

Parameters Settings:



- 1) **OPTION** , **MODE** ; Switch parameters value.

Chapter 4 Setting parameters of basic Cfg

Parameters		Functional description
Zero Cfg	PWR-ON Zero	Set zero range during power-on. If the value is 0, the zero range will not be performed during power-on. Initial value: 0;Parameters Range: 0 to 99%
	Zero Range	Sets the range that zeroing is allowed. Initial value: 20%;Parameters Range: 0 to 99%
STAB And TrZero	STAB Timer	In this time, the weight change range is not greater than STAB Range, considered stable. Initial value: 1.000s;Parameters Range: 0.100 to 9.999s.
	STAB Range	During the Stable time, the weight variation range is not greater than STAB range, and it is considered stable. Initial value: 1d;The value ranges from 0 to 99d
	TrZero Time	In the set time, the weight change range is less than the Tr-Zero Range, automatic tracking zero. Initial value: 1.000s;Parameters Range: 0.100 to 9.999 seconds
	TrZero Range	When the weight change range is less than this set Tr-Zero Range, zero will be automatically tracked. Initial value: 0d;The value ranges from 0 to 99d
FIR And Sample	Digit-Filter	Digital filter, the higher the level, the stronger the filtering, but the longer the response time. Initial value:4;Parameters Range: 0 to 9
	Adv. Filter	Steady-state filter, which is enabled when the weight is in a steady state. The higher the level, the stronger the filtering, but the longer the response time. Initial value: 0;Parameters Range: 0 to 9
	Sample Rate	Sampling frequency, initial value: 100 times/s. Range: 50,60,100,120,200,240,400,480 times/s. Optional.
Basic Reset		Press ENTER(Confirm Key) to restore the factory Settings of weighing parameters.

Chapter 5 Calibration parameters

Parameters		Functional description
Wt. Format	Unit	A unit used for indicating weight. Initial value: kg Range: 0:kg/1:g/2:t/3:lb
	Decimal	The number of decimal points used for weight indication. Initial values: 0. Parameters range: 0/0.0/0.00/0.000
	Division	The smallest unit of change in weight. Initial value: 1. Parameters: 1/2/5/10/20/50/100/200/500 (d)
	Full Scale	Maximum weight that can be displayed. Initial value: 10000 Parameters range: 1~(100000* division)
Weight CAL	Auto Capture	The actual millivolt of the current loadcell is displayed
	Key In mV	Input the zero millivolt value manually for zero calibration without weight.
	CAL Weight	Perform weight calibration parameters
Theory CAL	LC mV/V	Average value of the true sensitivity of the connected loadcell, initial value: 2.0000.Range: 0.0001-5.0000 mV/V
	LC Capacity	The sum of the real range of the loadcell; Initial value: 10000 Range: 0-999999
	Use T-CAL	Choose to enable the theoretical value to calibrate and calculate the weight; Initial value: OFF. Range: ON/ OFF
Correct Coef		Used to correct the weight value, the showing weight=correction factor * weight calculated by the calibration parameters (theoretical value parameters);Initial value: 1.0000. Range: 0.00001-9.99999
CAL Reset		Press ENTER(Confirm Key) and input the

	calibration password to restore the factory Settings of the calibration parameters.
--	---

5.1 Zero Calibration

Zero calibration function can be completed by interface operation and communication port operation.

Interface operation: Weighing interface --> [Calibration] menu --> [WT. Format]

Auto Capture

Auto	Capture	STAB
2.760mV		
■ Cancel		● Enter

Stable/Unstable: The loadcell status is only allowed in a stable state.

2.270mV: the millivolt of the current loadcell (the actual value)

■ Key---Cancel: Press  Key to exit the automatic zero calibration interface.

● Key---Enter: Press  Key to complete zero calibration (zero calibration operation can be completed only in a stable state. Otherwise, an alarm interface will pop up.

Note: 1) Automatic zero calibration defines the current state as zero. The platform should be emptied before execution.

2) Record "current loadcell millivolt value", so as to carry out "input zero calibration" when it is inconvenient to empty the platform.

【Key In mV】

Manually input millivolt value for weightless calibration.

5.2 CAL Weight

CAL Weight		0.027 mv
000000 kg		
■ Cancel	● Enter	STAB

Calibration steps:

- 1) Enter the weight calibration interface
- 2) Add weights to the weighing table
- 3) Valid until stable output
- 4) Enter the weight corresponding to the weight value
- 5) Press **ENTER**  Key to complete weight calibration.

5.3 Theory CAL

The theoretical value calibration refers to the weight calibration operation through the input connection of load cell sensitivity and load cell range value.

Theoretical value calibration requires 3 steps:

- 1) Set load cell sensitivity (for example, connect multiple loadcells and enter the average value of sensitivity)
- 2) Set the total loadcell range (such as connecting multiple loadcells, input the sum of the total loadcell range)
- 3) Turn on the "Use T-CAL" switch.

Chapter 6 Filling Function

6.1 Interface Description

Press the **OPTION**  key on the main interface, Enter the quantitative operation interface, which is divided into filling operation and discharging operation. Click on the filling/discharging operation to enter the corresponding filling/discharging operation interface as follows.

DISC: 5000kg
Start Stop Pause
Done:2356kg/ Discharging
Cur WT :11193kg

Filling: 9000kg
Start Stop Pause
Done:3366kg/ Filling
Cur WT :12026kg

6.2 Parameters Description

Parameters		Function Description
Filling Parameters	DISC Value	Quantitative discharging involves discharging materials of a specified weight. Once the discharging process is initiated and the set discharging weight is reached, the discharging stops. Initial value: 0 Range: 0-999999
	Filling Value	Quantitative feeding involves loading materials of a specified weight. Once the feeding process starts, it stops when the set feeding weight is reached. Initial value: 0 Range: 0-999999
	Done(DISC)	The weight of the material that has been cut so far after the cutting is initiated. Display the weight of the previous cutting before cutting.

	Done(Filling)	The weight of the material that has been fed so far after the feeding is started. Display the weight of the last cut before loading.
	Cur Weight	The real-time weight currently displayed.

6.3 Operating Instructions

DISC Operation:

When entering this interface, move the cursor to "Start" by pressing **MODE**  key. Press **ENTER**  key to start the discharging process. If the discharging output is defined, this switch output is valid. If the cursor is moved to the "Stop" button and the **ENTER**  key is pressed, the discharging will stop. After the discharging stops, the output of the discharging switch quantity will be invalid. Start discharging. If the current weight is less than the discharging weight, an alarm will be triggered. You can choose to continue or cancel. During the discharging process, you can switch to the "Pause" button to perform the pause operation of this discharging. When the discharging is paused, the "discharging" in Progress sign changes to "Pause" in progress. Press "Start" discharging again, and then continue the blanking process from the previous pause until the blanking target quantity is completed. The current weight is equal to the weight of the discharging material. After it stabilizes, it will be included in the accumulation.

Note: If you want to directly end the current blanking process during the pause, click "Stop " operation once to end the previous blanking process.

Filling Operation:

Move the cursor to "Start "filling by pressing the **MODE**  key, then press the **ENTER**  key to start the loading process. At the same time, the output of the filling IO is effective. After the feeding starts, the cursor flashes on the "Stop" button. Pressing the **ENTER**  key will stop the feeding. After the feeding stops, the output of the feeding IO is invalid. When starting the feeding process, if the completed feeding exceeds the set maximum range, an alarm will prompt that the current feeding will overflow. You can choose to continue or cancel. During the feeding process, you can switch to the pause button to perform the pause operation of this feeding. When the feeding is paused, the "Filling " in Progress sign changes to "Pausing" in progress. Press the start filling button again, and then continue the filling process from the previous pause until the feeding target quantity is completed.

Note: If you want to directly end the current feeding process during the pause, click "Stop"Operation once to end the previous feeding process.

Chapter 7 Application Settings

7.1 Application Setting Parameters

Parameters		Functional description
In/Out Manage	Min In WT	When the positive weight change is greater than this value, the instrument considers that feeding operation has occurred. If 0, no judgment feeding operation is performed Initial value: 1;Range: 0-999999
	Min Out WT	When the negative weight change is greater than this value, the instrument considers that discharging operation occurs; If 0, no judgment operation will be performed Initial value: 1;Range: 0-999999
	PreDelay of In/Out	In the set period of time, the weight does not change, it is considered that completing the material in and out. Initial value: 1.000s;Range: 0.100 to 99.999
	In/Out Stable Delay	If the weight remains unchanged within the set time period, it is considered that the feeding and discharging process is complete . Initial value: 5.000s;Range: 0.100 to 99.999
	Allow People On/Down	The up and down switch for feeding and discharging materials. When this switch is turned on, when feeding or discharging materials at a constant speed, the weight of the person on the upper or lower part of the material tank (the person has not come down) should be reduced after the feeding and discharging process is completed. It is only suitable for a single person to go up and down, and the time interval between each up and down movement is 10 seconds. Initial value:ON.
IO Setting		Set the functions of the input port, output port and free port. For specific operations, please refer to the IO instructions in Section 7.1.1.
Auto Send ON/OFF		After this function is enabled, the incoming and outgoing material frames in GPRS communication will be automatically reported. Initial value: ON; Range: ON/OFF

App Reset	Press ENTER(Confirm key) and input the calibration password to restore the factory Settings of the calibration parameters.
-----------	--

7.2 IO Description

The standard configuration of the instrument includes 3 input interfaces and 3 output interfaces. There are 3 input and output ports that can be defined by yourself. It can achieve up to 6 input or output channels, thereby enabling the instrument to connect with external devices.

Each input and output port can be set by oneself. The factory definitions of the input and output ports are as follows.

Default definition:

Input		Output	
IN1	I1 Manual Filling	OUT1	O1 Fill
IN2	I2 Manual DISC	OUT 2	O2 DISC
IN3	I3 Stop	OUT 3	O0 None
Free Port IO: IO1 is for I4 to pause filling and discharging, and all other free ports are none.			

Input port function description

Code	Function	Description
0	None	If the port number is defined as 0, it indicates that this input port is undefined.
1	Manual Filling	This signal is valid. Proceed with the filling operation.
2	Manual DISC	This signal is valid and the instrument performs the discharging operation.
3	Stop	If this signal is valid, the instrument will stop the loading and unloading state.

4	Pause	If this signal is valid, the instrument will pause loading and unloading. Re-input to start loading and unloading.
----------	--------------	--

Output port function description

Code	Function	Description
0	None	If the port number is defined as 0, it indicates that this input port is undefined.
1	Fill	When loading materials, this signal output is valid.
2	DISC	When discharging materials, this signal output is valid.

Free Port Setting

This controller provides three freely defined interfaces, which users can define as input or output interfaces as needed.

- (1) Under the free port setting parameters item, select "IN" to define the free port as an input port. You can set the corresponding input port functions. For specific definitions, please refer to the above input port function description.
- (2) Click "OUT" to define the free port as an output port, and you can set the corresponding output port function. For specific definitions, please refer to the above output port function description.

※ Adaptive feeding and discharging parameters:

To cope with small flow rates of about 1 to 3 tons per hour, the weight is detected every 30 seconds without feeding or adding materials. Each time the weight increases or decreases by more than 9 for three consecutive times, the feeding and discharging parameters are automatically adjusted (the delay before feeding and discharging is changed to 0.5 seconds, the delay for checking the stability of feeding and discharging is changed to 30 seconds, and the minimum feeding and discharging weight is always 1).

7.3 History Data Parameters

Parameters	Functional description
Single Rec	Save 100 sets of single cumulative historical data.
Daily ACUM	Record the cumulative data of incoming and outgoing materials for the day.
Total ACUM	Record the total cumulative data of incoming and outgoing materials.
Clr Single Rec	Clear single record operation
Clr Daily ACUM	Clear single day cumulative operation
Clr All ACUM	Clear Total Accumulated Operations

Chapter 8 System Maintenance

Parameter		Instruction
Language Setting	Switch between Chinese and English display; initial value: Chinese; optional: 中文/English/Russian.	
Info Search	Software Version	View the compilation date and time and corresponding version information of the front and backend.
	MAC Addr.	Check the MAC address, modification is not supported.
	Date Time	Set current time and date.
IO Test	Input Test	Input/output test function. For details, please refer to Section 8.1 .
	Output Test	
COM Test	Receive test	Serial communication test function, please see Section 8.2 for details.
	Send test	
Reset Manage	Basic Reset	Press the [Enter] key to restore the weighing parameter values of the instrument to the factory settings.
	CAL Reset	Press the [Enter] key to restore the instrument calibration parameter values to the factory settings.
	APP Reset	Press the [Enter] key to restore the instrument application parameter values to the factory settings.
	COM Reset	Press the [Enter] key to restore the instrument communication parameter values to the factory settings.
	Historical Data Reset	Press the [Enter] key to clear historical data such as single records, single-day accumulation, and total accumulation with one click.
	Partly Reset	Press the [Enter] key to restore all parameter values of the instrument except calibration to factory settings.
	Reset All	Press the [Enter] key to restore all parameter values of the instrument to factory settings.

	Filling Reset	Press the [Enter] key to restore the instrument filling parameter values to the factory settings.
PWD. Manage	Basic PWD. Setting	This item is used to modify the password of various parameters and whether the password protection function needs to be turned on. Turn on protection: "On/Off" is optional. Off: Users do not need to enter a password to enter the corresponding parameters. On: Users need to enter a password to enter the corresponding parameters. Password modification: Users can change the password value of the selected parameter item by themselves。
	CAL PWD. Setting	
	APP PWD. Setting	
	COM PWD. Setting	
	Sys. PWD. Setting	
APP Mode	Mode 1	In Mode 1, the initial value of the serial communication protocol is: Modbus-RTU, and the initial value of the network port communication protocol is: Modbus-TCP.
	Mode 2	Using Mode 2, the initial value of the serial port communication protocol is: HL Modbus-RTU, and the initial value of the network port communication protocol is: HL Modbus-TCP.

8.1 IO Test

This item tests the input and output ports as well as the free port to check whether the external input and output are correctly connected. IO can be tested through the communication address.

Test method :

1) Input port I1~I3 and free port IO1~IO3 test: After the external wiring is connected, when the external signal input is valid, the corresponding input definition port under the interface from --> indicates that the input interface connection is correct. When the external input is valid but the interface shows no response, it indicates an abnormal connection. Check the

switch power input, wiring, etc.


2) Output port O1~O3 and free port IO1~IO3 test: After the external wiring is connected, click the corresponding output port from □->■. The corresponding external connection output status should be valid. If not, it indicates an abnormal connection. Check the switch power input, wiring, etc.

8.2 Communication Test

The serial port test function sends and receives data in a fixed baudrate (9600) and data format (8-N-1) to test the serial port connection status.

1) Send test: send data "TEST-nnn".

2) Receiving test: externally send test data (only ASCII code) to the instrument, and display the data on the display, the length of each frame of data should not exceed 10 bytes.



- 1) Enter serial port receive test interface.
- 2) Host computer send ASCII data
- 3) If instrument shows the data of host computer have send, it indicated serial port connects normally.

Chapter 9 MODBUS communication

9.1Data -Trans Parameters

		Parameters	Description
COM (RS485)	COM ID		Slave serial number used by serial port 1. Initial value: 1. Parameters range: 1 to 247. This only works if the communication protocol has a slave number.
	Baudrate		1200, 9600, 38400, 19200, 57600, 115200 are optional. Initial value: 38400bit/s
	Data format		Parameters range: 8-E-1, 8-O-1, 8-N-1, 7-E-1, 7-O-1 (data bit, parity bit, stop bit). Initial value: 8-E-1. The Modbus RTU protocol can be 8-E-1, 8-O-1, or 8-N-1.
	Protocol		Modbus_RTU/Auto Send/YH、Auto Send (MAC)/ HL Modbus_RTU. Initial value: Modbus RTU
	Dword Format		Parameters range: AB-CD, CD-AB. Initial value: AB - CD
	Send Gap		Continuous sending interval, initial value 0.000, range 0.000-9.999s
TCP	IP Addr.	Local IP address(Modbus TCP mode usage)	Initial value: 192.168.101.246; Parameters range: 0.0.0.0 to 255.255.255.255
		Target IP (Use of auto send mode)	
	Socket	Local Socket (Modbus TCP mode usage)	Initial value: 502; Parameters range: 0 to 65535
		Target Socket (Use of auto send mode)	
	Mask		Initial value: 255.255.255.000, Parameters range: 0.0.0.0 to 255.255.255.255
	Gateway		Initial value: 255.255.255.001, Parameters range: 0.0.0.0 to 255.255.255.255
	Protocol		Modbus TCP/Auto Send/ Auto Send(MAC)/HL Modbus TCP. Initial value: Modbus TCP

	Dword Format	Parameters range: AB-CD, CD-AB. Initial value: AB - CD
	Send Gap	Continuous sending interval, initial value 0.000, range 0.000-9.999s
	C/S Mode	Parameter range: Server, Client. Initial value: server (Only applicable to auto send and auto send_MAC protocol) Client mode: Just set the target IP address and target socket number and it will automatically connect to the target server. Server mode: only need to set the local IP address and local socket number.
GPRS	For details, please refer to Chapter 11.1 GPRS Communication Parameters.	
COM Reset	Press the 【Enter】 key to restore the communication parameter values of the instrument to the factory Settings.	

9.2 Modbus protocol

GMT-H1 Supports 1 way RS485 serial port and 1 network port. Supports Modbus-RTU(serial port), Modbus-TCP/IP(network port) communication mode and automatic sending mode. Among them, the HL Modbus protocol is a splendid customized protocol. The register address reading and writing adopt the 04 function code, and the coil address is not processed. The specific modbus address can be referred to the MODBUS Communication Address Table in [Section 9.4.](#)

9.3 MODBUS Function Code and Exception Code

◆ Function codes supported by the instrument:

Function code	Item	Instructions
03	Read register	Up to 125 single read registers
06	Write a single register	Up to 125 single read registers
16	Write multiple	This transmitter command only supports

	registers	writing to the double register. When writing, the address must be aligned. It is not allowed to write only part of the double register.
01	Read the coil	Note that this length is in bits.
05	Write the coil	

Note: this instrument only supports the above MODBUS function codes, the instrument will not respond to other function codes.

◆ MODBUS exception code response

Code	Item	meaning
02	Illegal data address	This error code indicates that the data address received is not allowed.
03	Illegal data value	The data written is not in the allowed range.
04	Computer	An unrecoverable error occurred while the transmitter was attempting to perform the requested operation.
07	Unsuccessful programming request	For the transmitter, the command received cannot be executed under the current conditions.

9.4 MODBUS Communication Address

Function address	PLC address	Meaning	Instructions
The following is readable (read function code 0x03)			
0000-0001	40001-40002	Weight status	Sign, int
0002	40003	Weight status	D12-15 Reserved. Return 0
			D11 Use theoretical weights
			D10 Reserved. Return 0
			D9 Reserved. Return 0
			D8 Millivolt stability (the flag for millivolt stability during calibration)
			D7 Negative loadcell overflow, lower than the allowable loadcell voltage range
			D6 The loadcell is overflow,

				exceeding the allowable loadcell voltage range
			D5	Weight negative overflow, weight less than "- (maximum range + 9d)"
			D4	Weight overflow, weight greater than "maximum range + 9d")
			D3	Overflow status, (abnormal weight or loadcell
			D2	Display weight negative sign,(display weight negative)
			D1	Zero point (weight within 0+/- 1/4 d range)
			D0	Stability (Stability sign for weight stability assessment)
0003	40004	Process status bit	D15	Feeding
			D14	Discharging
			D0-13	Reserved
0004-0011	40005-40012	Reserved		
0012	40013	Read the weight	Signed, integer (only used for HL Modbus RTU/TCP.	
0013	40014	预留		
0014-0015	40015-40016	Weight Value	Display values, including signed and floating-point types	
0016-0023	40017-40024	Reserved		
0024-0025	40025-40026	AD internal code after filtering	After filtering AD original code	
0026-0027	40027-40028	Loadcell voltage	Input the voltage values of loadcell, 4 decimal points	
0028-0029	40028-40030	Relative zero voltage	The relative of the zero voltage, 4 decimal points	
0030-0039	40031-40040	Reserved		
0040	40041	Calibration Error Code	bit12-bit15	Read-only, returns 0
			bit11	The maximum range is too large
			bit10	The maximum range is too small

			bit9	Beyond minimum resolution
			bit8	Weight input exceeds maximum range
			bit7	Input Weight cannot be zero
			bit6	The relative zero voltage is negative
			bit5	Loadcell overflow during weight calibration
			bit4	Negative loadcell overflow during weight calibration
			bit3	Weight calibration is unstable
			bit2	Loadcell overflow during zero calibration
			bit1	Negative loadcell overflow during zero calibration
			bit0	Zero calibration is unstable
0041	40042	Zeroing error code	bit6-bit15	Read-only, returns 0
			bit5	The loadcell overflow during zeroing
			bit4	Negative loadcell overflow during zeroing
			bit3	Unstable at zeroing
			bit2	Out of range at zeroing
			bit1	unstable during power-on zeroing
			bit0	Power-on zeroing exceeds the threshold
0042-0046	40043-40047	Reserved		
0047	40048	Input status area(IN1-IN3)	bit3-bit15	Read-only, returns 0
			bit2	Input 3 status
			bit1	Input 2 status
			bit0	Input 1 state
0048	40049	Output status area (OUT1-OUT3)	bit3-bit15	Read-only, returns 0
			bit2	Output 3 state
			bit1	Output 2 state
			bit0	Output 1 state

0049	40050	Customizing I/O status area (IO1-IO3)	bit3-bit15	Read-only, returns 0
			bit2	Custom IO3 status;1: valid (input mode: valid, output mode: valid)
			bit1	Custom IO2 status;1: valid (input mode: valid, output mode: valid)
			bit0	Custom IO1 status;1: valid (input mode: valid, output mode: valid)
0050-0099	40051-40100	Reserved		
0100-0101	40101-40102	PWR-On Zero Range	Initial value: 0 (The power-on and reset function is disabled) Range: 0~99% (full scale percentage)	
0102-0103	40103-40104	Reserved		
0104-0105	40105-40106	Zero Range	Initial value: 20; Range:0~99%(full scale percentage)	
0106-0113	40107-40114	Reserved		
0114-0115	40115-40116	STAB Range	Initial value: 1d;Range: 0 ~ 99 d	
0116-0117	40117-40118	STAB Time	Initial value: 3.000;Range: 0.100 ~ 9.999s	
0118-0119	40119-40120	Trzero Range	Initial value: 2d;Range: 0 ~ 99 d	
0120-0121	40121-40122	Trzero Time	Initial value: 3.000;Range: 0.100 ~ 9.999 s	
0122-0123	40123-40124	Digital Filter	Initial value: 8;Range: 0 ~ 9	
0124-0125	40125-40126	Adv. Filter	Initial value: 8;Range: 0 ~ 9	
0126-0127	40127-40128	AD Sample Rate	Initial value: 2; Range: 0~7; corresponding to 50-480 times/second respectively.	
0128-0199	40129-40200	Reserved		
Calibration para area, the following content is readable and writable (read function code is 0x03, write function code is 0x16)				
0200-0201	40201-40202	Unit	Initial value: 0; Range: 0: kg, 1: g, 2: t, 3: lb	
0202-0203	40203-40204	Decimal point	Initial value: 0 (0); Range: 0:0; 1-0. 0; 2-0. 00; 3-0. 000	
0204-0205	40205-40206	Division	Initial value: 1; Range: 1/2/5/10/20/50/100/200/500 d	
0206-0207	40207-40208	Full Scale	Initial value: 50000;Range: 1~999999	

0208-0209	40209-40210	Reserved	
0210-0211	40211-40212	Auto Capture	Write: 1 for zero calibration Read: the current sensor millivolts
0212-0213	40213-40214	Key In mV	0-15000 (3 decimal points), Write: write the voltage value as the zero point voltage Reading: the mV number of the current zero point)
0214-0215	40215-40216	CAL Weight	Write: weight value standard gain. Read: gain millivolt value.
0216-0223	40217-40224	Reserved	
0224-0225	40225-40226	LC mV/V	Write: Sensitivity value Read: Sensitivity value set last time
0226-0227	40227-40228	LC Capacity	Enter the sum of all loadcell ranges
0228-0229	40229-40230	Use T-CAL	0: disables the function of calculating the theoretical weight 1: Using the theoretical value to calculate the weight
0230-0231	40231-40232	Correct Coef	Fixed 5 decimal points
0232-0299	40233-40300	Reserved	
Process para area, the following contents are readable (read function code is 0x03)			
0300-0301	40301-40302	Reserved	
0302-0303	40303-40304	Minimum feed weight(min in WT); Initial value: 10; Range: 0~999999	
0304-0305	40305-40306	Minimum discharge weight(min out WT) Initial value: 10; Range: 0~999999	
0306-0307	40307-40308	In/Out Stable Delay Initial value: 05.000 ; Range: 0.1-99.999	
0308-0349	40309-40350	Reserved	
100 pieces of historical single incoming and outgoing material data			
0350-0351	40351-40352	Article 1 Start time of feeding and discharging (month/year/day) The first and second bytes are years, the third byte is months, and the fourth byte is days	
0352-0353	40353-40354	Article 1 Start time of feeding and discharging (hour/minute/second) The first byte is 0, the second byte is hour, the third byte is minute, and the fourth byte is second	
0354-0355	40355-40356	Article 1 Historical weight of incoming and outgoing materials. Negative number means discharge, positive number means incoming material	
0356-0949	40357-40358	Article 2 Start time of feeding and discharging (year, month, day)	

		The first and second bytes are the year, the third byte is the month, and the fourth byte is the day.
0358-0359	40359-40360	Article2 Start time of feeding and discharging (hours, minutes and seconds) The first byte is 0, the second byte is hours, the third byte is minutes, and the fourth byte is seconds.
0360-0361	40361-40362	Article 2 Historical weight of incoming and outgoing materials the negative number is the output material, the positive number is the input material
0362-0949	40363-40950	You can read the remaining 98 groups (100 groups in total) of historical incoming and outgoing material information according to the above two sets of historical incoming and outgoing material reading sequence examples 40351-40362. When there are more than 100 pieces of data, the first piece of data will be removed. That is, up to 100 pieces of incoming and outgoing material data can be read.
60 sets of single-day input and output data		
0950-0951	40951-40952	Day 1 feeding time (year, month, day)
0952-0953	40953-40954	The cumulative weight of the incoming materials on day 1
0954-0955	40955-40956	The cumulative weight of the discharged material on day 1
0956-0957	40957-40958	Day 2 feeding time (year, month, day)
0958-0959	40959-40960	The cumulative weight of the incoming materials on day 2
0960-0961	40961-40962	The cumulative weight of the discharged material on day 2
0962-1309	40963-41310	You can follow the example of reading the order of incoming and outgoing materials from 40951 to 40956 above, and read the cumulative data of incoming and outgoing materials from the last 59 (total of 60 days) days.
1. 4x00951-4x00956 of PLC address is the oldest data accumulated in a day 2. If 60 pieces of data are stored, 4x01305-4x01310 of PLC address is the latest data accumulated in a day 3. If 60 records are added, the old records will be deleted and new records will be added. The second-to-last will be offset to the oldest data, which still satisfies 1,2 above		
Total cumulative weight		
1310-1311	41311-41312	Total feed accumulated
1312-1313	41313-41314	Total output accumulated
1314-1399	41315-41400	Reserved
IO Setting		

1400-1401	41401-41402	IN1 definition	0- None 1- Manual Filling 2- Manual DISC 3- STOP 4- PAUSE
1402-1403	41403-41404	IN2 definition	
1404-1405	41405-41406	IN3 definition	
1406-1407	41407-41408	OUT1 definition	0- None 1- Fill 2- DISC
1408-1409	41409-41410	OUT2 definition	
1410-1411	41411-41412	OUT3 definition	
1412-1413	41413-41414	IO1 definition	Write the corresponding function code and refer to the definition code of the input and output. (Note: Defined as an input function, write the input interface function code at the corresponding address;) Define it as an output function. Write "Output interface function code +100" at the corresponding address.
1414-1415	41415-41416	IO2 definition	
1416-1417	41417-41418	IO3 definition	
1418-1449	41419-41450	保留	
1450	41451	IO test switch	Test the switch, which is readable and writable. Write 1 to turn on the switch quantity test, and write 0 to turn off the switch quantity test
1451	41452	IN1 Test	Reading out 0 indicates no input, and reading out 1 indicates there is input.
1452	41453	IN2 Test	
1453	41454	IN3 Test	
1454-1459	41455-41460	Reserved	
1460	41461	OUT1 Test	Range: 0-1, Write: 0: Off output, 1: On output (only valid in IO test mode), read is the current IO port state, 0: off, 1: on
1461	41462	OUT2 Test	
1462	41463	OUT3 Test	
1463-1469	41464-41470	Reserved	
1470	41471	IO1-IN1 Test	Refer to the test parameters from IN1 ~IN3
1471	41472	IO2-IN2 Test	
1472	41473	IO3-IN3 Test	
1473-1479	41474-41480	Reserved	
1480	41481	IO1-OUT1 Test	Refer to the test parameters from OUT1 ~OUT3
1481	41482	IO2-OUT2 Test	

1482	41483	IO3-OUT3 Test	
1483-1507	41484-41508	Reserved	
Quantitative parameters, readable and writable			
1508-1509	41509-41510	Fill	Write 1 to start filling
1510-1511	41511-41512	Discharge	Write 1 to start discharging
1512-1513	41513-41514	Stop	Write 1 for filling and discharging
1514-1515	41515-41516	Pause	Write 1 to pause filling and discharging
In the serial port para area, the following contents are read/write bit status (read function code is 0x03, write function code is 0x06)			
8000	48001	RS485 Slave ID	Initial value:1. Range: 1 to 247
8001	48002	RS485 Baud rate	Initial value 0:38400 0:9600/1:19200/2:38400/3 : 57600/4:115200 optional
8002	48003	RS485 Protocol	Initial value: 0:Modbus_RTU 0: Modbus_RTU; 1: Auto Send; 2:Auto Send(MAC);3:HL Modbus_RTU
8003	48004	RS485 Data Format	Initial value: 0:8-E-1.Range: 0:8-E-1; 1:8-O-1; 2:8-N-1; 3: 7-E-1; 4:7-O-1 (meaning: data bit---parity bit---stop bit)
8004	48005	RS485 Dword Format	Initial value: AB-CD. 0: AB-CD; 1:CD-AB
8005	48006	RS485 comm Interval	Range: 0 ~ 9999
8006-8099	48007-48100	Reserved	
In the network port para area, the following contents are read/write bit status (read function code is 0x03, write function code is 0x06)			
8100	48101	TCP protocol	0: Modbus TCP/IP; 1: Auto Send;2:Auto Send(MAC);3:HL Modbus_TCP
8101	48102	Dword Format	Initial value: AB-CD. 0: AB-CD; 1:CD-AB
8102	48103	Network port Sending interval	Range: 0 ~ 9999

8103	48104	Local IP1	IP address. Initial value: 192.168.101.246 Para ranges: 0.0.0.0 - 255.255.255.255
8104	48105	Local IP2	
8105	48106	Local IP3	
8106	48107	Local IP4	
8107	48108	Target IP1	
8108	48109	Target IP2	
8109	48110	Target IP3	
8110	48111	Target IP4	
8111	48112	Loacal Network port	Initial value:502. Para range:0-65535
8112	48113	Destination Network port	
8113	48114	Network port subnet mask 1	Initial value: 255.255.255.000; Parameter range: 0.0.0.0~255.255.255.255
8114	48115	Network port subnet mask 2	
8115	48116	Network port subnet mask 3	
8116	48117	Network port subnet mask 4	
8117	48118	Network Port Gateway 1	Initial value: 192.168.000.001; Parameter range: 0.0.0.0~255.255.255.255
8118	48119	Network Port Gateway 2	
8119	48120	Network Port Gateway 3	
8120	48121	Network Port Gateway 4	
8121-8249. 48122-48250. Reserved			
8250	48251	GPRS target IP1	Initial value: 192.168.101.246, Parameter range: 0.0.0.0~255.255.255.255
8251	48252	GPRS target IP2	
8252	48253	GPRS target IP3	
8253	48254	GPRS target IP 4	
8254	48255	GPRS target port	Initial value: 502; Parameter range: 0~65535
8255	48256	GPRS heart rate	Initial value: 30s. Range: 0-3600s
8256	48257	GPRS ON/OFF	0: GPRS is disabled. 1: GPRS is enabled
8257	48258	GPRS reactivate	Write only, 1: active
8258	48259	The GPRS IMEI1	read-only
8259	48260	The GPRS IMEI2	

8260	48261	The GPRS IMEI3	
8261	48262	The GPRS IMEI4	
8262	48263	The GPRS IMEI5	
8263	48264	The GPRS IMEI6	
8264	48265	The GPRS IMEI7	
8265	48266	The GPRS IMEI8	
8266	48267	The GPRS IMSI1	
8267	48268	The GPRS IMSI2	
8268	48269	The GPRS IMSI3	
8269	48270	The GPRS IMSI4	
8270	48271	The GPRS IMSI5	
8271	48272	The GPRS IMSI6	
8272	48273	The GPRS IMSI7	
8273	48274	The GPRS IMSI8	
8274-8799	48275-48900	Reserved	
Reset para area, the following contents are read/write bit state (read function code is 0x03, write function code is 0x06)			
8900	48901	Reset all	Reset para address area: Write 1 in the corresponding address to reset the para. For example, write 1 to address 8900 to complete the reset of all parameters
8901	48902	Reset all(except calibration parameters)	
8902	48903	Reset Calibration parameters	
8903	48904	Reset Basic parameters	
8904	48905	Reserved	
8905	48906	Reset Application parameters	
8906	48907	Reset historical parameters	
8907	48908	Reset serial port parameters	
8908	48909	Reset network port Paras	
8909	48910	Reset GPRS paras	
8910	48911	Reset all communication parameters	
8911	48912	Reset filling parameters	
8912-9999	48913-410000	Reserved	
The following is a read-only area (read function code 0x03)			
10000	410001	Back-end Software Version (high word)	View the product software version and compilation date address area
10001	410002	Back-end Software Version (low type)	
10002	410003	Back-end Compilation Date (high type)	
10003	410004	Back-end Compilation Date (low type)	
10004	410005	Instrument serial number 1th character	
10005	410006	Instrument serial number 2th character	
10006	410007	Instrument serial number 3th character	
10007	410008	Instrument serial number 4th character	

10008	410009	Instrument serial number 5th character
10009	410010	Instrument serial number 6th character
10010	410011	Instrument serial number 7th character
10011	410012	Instrument serial number 8th character
10012	410013	Instrument serial number 9th character
10013	410014	Instrument serial number 10th character
10014	410015	Instrument serial number 11th character
10015	410016	Instrument serial number 12th character
10016	410017	Instrument serial number 13th character
10017	410018	Instrument code 01th character
10018	410019	Instrument code 02th character
10019	410018	Instrument code 03th character
10020	410021	Instrument code 04th character
10021	410022	Instrument code 05th character
10022	410023	Instrument code 06th character
10023	410024	Instrument code 07th character
10024	410025	Instrument code 08th character
10025	410026	Instrument code 09th character
10026	410027	Instrument code 10th character
10027	410028	Instrument code 11th character
10028	410029	Instrument code 12th character
10029	410030	Reserved
10030	410031	Instrument model character 1
10031	410032	Instrument model character 2
10032	410033	Instrument model character 3
10033	410034	Instrument model character 4
10034	410035	Instrument model character 5
10035	410036	Instrument model character 6
10036	410037	Instrument model character 7
10037	410038	Instrument model character 8
10038	410039	Instrument model character 9
10039	410040	Instrument model character 10
10040-10099	410041-410100	Reserved
10100	410101	Network port 0 Instrument Mac address 1, 0-255
10101	410102	Network port 0 Instrument Mac address 2, 0-255
10102	410103	Network port 0 Instrument Mac address 3, 0-255
10103	410104	Network port 0 Instrument Mac address 4, 0-

		255	
10104	410105	Network port 0 Instrument Mac address 5, 0-255	
10105	410106	Network port 0 Instrument Mac address 6, 0-255	
10106-10299	410107-410300	Reserved	
The following content is the readable and writable area (the function code for reading is 0x03)			
10106	410107	Custom URL characters 1, 0-255	Address 10106. Write 0 or 255. The website address will not be displayed
10107	410108	Custom URL characters 2, 0-255	
10108	410109	Custom URL characters 3, 0-255	
10109	410110	Custom URL characters4, 0-255	
10110	410111	Custom URL characters5, 0-255	
10111	410112	Custom URL characters6, 0-255	
10112	410113	Custom URL characters7, 0-255	
10113	410114	Custom URL characters8, 0-255	
10114	410115	Custom URL characters9, 0-255	
10115	410116	Custom URL characters10, 0-255	
10116	410117	Custom URL characters11, 0-255	
10117	410118	Custom URL characters12, 0-255	
10118	410119	Custom URL characters13, 0-255	
10119	410120	Custom URL characters14, 0-255	
10120	410121	Custom URL characters15, 0-255	
10121	410122	Custom URL characters16, 0-255	
10122	410123	Custom URL characters17, 0-255	
10123	410124	Custom URL characters18, 0-255	
10124	410125	Custom URL characters19, 0-255	
10125	410126	Custom URL characters20, 0-255	
10126	410127	Custom URL characters21, 0-255	
10127	410128	Custom URL characters22, 0-255	
10128	410129	Custom URL characters23, 0-255	
10129	410130	Custom URL characters24, 0-255	
10130	410131	Custom URL characters25, 0-255	
10131	410132	Custom URL characters26, 0-255	
10132	410133	Custom URL characters27, 0-255	
10133	410134	Custom URL characters28, 0-255	
10134	410135	Custom URL characters29, 0-255	

10135	410136	Custom URL characters 30, 0-255	
10136-10299	410137-410300	Reserved	
Function coil address, readable and writable (read function code is 0x01, write function code is 0x05)			
300	00301	Reset all parameters	Write 1 to perform the corresponding reset operation, and read it all as 0
301	00302	Reset Partly(except calibration)	
302	00303	Reset Calibration parameters	
303	00304	Reset Basic parameters	
304	00305	Reserved	
305	00306	Reset Application parameters	
306	00307	Reset historical parameters	
307	00308	Reset Serial port parameters	
308	00309	Reset network port parameters	
309	00310	Reset GPRS parameters	
310	00311	Reset all communication parameters	
311	00312	Reset quantitative parameters	
312-399	0033-00400	Reserved	
Coil address, readable and writable (read function code 0x01, write function code 0x05)			
400	00401	Input IN1	Bit read-only area, read bit each input, output port status,1:valid, 0:invalid
401	00402	Input IN2	
402	00403	Input IN3	
403	00404	Output OUT1	
404	00405	Output OUT2	
405	00406	Output OUT3	
406	00407	Customizable IO1	
407	00408	Customizable IO2	
408	00409	Customizable IO3	

Chapter 10 Automatic Sending Protocol

GMT-H1 Serial port and network port communication can be reported continuously. It can automatically upload instrument status, weight information and material information according to the set interval time. Format of automatically reporting data when there is no incoming or outgoing status.

STX	Slave ID	State	Symbol +/-	Weight	checksum	0D	0A
-----	----------	-------	------------	--------	----------	----	----

Among:

STX——1 byte, start character, 02H

Slave ID——3 bytes, Range: 001 - 247

+/-——1 byte, +:2BH; -:2 DH.

Weight——7 bytes, including decimal point, high to 0 without decimal point

Checksum——2 bytes, checksum. Calculation: add all the preceding values and convert them to decimal, then take the last two digits and convert them to ASCII. For example, if the sum of 02 30 30 31 41 2B 20 30 30 30 30 39 35 32 39 31 0D 0A is 24F, the value is 591 in decimal notation. If the last two digits are 9 and 1 are ASCII, the value is 39 31

Status:

Status bit description								
Order	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Define	-	-	-	-	-	1-zero	1-overflow	1-stable
describe	0	1	0	0	0	0-not zero	0-normal	0-unstable

Automatically report data format when incoming or outgoing material state

STX	Slave ID	In&Out	Start time	End Time	Weight	Checksum	0D	0A
-----	----------	--------	------------	----------	--------	----------	----	----

In&Out-- 1 byte, I(In) : 49H;O(Out) : 4FH

Start/End time--12 bytes, corresponding to year, month, day, hour, minute, second.

For example, the following data is reported,

02 30 30 31 4F 32 30 31 31 32 30 31 39 35 31 33 35 32 30 31 31 32 30 31 39 35 31 35 38 20 30 30 30 37 36 37 38 33 0D 0A

The reported information is,

Slave ID: 01

State: Discharge

Start time: 19:51:35, 20th Of November, 2000

End time: 19:51:58, 20th Of November, 2000

Weight data: 767

The reported data are,

02 30 30 31 40 2B 20 30 30 33 37 35 35 39 34 0D 0A

The reported information is,

Slave ID: 01

State: current weight is positive (not in and out state)

Weight data: 3755

Chapter 11 GPRS Communication

11.1 GPRS Communication Parameters

Target IP	The IP address of the server for communication; Initial value: 192.168.101.246, Range:000.000.000.000-255.255.255.255
Target Socket	The IP port number of the server for communication; Initial value: 10081
Heart Rate	The heartbeat packet frequency connected to the server during communication; Initial value: 60s.Range: 30-3600s
COM ON/OFF	Whether to enable GPRS communication or reactivate it; Initial value: ON;
IMEI IMSI	The IMEI and IMSI information of the GPRS chip cannot be modified
GPRS Status	View the current GPRS status
Signal Strength	Check the current signal strength of GPRS. 0-11: Communication is prone to disconnection. 12-18: Unstable communication 19-30: Stable communication, 31: Best signal 99: No signal

11.2 GPRS data frame structure description

Data Format	Frame header 1	Frame header 2	Frame length 1	Frame length 2	Command code	Data content	End
Sender	0xFE	0xFE	2 bytes, 6+ number of bytes of data content		0x01-0x7F	See specific protocol	0xED
Respond end	0xFE	0xFE	2 bytes, 6+ number of bytes of data content		0x80 command code	See specific protocol	0xED

11.3 GPRS protocol

11.3.1 The heartbeat packets

Heartbeat packets	Byte No.	Instrument - > PC	Content	PC -> Instrument	The reply content
	1	0xFE			

Single Direction (no reply)	2	0xFE	The fixed frame header	The PC No Response	The PC No response
	3	0x00	Data frame length		
	4	0x13			
	5	0x01	The command code		
	6	Instrument MAC1	Instrument MAC address		
	7	Instrument MAC2			
	8	Instrument MAC3			
	9	Instrument MAC4			
	10	Instrument MAC5			
	11	Instrument MAC6			
	12	Weight data 1	Current weight, float type, signed data		
	13	Weight data 2			
	14	Weight data 3			
	15	Weight data 4			
	16	Material level data	The lower six bytes correspond to input 1-6		
	17	Decimal	0 to 4 represent different decimal places		

	18	Unit	0: kg, 1: g, 2: t, 3: lb		
	19	0XED	terminator		

11.3.2 In&Out materials report frames

In&Out	Byte No.	Instrument - > PC	Report Content	PC -> Instrument	The Reply content	
Two-way (with reply)	1	0xFE	The fixed frame head	0xFE	The fixed frame head	
	2	0xFE		0xFE		
	3	0x00	Data frame length	0x00	Data frame length	
	4	0x21		0x07		
	5	0x02	Command code	0x82	Return command code	
	6	Instrument MAC1	Instrument MAC address	Receiving state	0x01:succ eeded; 0x00 : fail ed	
	7	Instrument MAC2		0XED	terminator	
	8	Instrument MAC3		Note that if the data reporting is unsuccessful, it needs to be saved on the instrument end. At least 200 pieces of unreported feed or discharge data should be saved respectively and reported again until it is successful. The input and output data generated by the		
	9	Instrument MAC4				
	10	Instrument MAC5				
	11	Instrument MAC6				
	12	Year	Display in two bytes			
	13					
	14	Month	The end time of in and out materials			
	15	Day				
	16	Hour				
	17	Minute				

	18	Second		input and output events are stored in a queue and sent to the server side one by one in a first-in-first-out manner. The unsent data is backed up in the power-off memory to prevent data loss after power failure. After the instrument starts up normally, it will check whether there is any unsent historical data in the power-off memory. If there is, it will be read into the sending queue and sent one by one. If not, continue to wait for the occurrence of the feeding and discharging incident
	19	In & Out marks	0x00 In, 0x01Out	
	20	Cumulative count 1	The total cumulative number of incoming or outgoing times	
	21	Cumulative count 2		
	22	Cumulative count 3		
	23	Cumulative count 4		
	24	Weight data1	Incoming or outgoing material this time, floating-point type, signed data	
	25	Weight data2		
	26	Weight data3		
	27	Weight data4		
	28	Weight data1	Total cumulative weight value of incoming or outgoing, floating-point type, with signed data	
	29	Weight data2		
	30	Weight data3		
	31	Weight data4		
	32	Decimal	0 to 4 represent different decimal places	
	32	Unit	0: kg, 1: g, 2: t, 3: lb	
	33	0XED	End	

11.3.3 Setting GPRS Communication Paras

GPRS	Byte No.	PC -> Instrument	Report Content	Instrument - > PC	The Reply content
Two-way	1	0xFE	The fixed	0xFE	

(with reply)	2	0xFE	frame head	0xFE	The fixed frame head
	3	0x00	Data frame length	0x00	Data frame length
	4	0x0E		0x09	
	5	0x03	The command code	0x83	Return command code
	6	Download serial Number (high 8 digits)	Download para serial number	Download serial Number (high 8 digits)	Corresponding download para serial number
	7	Download serial number (lower 8 bits)		Download serial number (lower 8 bits)	
	8	Target IP1	New target IP address	Receiving state	0x01: succeeded, 0x00:failed
	9	Target IP2		0XED	End
	10	Target IP3			
	11	Target IP4			
	12	Target port1	New destination port		
	13	Target port2			
	14	0XED	End		

11.3.4 Historical data frames

Get historical data	Byte No.	PC -> Instrument	Report Content	Meter->PC	Response content description
Two-way	1	0xFE	Fixed frame header	0xFE	Fixed frame header
	2	0xFE		0xFE	

(response)	3	0x00	Data frame length	Data frame length (High 8 bit)	Data frame length
	4	0x0E		Data frame length (Low 8 bit)	
	5	0x04	Command code	0x84	Return command code
	6	Download serial number (High 8 bit)	Download parameter serial number	Download serial number (High 8 bit)	Corresponding download parameter serial number
	7	Download serial number (Low 8 bit)		Download serial number (Low 8 bit)	
	8	Year	Query the starting point of time for in&out materials	Total quantity of in&out materials	The number of in&out materials during the time period
	9	Month		Quantity of this transfer	The number of frames transmitted this time
	10	Day		The remaining amount	Remaining untransmitted quantity of in&out materials
	11	Year	Query the end point of loading and unloading time	MAC1	Meter MAC Address
	12	Month		MAC2	
	13	Day		MAC3	
	14	0XED	End	MAC4	
	15			MAC5	
	16			MAC6	

	17		Year	In and out time
	18		Month	
	19		Day	
	20		Weight data1	The current cumulative weight value of the feed, floating point type
	21		Weight data2	
	22		Weight data3	
	23		Weight data4	
	24		Weight data1	Current discharging cumulative weight value, floating point type
	25		Weight Data2	
	26		Weight Data3	
	27		Weight Data4	
		If the queried data exceeds the maximum amount of data that can be carried by the protocol in one frame, the instrument will report the data in multiple frames until the data reporting is completed.	In&Out material data 2,3,.....N	
	N		0XED	End Character

11.3.5 SIM card information

After each successful connection of the APP, upload the IMEI number, IMSI number and SIM card number of the GPRS module of the instrument

In and Out reporting frame	Byte sequence No.	Instrument - > PC	Reported content
	1	0xFE	Fixed frame header
	2	0xFE	

Two-way (with response)	3	0x00	Data frame length
	4	0x3E	
	5	0x03	Command code
	6	Instrument MAC1	Instrument MAC
	7	Instrument MAC2	
	8	Instrument MAC3	
	9	Instrument MAC4	
	10	Instrument MAC5	
	11	Instrument MAC6	
	12	IMEI1 of GPRS	IMEI number
	13	IMEI2 of GPRS	
	14	IMEI3 of GPRS	
	15	IMEI4 of GPRS	
	16	IMEI5 of GPRS	
	17	IMEI6 of GPRS	
	18	IMEI7 of GPRS	
	19	IMEI8 of GPRS	
	20	IMEI9 of GPRS	
	21	IMEI10 of GPRS	
	22	IMEI11 of GPRS	
	23	IMEI12 of GPRS	
	24	IMEI13 of GPRS	
	25	IMEI14 of GPRS	
	26	IMEI15 of GPRS	
	27	IMS1 of GPRS	IMS1 number
	28	IMS2 of GPRS	
	29	IMS3 of GPRS	
	30	IMS4 of GPRS	
	31	IMS5 of GPRS	
	32	IMS6 of GPRS	
	33	IMS7 of GPRS	
	34	IMS8 of GPRS	

	35	IMSI9 of GPRS	
	36	IMSI10 of GPRS	
	37	IMSI11 of GPRS	
	38	IMSI12 of GPRS	
	39	IMSI13 of GPRS	
	40	IMSI14 of GPRS	
	41	IMSI15 of GPRS	
	42	ICCID1	SIM card number
	43	ICCID2	
	44	ICCID3	
	45	ICCID4	
	46	ICCID5	
	47	ICCID6	
	48	ICCID7	
	49	ICCID8	
	50	ICCID9	
	51	ICCID10	
	52	ICCID11	
	53	ICCID12	
	54	ICCID13	
	55	ICCID14	
	56	ICCID15	
	57	ICCID16	
	58	ICCID17	
	59	ICCID18	
	60	ICCID19	
	61	ICCID20	
	62	0XED	End Character

11.3.6 Clear the data logging

In and Out reporting frame	Byte sequence No.	Instrument - > PC	Reported content	Instrument PC	-> Response content
----------------------------------	-------------------------	----------------------	---------------------	------------------	------------------------

Two-way (with response)	1	0xFE	Fixed frame	0xFE	Fixed frame
	2	0xFE	header	0xFE	header
	3	0x00	Data frame	0x00	Data frame
	4	0x0D	length	0x0D	length
	5	0x04	Command code	0x84	Return command code
	6	Instrument MAC1	Instrument MAC	Instrument M AC1	Instrument MAC
	7	Instrument MAC2		Instrument M AC2	
	8	Instrument MAC3		Instrument M AC3	
	9	Instrument MAC4		Instrument M AC4	
	10	Instrument MAC5		Instrument M AC5	
	11	Instrument MAC6		Instrument M AC6	
	12	0x01	Clear the record	Receiving status	0x01 cleared successfully 0x00 Clearing failed
	13	0xED	End Character	0xED	End Character

Chapter 12 YH Protocol

When the serial communication protocol is selected as the YH protocol, the data frame format is automatically adjusted to 8-n-1 and the baud rate is automatically adjusted to 1200. The sending interval time is automatically adjusted to 50ms.

Under this protocol mode, data is output in ASCII code format, and each frame of data consists of a total of 9 groups (including decimal points). Data transmission starts with the lower bit and then the higher bit. There is a set of delimiters "=" between each frame of data. The transmitted data is the gross weight. For example, the current gross weight is 70.15, and continuous transmission is 51.0700=51.0700...

For example: 123.9

Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7	Bit8
=	9	.	3	2	1	0	0	0

Among them:

If the high bits are insufficient, add 0. The decimal point occupies 1 byte.

When the number is negative, Bit8 is a negative sign "-".

Chapter 13 Automatic reporting of the MAC protocol

The product communication protocol supports the automatic reporting data format protocol with MAC address. The instrument status, MAC address, weight information and in and out material information can be automatically uploaded at set time intervals.

Automatically report the data format in the state of no entry or exit

STX	Slave ID	MAC Address	Status	Sign +/-	Weight	Check Sum	0D	0A
-----	----------	-------------	--------	----------	--------	-----------	----	----

Among them:

STX – 1 byte, start character, 02H

Slave ID - 3 bytes, range 001 to 254

MAC address - the last six bytes

+/- -- 1 bytes, + : 2BH; : 2DH

Weight - 7 bytes, including decimal points. The higher digit is 0 when there is no decimal point

Checksum - 2 bytes, checksum. Calculation method: Add up all the preceding values and convert to decimal, then take the last two digits and convert to ASCII code. For example, the sum of the data 02 30 30 31 39 33 44 45 42 43 41 2B 20 30 30 31 33 32 33 36 32 0D 0A is 3C2. This value is converted to decimal as 962, and the last two digits are 6 and 2, which are converted to ASCII as 36 32.

Status:

Status bit description								
Order of position	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Define	Reserved	Reserved	Reserved	Reserved	Reserved	1-Zero	1-OFL	1-Stable
Description	Fixed0	Fixed1	Fixed0	Fixed0	Fixed0	0-Non-Zero	0-Normal	0-Unstable

In the inbound and outbound states, automatically report the data

format

STX	Slave ID	MAC Address	In&Out material	Start Time	End Time	Weight	Check Sum	0D	0A
-----	----------	-------------	-----------------	------------	----------	--------	-----------	----	----

In&Out material - 1 byte, I(feeding) : 49H; O(Discharge) : 4FH

Start/end time - 12 bytes, corresponding respectively to: year, month, day, hour, minute, second.

For example, the reported data is:

02 30 30 31 39 33 44 45 42 43 4F 32 30 31 31 32 30 31 39 35 31 33 35 32 30
31 31 32 30 31 39 35 31 35 38 20 30 30 30 37 36 37 36 31 0D 0A

Then the reported information is:

Slave ID: 01

Status: Discharge

Start time: 19:51:35 on November 20, 2020

End time: 19:51:58 on November 20, 2020

Weight data: 767

The reported data is:

02 30 30 31 40 2B 20 30 30 33 37 35 35 39 34 0D 0A

Then the reported information is:

Slave ID: 01

Condition: The current weight is positive (not in the state of feeding and discharging)

Weight data: 3755

Chapter 14 Product size

