



杰 · 曼 · 科 · 技

GMT-P1

User Manual

©2015, Shenzhen General Measure Technology Co., Ltd reserves all copyright.

Without permission from Shenzhen General Measure Technology Co., Ltd.,

Any corporations or person must not copy, spread, record or translate into other language by any forms.

Our company reserved the right to update user's manual without additional notice to customers by reason of update, so please visit our website or contact with our service person to get update information.

Website: <http://www.gmweighing.com>

CONTENTS

1 General Description	1
1.1 Functions and Characteristics	1
1.2 Front Panel	2
1.3 Rear Panel	3
1.4 Technical Specifications	5
1.4.1 Common:	5
1.4.2 Analog:	5
1.4.3 Digital:	6
2 Installation and Wiring	7
2.1 Connection of Power Supply	7
2.2 Connection of Load Cell	7
2.2.1 6 wires connection	8
2.3 I/O terminals	9
2.4 Optional Expansion Board Output	10
2.4.1 Analog Output (Optional)	10
2.4.2 Serial Interface RS485 Output	13

2.4.3 Serial Interface RS232 output (Optional).....	14
3 Calibration	15
3.1 Instruction	15
3.2 Flow Chart of Calibration.....	16
3.3 Millivolt Value Display.....	21
3.4 Calibration with Weights.....	22
3.5 No weight calibration	22
3.5.1 No weight zero Calibration.....	22
3.5.2 No weight gain Calibration.....	24
Historical gain calibration.....	24
Theoretical value gain calibration.....	26
3.6 Calibration Switch for Communication Interface	27
3.7 Explanation for Calibration Parameters	27
4 Working Parameters Setting.....	29
4.1 Flow Chart of Working Parameters Setting	29
4.2 Parameter Setting Method	30
4.3 Descriptions of Operation Parameters	31

4.4 Set point parameters	36
5 I/O Definition	39
5.1 I/O Definition	39
5.2 I/O testing.....	42
6 Serial Communication	44
6.1 r-Cont.....	44
6.2 r-SP1.....	45
6.2.1 Parameters Code Chart	45
6.2.2 Error Code Explanation.....	46
6.2.3 Command	47
6.3 tt TOLEDO Protocol	52
6.4 Cb920	53
6.5 rECont	55
6.6 rEREAD	55
6.7Modbus.....	56
6.7.1 Modbus communication address	57
6.8PT650D protocol	65

6.9 Yh protocol.....	66
6.10WI-125 Protocol	66
7 Password Input and Setting, Reset.....	68
7.1 Password Input.....	68
7.2 Password Setting	69
7.3 Factory Reset	70
8 Display Testing.....	72
9 Errors and Alarm Messages.....	73
10 Indicator model user-defined function	74
11 Dimension of Indicator	76

1 General Description


GMT-P1 weighing indicator is specially designed for weight transmitting in industrial fields.

This indicator has the features of small volume, plenty communicating commands, stable performance, easy operation and practicability. It can be widely applied to concrete and bitumen mixing equipment, metallurgy furnace and converter, chemical industry and feed, etc. .

1.1 Functions and Characteristics

- Small volume, unique design, easy operation
- Applicable to all kinds of resistance strain gauge bridge load cell
- Front panel numerical calibration
- Multilevel of digital filter
- Automatic zero -tracking
- Automatically zero when powered on
- 4 set points
- 1 input and 2 outputs
- Serial communication interface:RS232 or RS485
- Calibration via serial interface
- Optional interfaces: Analog output, serial interface

1.2 Front Panel



Main Display: 6 digits, for displaying weight and the information of parameters.

Status Indicator Lamp:

- **ZERO:** Light on when present weight is within $0 \pm 1/4d$.
- **STAB:** Light on when changes of weight values are within the range of motion detecting during motion detecting time.
- **NET:** The indicator light of gross and net weight and communication status is displayed according to the requirements of working parameter F1.8

Keypad:

ZERO
ESC ■ : Zero/Esc, Used to exit from current operation or go previous. Long press this key for zero calibration (limited by zero clearing range, not limited by calibration lock).


TARE
OPTION ▲ : Used to scroll optional values of parameter and to make flashing digit increase 1 while data inputting.

MODE ► : Function Selecting Key, to make flashing position move to the right digit when data inputting. Long-press the key will start to transmit data and it will flicker.

W/A
ENTER ● : Confirming Key. When calibrating or setting parameters, confirm entering the current option. The data input operation confirms the data and ends the operation.

Note: Under the status of gross weight, user could remove tare by pressing OPTION key, and if press Esc key in net weight mode, it will add tare weight, while it is zeroing under the status of net weight. It will show net weight value after tare, meanwhile the NET light is on.

1.3 Rear Panel



1.4 Technical Specifications

1.4.1 Common:

Power supply: **DC24V±5%**

Working temperature: **-10~40°C**

Max humidity: **90%R.H without dew**

Power consumption: **About 10W**

Dimension: **110×89×60 (mm)**

1.4.2 Analog:

Load cell power: **DC5V 200mA (MAX)**

Input impedance: **10MΩ**

Zero steady range: **0.00~15mV(Load cell 3mV/V)**

Input sensitivity: **0.01uV/d**

Input range: **0.00~15mV(Load cell 3mV/V)**

Transfer mode: **Sigma - Delta**

A/D conversion speed: **30, 60, 120,240, 480, 960 times/sec**

Non-linearity: **0.01% F.S**

Gain drift: **10PPM/°C**

Display Precision: **1,000,000d**

1.4.3 Digital:

Weight display: **6 digits red high-brightness LED**

Minus display: “-”

Overload display: “OFL”


Decimal point: **5 kinds (optional)**

Function keys: **4 keys soniferous keypad**

2 Installation and Wiring

2.1 Connection of Power Supply

GMT-P1 weighing indicator connects DC24V power supply as follows:



Power supply connection

2.2 Connection of Load Cell

GMT-P1 weighing indicator connects bridge type resistance strain gauge load cells by 6 wires or 4 wires as follows. When you use 4-wired load cells, you must bridge the SN+ with EX+ and bridge the SN- with EX-.


The signal definition of each port of the load cell connector is as follows:

EX+: Excitation+ **EX-:** Excitation- **SN+:** Sense+ **SN-:** Sense- **SIG+:** Signal+ **SIG-:** Signal-

6 wires	EX+	SN+	EX-	SN-	SIG+	SIG-	Shield
---------	-----	-----	-----	-----	------	------	--------

4 wires	EX+	EX-	SIG+	SIG-	Shield
---------	-----	-----	------	------	--------


2.2.1 6 wires connection



Note:

1. As load cell output sensitive analog signal, please use shield cable to separate with other cables, especially AC power.
2. 4 wires connection is suitable for short distance and stable temperature or low precision field, otherwise use 6 wires connection.
3. For more load cells parallel connection, their sensitivity (mV/V) should be same.


2.3 I/O terminals




I/O tolerant definition as follows:

Output		Input	
OUT1	Stable	IN1	No definition
OUT2	OFL		

Indicator input terminal connection:



Indicator input terminal connection:




2.4 Optional Expansion Board Output

GMT-P1 weighing indicator supports analog output, RS232 or RS485 as optional output function, please confirm it when place orders.

2.4.1 Analog Output (Optional)

If the instrument is equipped with an analog expansion board, it will have an analog output function. The output mode can be selected in the parameter list (see Section 4.3). At normal displaying status, press $\frac{W/A}{ENTER}$ ● to check the analog output. Format A X.XXX.

The definition of analog output as below:




The definition of analog output:
V+: voltage-output+, **V-**: voltage-output-
I+: current-output +, **I-**: current-output -


Analog output two types:

- 1) Voltage output: 0-5V/0-10V is optional .
- 2) Electric current output: 4-20mA/0-20mA/0-24mA is optional.
- 3) User-define function, users can define analog output type and output range.

The analog output has been calibrated before the delivery of the indicators, so users do not need to make calibration. If analog output is abnormal, users can calibrate by themselves as follows: (Suggestion: please calibrate under the instruction of professionals)



Note: only support calibration under current mode. 4 points must be finished for current calibration.





This interface is the highest point calibration of analog output.


In the interface of highest point calibration, press $\frac{W/A}{ENTER}$ ● to enter into analog display value interface, the display will be 5 digits (initial value is **24000**, means **24.000mA**), press $\frac{W/A}{ENTER}$ ● to input the value measured by the multimeter.


Note: Analog output calibration, highest point must be calibrated.

2.4.2 Serial Interface RS485 Output

Serial Interface RS485 output is optional, please refer to chapter 6.0 for communication protocol.


RS485 serial interface connection:





2.4.3 Serial Interface RS232 output (Optional)

RS232 serial interface connection:




3 Calibration

3.1 Instruction

- (1) Calibration procedure must be executed when a GMT-P1 indicator is put in use at the first time, the preset parameters may no longer meet the user's needs, and any part of the weighing system was changed. Position of decimal point, minimum division, maximum capacity, zero, and gain can be set and confirmed through calibration.
- (2) If you want to set only one parameter, please press $\frac{W/A}{ENTER}$ ● to save parameter's value and then press $\frac{ZERO}{ESC}$ ■ to exit.
- (3) Please see section 3.7 for parameters instruction.
- (4) Please record each value in the blank table in section 3.4 during calibration for the emergency use in future.
- (5) See chapter 9 for error alarm message that may be displayed during calibration.


3.2 Flow Chart of Calibration



1. Under this status, press **MODE** ► (twice), indicator will display **CAL**, then press $\frac{W/A}{ENTER}$ ● to enter password input.

2. After password is input, the indicator will display **CALON** for one second, then go to next step.

3. Press $\frac{TARE}{OPTION}$ ▲ to select a desired value for decimal point among **0**, **0.0**, **0.00**, **0.000** and **0.0000**, and then press **MODE** ► to save it and enter next step. If there's no need to change the value, press $\frac{W/A}{ENTER}$ ● directly to enter next step.



4. Press $\frac{\text{TARE}}{\text{OPTION}}$ $\blacktriangle$ to select a desired value for min. division among **1, 2, 5, 10, 20** and **50**, and then to save it and enter next step.
If there's no need to change the Min, division, then press $\frac{\text{W/A}}{\text{ENTER}}$ $\bullet$ directly to enter next step.
5. Input max. capacity ($\leq \text{min. division} \times 100000$), press $\frac{\text{W/A}}{\text{ENTER}}$ $\bullet$ to save it and enter Millivolt value display interface..
If there's no need to change the max. capacity, then press $\frac{\text{W/A}}{\text{ENTER}}$ $\bullet$ directly to enter Millivolt display interface.



Millivolt value display



Zero calibration

6. Under this status, press $\frac{W/A}{ENTER}$ ● to enter zero calibration.

Display value near the output value in millivolt between **SIG+/SIG-** of load cell.

See section 3.3 for details about this

7. Unloaded scale first, when **STAB** lamp is on, press $\frac{W/A}{ENTER}$ ● to finish zero calibration.


If there's no need to calibrate zero, press $\frac{ZERO}{ESC}$ ■ directly to enter gain calibration.

8. The process of gain calibration is as follows. If there's no need to do gain calibration, press

ZERO
ESC

■ directly to enter serial ports calibration switch setting.

Gain Calibration



Serial ports
calibration switch



Password setting



Normal status



9. Press $\frac{W/A}{ENTER}$ ● to enter setting interface, press $\frac{TARE}{OPTION}$ ▲ to choose the switch position, press $\frac{W/A}{ENTER}$ ● to set password. If don't need to set switch position, then press $\frac{ZERO}{ESC}$ ■ to enter password setting.

10. See section 7.2 for reference to set password. If there's no need to set password, press $\frac{ZERO}{ESC}$ ■ directly to go back to normal status.

3.3 Millivolt Value Display

This function is mainly used for system test, position-error test for weighing mechanism and linearity test for load cell.

1. System Test

(1) If display data changes with loaded weight changes, it shows that connection of load cell is correct and weighing mechanism works well.

(2) If display value is OFL (or -OFL), it means that loaded weight on load cells is too large (or too small). Please unload the weight (or load more), if display value is still OFL (or -OFL), the possible reasons are as follows:

- a. There is something wrong with weighing mechanism, please check and clear.
- b. The connection of load cell is incorrect, please check and clear.
- c. Load cells may be damaged, please replace.

2. Position-error Test for Weighing Mechanism

Load a same weight on each corner of weighing mechanism and record displayed millivolt value respectively. If differences among these values are obvious, please adjust weighing mechanism.

3. Linearity Test for Load Cell

Load same weight for several times, and record displayed value every time. If one or two values are obviously much larger or smaller than any others, it means that the linearity of load cell is bad.

***NOTE: You must use to zero display data before weight is loaded for each time.**

3.4 Calibration with Weights

In Chapter 3.2, steps 7 and 8 in the calibration flow chart are operation instructions of calibration zero point and calibration gain with weights

During calibration with weight, please record the zero millivolt value, gain millivolt value and the loaded weight value in the blank table below. If it is not convenient to load a weight to calibrate, these values can be used for calibration without weights.

	Zero millivolt value(mV)	Gain millivolt value(mV)	Loaded Weight	Date	Remarks
1					
2					
3					
4					
5					

3.5 No weight calibration

3.5.1 No weight zero Calibration

No weight calibration zero point, it is necessary to record the millivolt value corresponding to the empty balance when the mechanism is calibrated with weight. Zero calibration is accomplished by manually entering historical values.



- 1) In the calibration step 7, press $\frac{\text{TARE}}{\text{OPTION}}$ $\blacktriangle$ the button to enter the interface of zero millivolt manually.

- 2) Enter the zero millivolt value of the history.



- 3) Press $\frac{\text{W/A}}{\text{ENTER}}$ $\bullet$ to finish zero calibration, enter the gain calibration interface.




3.5.2 No weight gain Calibration

There are two methods for weighting - free calibration gain


- 1) Historical calibration: Gain calibration by entering historical record values
- 2) Theoretical calibration: Calibrate through sensor sensitivity and maximum range value of input mechanism (the sum of the average value of input sensitivity and maximum range when multiple sensors are connected)

Historical gain calibration



- 1) In gain calibration interface, press $\frac{\text{TARE}}{\text{OPTION}}$ ▲ , and the interface displays 1. Press $\frac{\text{W/A}}{\text{ENTER}}$ ● to enter the manual gain millivolt input interface and enter the historical millivolt value.
- 2) Press $\frac{\text{W/A}}{\text{ENTER}}$ ● save to enter the weight input interface and enter the weight value corresponding to the millivolt number.
- 3) Press $\frac{\text{W/A}}{\text{ENTER}}$ ● save to complete gain calibration and enter the serial port calibration switch.

Theoretical value gain calibration



- 1) In gain calibration interface, press twice $\frac{\text{ZERO}}{\text{ESC}}$ ■ to enter and choose "2" press enter interface for manual input of sensor sensitivity and input the sensitivity of the actual sensor.
- 2) Press $\frac{\text{W/A}}{\text{ENTER}}$ ● , enter the maximum range input interface and input sensor range.
- 3) Press $\frac{\text{W/A}}{\text{ENTER}}$ ● , complete gain calibration and enter serial port calibration switch.

3.6 Calibration Switch for Communication Interface

When calibrate the transmitter through serial port(Rs、 SP1 or Modbus), must set to “ON” status for the calibration switch for communication interface.

3.7 Explanation for Calibration Parameters


Symbol	Parameter	Types	Value of parameter	Default
Pt	Decimal Point	5	0 0.0 0.00 0.000 0.0000	0
1d	Min. Division	6	1 2 5 10 20 50	1
CP	Max. Capacity		$\leq \text{Min. Division} \times 100000$	10000
t	Millivolt Value			
o	Zero			
C	Gain			
SIOCAL	Switch for Calibration via serial interface			OFF
PASS	Password Setting			000000


Log Table for Calibration Parameters

Parameter	Calibrated Value	Date	Remarks
Decimal Point			
Min. Division			
Max. Capacity			
Load cell sensitivity			
Password			

4 Working Parameters Setting

4.1 Flow Chart of Working Parameters Setting





2 .Press $\frac{W/A}{ENTER}$ ● to enter into sub-selection,

Press $\frac{ZERO}{ESC}$ ■ to return back to previous menu.

When it displays **F2**,press $\frac{W/A}{ENTER}$ ● to enter into **F2.1**.

4.2 Parameter Setting Method


GMT-P1 has 2 kinds of working parameters: Selection type and data type. For

selection type parameters, press $\overline{\text{TARE}}/\text{OPTION}$ ▲ to choose. For data type parameter in parameter interface, press **MODE** ► to choose digit position, press $\overline{\text{TARE}}/\text{OPTION}$ ▲ to choose value.

Selection:



Data:



4.3 Descriptions of Operation Parameters

Code	Default	Description
F1	Null	The first major term of working parameter.

F1.1	OFF	Switch for Auto-Zeroing when power-on, OFF: disabled ON1: Auto-Zeroing when power-on; ON2: when power on, recall previous zero
F1.2	0	Zero-tracking Range (0~9d optional) . This parameter is for automatic calibration, disabled when is set "0".
F1.3	1	Motion Detecting Range (1~9d optional)
F1.4	50	Zeroing Range (00%~99% of Maximum capacity)
F1.5	5	Digital filtering parameter: (1-9 as optional) 0: without filtering 9: strongest digital filtering
F1.6	0	VF-Filter: 0: without filtering 9: strongest digital filtering
F1.7	0	A/D conversion rate: 120,480,960,15,30,60 as optional
F1.8	OFF	NET Indicator function switch OFF: NET Indicator light is the function of gross/net weight. Net weight is on, gross weight is off. ON: NET Indicator light has communication indicator function. When there is communication, indicator light flashes

F1.9	OFF	Switch for Tare Record。 ON: tare value will be recorded until new tare value obtained; OFF: tare value will be reset when indicator restart next time。
F2	Null	The second major term of working parameter
F2.1	01	Scale no., indicator no.
F2.2	38400	Baud rate of serial port:1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600
F2.3	Modbus-RTU	Serial ports communication mode: Modbus-RTU: MODBUS RTU mode; r-Cont:SP1 continuous mode; r-SP1: SP1 command mode; tt:TOLEDOcontinuous mode; Cb920: Cb920 continuous mode。 rE-Cont:rE continuous mode; rE- rEAd:rEcommand mode; Pt650D:Pt continuous mode; Yh:Yh continuous mode; WI-125 continuous mode;

F2.4	8-E-1	Data format: 7-E-1: 7 data bits, even parity check, 1 stop bit; 7-O-1: 7 data bits, odd parity check, 1 stop bit; 8-E-1: 8 data bits, even parity check, 1 stop bit; 8-O-1: 8 data bits, odd parity check, 1 stop bit; 8-n-1: 8 data bits, no parity check, 1 stop bit; 8-n-2: 8 data bits, no parity check, 2 stop bit;
F2.5	HiLo	MODBUS dual-byte register storage turn, Hi Lo: High byte in the front, low byte at the back; Lo Hi: Low byte in the front, high byte at the back
F2.6	nonE	Cont mode automatic sending time interval
F2.7	0	tt(TOLEDOcontinuous mode) If send the checksum. 0: not send, 1: send. yH: (Cont. mode) 0: send actual weight. 1: send if stable, not send if unstable.
F3	Null	The third major term of working parameter. (For analog output only)
F3.1	0-5	Analog output: 4-20: 4-20mA

		0-20: 0-20mA 0-24: 0-24mA 0-5: 0-5V 0-10: 0-10V I_out: Current customized V_out: Voltage customized In customized mode, F3.2-F3.5 parameters available
F3.2	3920	Minimum output
F3.3	4000	Zero point output
F3.4	20000	Maximum capacity output
F3.5	20020	Maximum output
F4	Null	The fourth major term of working parameter.
F4.1	OFF	Parameters password setting switch.
F4.2	000000	Parameters password setting: Valid when F4.1 is ON
F5	Null	Parameter setting refer the 5 th term
F5.1	1.00000	Weight correction factor K, weight correction factor K = Expected weight/current weight range: 0-9.99999 When the calibration weight (gain) calibration parameters reset. The value reverts to the default value of 1.00000
F5.2	0-15V	0: Unipolar (0-15v) 1: Bipolar (-15-15v)

4.4 Set point parameters

Press **MODE** ► 3 times, under the main display indicator display SPoint, under this interface, press $\frac{W/A}{ENTER}$ ● , if the working parameters F4.1 to ON, the working parameters must be entered password, if OFF, no need to enter the password to enter the setting parameter P1, press $\frac{W/A}{ENTER}$ ● to enter P1.1, again according to $\frac{W/A}{ENTER}$ ● parameters of flashing, can modify the parameter values in the interface (see section 4.2 to modify parameters), modified is completed press $\frac{W/A}{ENTER}$ ● to save, then press $\frac{ZERO}{ESC}$ ■ to exit to P1, press **MODE** ► ON to the next item parameter Settings. In the same way, other parameter items can be set.

Note: There are 4 sets points. Set points X stands for "set points 1~4". Users can set them according to their requirements.

Code	Default	Description
P1-P4	Null	The first term of working parameters
PX.1	OFF	Change of state if need stable

PX.2	0.0	Change of state minimum duration
PX.3	P1.3=1 P2.3=5 P3.3=0 P4.3=0	Comparing conditions: 0: forbid; No Comparing 1: < Less than; If the weight displayed by the indicator is less than PX.4, I/O Module is effective when it outputs the set point X, otherwise the output is invalid 2: <= Less than or equal to; The weight displayed by the indicator is less than or equal to PX.4, the output of I/O Module output set point X is valid, otherwise the output is invalid. 3: == Equal; The weight displayed by the indicator is equal to PX.4 items. The output of I/O Module output set point X is valid, otherwise the output is invalid. 4: >= Bigger than or equal to; If the weight displayed by the indicator is bigger than or equal to PX.4, the output of the I/O Module is effective and the output of the set point X is invalid 5: > Bigger than; If the weight displayed by the indicator is bigger than PX.4, the output of the I/O Module is effective, and the output of the set point X is invalid

		6: != not equal to; The weight displayed by the indicator is not equal to PX.4 items, the output of I/O Module output set point X is valid, otherwise the output is invalid 7: _<>_ Outside the interval, if the weight displayed by the indicator is less than or greater than PARx.4 or parx.5, the output of set point X of the I/O Module is effective, otherwise the output is invalid 8: =<_>= Within the interval, when the weight displayed by the indicator is bigger than or equal to PARx.4 and less than or equal to Parx.5, the output of the I/O Module at set point X is effective, otherwise, the output is invalid. 9: external trigger. If it's IO, do 1 state change for 1 trigger, if it's command, then decide according to valid or invalid command.
PX.4	0	Set value 1; 0 ~ 999999 can be set
PX.5	0	Set value 2; 0 ~ 999999 can be set

Set point has 4 major terms which are user defined.

5 I/O Definition

5.1 I/O Definition

In the main display interface, press **MODE** ► 4 times to display iodEF in the indicator. In this interface, press **MODE** ► to enter the interface of custom setting of I/O module. If the password ON/OFF of working parameter F4.1 is set as ON, the password of working parameter needs to be entered before entering the custom setting of I/O module.

Operation steps of I/O module customization: After entering the interface of I/O module customization,

- 1) Press **MODE** ► to modify the definition of OUT1
- 2) Press **TARE
OPTION** ▲ to select the meaning code of I/O module
- 3) Press **W/A
ENTER** ● to confirm and return to the OUT1 interface

4) Press **MODE** ► to define the next I/O module, then press **MODE** ► to skip the current I/O module definition (keep the original definition) to set the next I/O module. The definition method is the same as the above three steps, which will not be repeated here. Press **ZERO**
ESC ■ to exit when the setup is complete.

Output/Input code table:

Output		
Code	Definition	Description
O0	None	No definition
O1	Stable	Effective output in stable status.
O2	Overflow	Effective output when overflow.
O3	Sp1	Effective output when set point 1 status output.
O4	Sp2	Effective output when set point 2 status output.
O5	Sp3	Effective output when set point 3 status output.
O6	Sp4	Effective output when set point 4 status output.
Input		

Code	Definition	Description
I0	None	No definition
I1	Zeroing	Effective input for zeroing, pulse input signals
I2	Sp1	If this signal is valid, Sp1 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I3	Sp2	If this signal is valid, Sp2 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I4	Sp3	If this signal is valid, Sp3 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I5	Sp4	If this signal is valid, Sp4 status will be regarded as invalid. Output valid state when comparision condition turns to invalid, and be effective again.
I6	Reset all	Reset all parameter value when this signal is valid.

I7	Clear/Add tare	Clear tare when this signal is valid at first time, and add tare at the second time.
I8	Clear tare	Clear tare when this signal is valid.
I9	Add tare	Add tare when this signal is valid.
I10	Calibration lock	After the function is defined, the signal is valid (level signal), and then the password input state of the first item in the calibration step can be entered; otherwise, it cannot be entered, and an alarm Error7 is prompted. If this function is defined, MODBUS cannot perform serial port calibration.

5.2 I/O testing

The function of indicator I/O module measurement is mainly used to test whether the connection of indicator I/O module measurement and equipment is correct. It is divided into input test and output test.

Input test (test whether the input interface of the indicator is normally connected with the equipment) :



Normal Status



Under weighing status, press **MODE** ► (5 times), then display **TESTio**, press $\frac{W/A}{ENTER}$ ● enter into I/O testing interface.

Press $\frac{TARE}{OPTION}$ ▲ **OUT1** status flash, press **MODE** ► **OUT2** status flash.

This interface shows: **IN1** input valid, **OUT1** output valid.

6 Serial Communication

GMT-P1 has RS232 or RS485 as optional to realize communication with upper computer. Support r-Cont, r-SP1, Modbus(bus), tt TOLEDO, Cb920, rECont protocols, rErEAD protocol, PT650D protocol, Yh protocol and WI-125 protocol.

Serial communication terminal please refer to chapter 2.4.2、2.4.3. Baud rate and communication format setting please refer to F2.2、F2.3 and F2.4.

6.1 r-Cont

Indicator will send weighing data to host computer without command.

Data Format:

STX	Scale no.	Channel no.	Status	Value	CRC	CR	LF
-----	-----------	-------------	--------	-------	-----	----	----

Here:

STX —— 1byte, start character **02H**

Scale no. —— 2bytes, **00~99**

Status —— 2bytes, high byte:**40H**; low byte definition as follows:

D6	D5	D4	D3	D2	D1	D0
Null	Null	G./N. weight	+/-	Zero point	OFL	Stable
1	0	0: G 1: N	0: + 1: -	0: non/zero 1: zero	0: normal	0: not stable 1: stable

					1: OFL	
--	--	--	--	--	---------------	--

Weight Value —— **6** bytes; when weight is+ (-) overflow,return to“space space **OFL** space”

CRC —— **2** bytes,check sum

CR —— **1** byte, **0DH**

LF —— **1** byte, **0AH**

For example:

02 30 31 31 40 41 20 20 20 37 30 30 (present weight) 32 34 0D 0A

Means: stable,positive data,present weight **700**

6.2 r-SP1

Code : **ASCII**

Operation code supported: **W**, write; **R**, read; **C**, calibrate; **O**, zero

6.2.1 Parameters Code Chart

Operation code	Para code	Para. Name	number of character
R	WT	Read current status and weight	8
C	ZY	Zero calibration with weight	
C	ZN	Zero calibration without weight	6

C	GY	Gain calibration with weight	6
C	GN	Gain calibration without weight	12
R	AM	Absolute millivolt	7: D6D5D4D3D2D1D0; D6: +; D5-D0: corresponding ASCII for 6 digits millivolt, Decimal point is fixed to 3 digits
R	RM	Relative zero point on millivolt	7: D6D5D4D3D2D1D0 D6: +/-; D5-D0: corresponding ASCII for 6 digits, Decimal point is fixed to 3
O	CZ	Zero clearing command	

6.2.2 Error Code Explanation

- 1: CRC check error
- 2: Operation code error
- 3: Parameters code error
- 4: Write data error
- 5: Operation invalid
- 6: Channel no. error

Note: Default channel no. of this indicator : **1 (31H)**

6.2.3 Command

Indicator will send weighing data to host computer after received command.

6.2.3.1 Host computer read present status

Send command:

STX	Scale no.	Channel No.	R	WT	CRC	CR	LF
------------	-----------	-------------	----------	-----------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	R	WT	Status	Value	CRC	CR	LF
------------	-----------	-------------	----------	-----------	--------	-------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	R	WT	E	Error code	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

STX — 1byte, start character, **02H**

R — 1 byte, **52H**

WT — 2 byte, **57H 54H**

E — 1 byte, **45H**

Status — 2bytes, high byte: **40H**; low byte definition as follows:

D6	D5	D4	D3	D2	D1	D0
Null	Null	G./N. weight	+/-	Zero point	OFL	Stable

1	0	0: G 1: N	0: + 1: -	0: non/zero 1: zero	0: normal 1: OFL	0: not stable 1: stable
---	---	--------------	--------------	------------------------	------------------------	-------------------------------

Weight Value —— 6 bytes; when weight is+ (-) overflow,return to“space space OFL space”

For example:

02 30 31 31 52 57 54 30 31 0D 0A

Correct response: **02 30 31 31 52 57 54 40 4130 30 33 37 35 33 33 36 0D 0A**
(**stable**present value **3753**)

Wrong response: **02 30 31 31 52 57 54 45 31 31 39 0D 0A** (CRC check error)

6.2.3.2 Calibration Zero

1) Calibrate zero as per current weight (with weight)

Send command:

STX	Scale no.	Channel No.	C	ZY	CRC	CR	LF
------------	-----------	-------------	----------	-----------	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	C	ZY	O	K	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	C	ZY	E	Error code	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	------------	-----------	-----------

Here:

Z——1 byte, **5AH**

Y——1 byte, 59H

For example:

02 30 31 31 435A 59 39 34 0D 0A

Correct response:**02 30 31 31 43 5A 59 4F 4B 34 38 0D 0A**

Wrong response:**02 30 31 34 43 5A 59 45 36 32 30 0D 0A** (channel no. error)

2) Input millivolt calibration zero in the chart (without weight)

Send command:

STX	Scale no.	Channel No.	C	ZN	Zero millivolt value						CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------------------	--	--	--	--	--	------------	-----------	-----------

Correct response:

STX	Scale no.	Channel No.	C	ZN	O	K	CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	----------	------------	-----------	-----------

Wrong response:

STX	Scale no.	Channel No.	C	ZN	E	Error code						CRC	CR	LF
------------	-----------	-------------	----------	-----------	----------	------------	--	--	--	--	--	------------	-----------	-----------

Here:

ZN——2 bytes, 5AH4EH

Zero millivolt value——6 bytes

For example:

02 30 31 31 43 5A 4E 30 31 32 36 31 30 38 31 0D 0A

Correct response:**02 30 31 31 43 5A 4E 4F 4B 33 37 0D 0A**

Wrong response:**02 30 31 31 43 5A 4E 45 34 30 34 0D 0A** (Write data error)

6.2.3.3 Gain calibration

1) With weights

Send command:

STX	Scale no.	Channel No.	C	GY	Weight value	CRC	CR	LF
-----	-----------	-------------	---	----	--------------	-----	----	----

Correct response:

STX	Scale no.	Channel No.	C	GY	O	K	CRC	CR	LF
-----	-----------	-------------	---	----	---	---	-----	----	----

Wrong response:

STX	Scale no.	Channel No.	C	GY	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	----	---	------------	-----	----	----

Here:

GY——**2 bytes**, 47H 59H

Weight value——**6 bytes**: Write in weight value

For example:

02 30 31 31 43 47 59 30 30 30 32 30 30 36 35 0D 0A (Write in: weight value **200**)

Correct response: **02 30 31 31 43 47 59 4F 4B 32 39 0D 0A**

Wrong response: **02 30 31 35 43 47 59 45 36 30 32 0D 0A** (Channel no. error)

2) Without weights

Send command:

STX	Scale no.	Channel No.	C	GN	Gain millivolt	Weight value	CRC	CR	LF
-----	-----------	-------------	---	----	----------------	--------------	-----	----	----

Correct response:

STX	Scale no.	Channel No.	C	GN	O	K	CRC	CR	LF
-----	-----------	-------------	---	----	---	---	-----	----	----

Wrong response:

STX	Scale no.	Channel No.	C	GN	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	----	---	------------	-----	----	----

Here:

Gain millivolt——**6 bytes**

Weight value——6bytes

For example:

02 30 31 31 43 47 4E 30 30 31 39 34 30 30 30 32 30 30 35 36 0D 0A (Write in: weight value **200**, corresponding gain millivolt **0.194**)

Correct response: **02 30 31 31 43 47 4E 4F 4B 31 38 0D 0A**

Wrong response: **02 30 31 31 43 48 4E 45 33 38 35 0D 0A** (Para. Code error)

6.2.3.4 Zeroing

Send command:

STX	Scale no.	Channel No.	O	CZ	CRC	CR	LF
-----	-----------	-------------	---	----	-----	----	----

Correct response:

STX	Scale no.	Channel No.	O	CZ	O	K	CRC	CR	LF
-----	-----------	-------------	---	----	---	---	-----	----	----

Wrong response:

STX	Scale no.	Channel No.	O	CZ	E	Error code	CRC	CR	LF
-----	-----------	-------------	---	----	---	------------	-----	----	----

For example:

02 30 31 31 4F 43 5A 38 34 0D 0A

Correct response: **02 30 31 31 4F 43 5A 4F 4B 33 38 0D 0A**

Wrong response: **02 30 31 31 4F 43 5A 45 35 30 36 0D 0A** (Operation can't execute)

6.2.3.5CRC computation

All the values in front of the parity byte add together and convert to decimal data, then convert the last 2 bytes to **ASCII** code (decade in front and the unit at the back).

For example

The following is a frame of data:

02	30	31	31	4F	43	5A	38	34	0D	0A
----	----	----	----	----	----	----	----	----	----	----

Add 02~5A: 180(Hex), convert to decimal data: 384. We can calculate from this that the check code is 38,34 for the data frame.

6.3 tt TOLEDO Protocol

When choose “tt” protocol in working parameter F2.3, indicator will send datas in continuous mode with TOLEDO protocol.

Continuous sending mode format as below:

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
STX																0D	

⌞ A B C display weight(6 bytes: is synchronized with display) 6 ↑ 30H

Checksum

Here: start character is standard **ASCII** start character **02(STX)**

status byte **A** definition as below:

D0	0	1	0	1	0
D1	1	1	0	0	1
D2	0	0	1	1	1
Decimal point	x	.x	.xx	.xxx	.xxxx

D3 D4 D6 为 **0(not change)** **D5** is **1(not change)**

status byte **B** definition as below:

D6	D5	D4	D3	D2	D1	D0
Status			Stable	Overflow	symbol	G.W.
Is 0 (not change)	Is 1 (not change)	Is 1 (not change)	1-unstable 0-stable	1-overflow 0-normal	1-negative 0-positive	0-G 1-N

status byte **C** is reserved, output 20H.

6.4 Cb920

When **F2.3=Cb920** in working parameter, indicator will send weighing data continuously without command under **Cb920** protocol.

Data format:

Status	,	G.W.	0/1	Symbol	Display	Unit	CR	LF
--------	---	------	-----	--------	---------	------	----	----

Here:

Status — 2 bytes, **OL:** (4FH 4CH) OFL; **ST:** (53H 54H)Stable; **US:** (55H 53H)unstable

, — 1 byte, separator **2CH**

G.W. — 2 bytes, **GS:** gross weight 47H 53H. **NT:** net weight 4EH 54H

0/1 — 1 byte, (30H/31H) interleaved transmission

Symbol — 1 byte, 2BH (+) , 2DH (-)

Display — 7 bytes, including decimal point: display weight value.

Unit — 2 bytes, blank space (20H 20H)

CR — 1 byte, 0DH

LF — 1 byte, 0AH

For example: When indicator send the following automatically:

53 54 2C 47 53 31 2B 20 20 31 39 30 2E 31 20 20 0D 0A

Means: Stable、G.W.、Data value is positive、current weight is **190.1**

6.5 rECont

Indicator will send weighing data to the upper computer continuously without any command.

Return data frame format specification :

Status	,	GS/ NT	,	+/-	Display	Unit	CR	LF
2bytes	2C	47 53/4E 54	2C	2B/2D	7bytes	6B 67	0D	0A

Here:

Status —— **2 bytes**, **OL(OFL):4FH 4CH; ST(stable):53H 54H; US(unstable):55H 53H**

Display value —— **7bytes**, including decimal point, high byte is blank if no decimal point.

For example: When indicator send the following automatically:

53 54 2C 47 53 2C 2B 30 31 31 2E 31 32 30 6B 67 0D 0A

Means: Stable, Data value is positive, display value is **11.120kg**

6.6 rEREAD

Indicator will send weighing data to the upper computer under command.

Data format:

Data	R	E	A	D	CR	LF
explain	52H	45H	41H	44H	0DH	0AH

The return data frame is the same with that of **rECont** protocol, please refer to **rECont**.

- 1) Zero clearing command: ZERO ON<CR><LF> : **5A 45 52 4F 20 4F 4E 0D 0A**

Return YES<CR><LF> or NO? <CR><LF>

- 2) Calibration zeroing command: TARE ON<CR><LF> : **54 41 52 45 20 4F 4E 0D 0A**

Return YES<CR><LF> or NO? <CR><LF>

- 3) Read ID no.: GET ID<CR><LF> : **47 45 54 20 49 44 0D 0A**

Return ASCII code with 6 digits ID no.

6.7Modbus

Indicator uses **RTU mode** to communicate, every 8-bit byte of the message are divided into 2pcs of 4-bit hexadecimal characters to transmit at binary code.

Code: Binary

Function code:

Function code	Definition	Description
03	read the register	
06	preset single register	
16	preset several registers	Command only support preset double registers.
01	read coil	The length unit is bit.
05	write coil	

Exception code response

Code	Definition	Description
02	Illegal data address	Data address received from error code is not allowed
03	Illegal data value	Data wrote in is not in permissible range
04	machine fault	When indicator is trying to execute operation required, unrecoverable error is produced.
07	Unsuccessful programming request	Command received can't be executed under current condition.

6.7.1 Modbus communication address

PLC addr.	Display addr.	Description
The following items are only-read register(code 0x03)		

40001	0000	Present weight value(4bytes including sign characters, the high byte is in the front)
40002	0001	
40003	0002	D15—D14..D5—D4 — D3 — D2 — D1 — D0 All is 0 0:+ 0:non-zero 0:normal 0:unstable 1:- 1: zero 1:OFL 1:stable
40004	0003	Reserve(permit to read, reading value is 0)
.....		
40006	0005	
The following items are two bytes and are available to read and write (write code 0x06, read code 0x03)		
40007	0006	Zeroing(zeroing when write in non-zero value)
40008	0007	Automatically zeroing when power on (0: OFF; 1: ON1; 2: ON2)
40009	0008	Zero tracking range (0-9d)
40010	0009	Stable range (0-9d)
40011	0010	Zeroing range (0%-99%)
40012	0011	Digit filter parameters(0-9)
40013	0012	Stability filter series(0-9)

40014	0013	AD sample rate: 0:15/s 1:30/s 2:60/s 3: 120 /s 4:480/s 5:960/s
40015	0014	Reserved
40016	0015	NET Indicator switch, 0: Used for gross and net weight ,1: For communication indication
40017	0016	Switch for Tare Record (0: OFF; 1: ON)
40018	0017	Reserved
40019	0018	Decimal point place (0:0,1:0.0,2:0.00,3:0.000,4:0.0000)
40020	0019	Minimum division (1/ 2/ 5/ 10/ 20/ 50)
The following items are available to read and write (writing code 0x10,read code 0x03)		
40021	0020	Maximum capacity (max.capacity≤mini.division×1000000)
40022	0021	
40023	0022	Zero calibration with weights: write in 1 and calibrate zero with the current weight. Read: Absolute millivolt of current load cell
40024	0023	
40025	0024	Zero calibration without weights: Write millivolt value at zero; Write in range (load cell 3mV/V:millivolt value range within 0.02-12.000mV) millivolt value at zero when read.
40026	0025	

40027	0026	Gain calibration with weights. Write weight value($\leq$ max. capacity). Return millivolt at present weight value when read
40028	0027	
40029	0028	Gain calibration without weights; input gain millivolt(load cell 3mV/V:0.000 < millivolt< 15.000mV — zero millivolt).Read: millivolt value for gain calibration.
40030	0029	
40031	0030	Gain calibration weight without weights. input gain millivolt($\leq$ max. capacity) Read: weight value for gain calibration.
40032	0031	
40033	0032	Gross weight, with symbol
40034	0033	
40035	0034	Net weight
40036	0035	
40037	0036	Tare weight
40038	0037	
40039	0038	Display weight value (floating-point type)
40040	0039	
40041	0040	Set point 1 stable or not (0: no; 1: yes)
40042	0041	Set point 1 min. duration time (0-999 : 0-99.9sec.)
40043	0042	Set point 1 valid condition

40044~40045	0043~0044	Set point 1 set value 1
40046~40047	0045~0046	Set point 1 set value2
40048	0047	Set point 2 stable or not (0: no; 1: yes)
40049	0048	Set point 2 min. duration time (0-999 : 0-99.9sec.)
40050	0049	Set point 2 valid condition
40051~40052	0050~0051	Set point 2 set value1
40053~40054	0052~0053	Set point 2 set value2
40055	0054	Set point 3 stable or not (0: no; 1: yes)
40056	0055	Set point 3 min. duration time (0-999 : 0-99.9sec.)
40057	0056	Set point 3 valid condition
40058~40059	0057~0058	Set point 3 set value 1
40060~40061	0059~0060	Set point 3 set value 2
40062	0061	Set point 4 stable or not (0: no; 1: yes)
40063	0062	Set point 4 min. duration time (0-999 : 0-99.9sec.)
40064	0063	Set point 4 valid condition
40065~40066	0064~0065	Set point 4 set value 1
40067~40068	0066~0067	Set point 4 set value 2
40069	0068	Output 1 user-defined
40070	0069	Output 2 user-defined

40071	0070	Input 1 user-defined	
40072	0071	I/O output value	Note: available only when coil address 00016 is valid. Input write 1 valid, 0 invalid. Read 1 valid, 0 invalid
40073	0072	I/O input value	
Reserved			
40401	0400	Current weight value(4 bytes with symbolic number, high digit in front)	
40402	0401		
40403	0402	D15—D14……D4 0 D3 0:+ 1:- D2 0:non-zero 1:zero D1 0:normal 1:OFL D0 0:Stable 1:Unstable	
40404	0403	0	
40405	0404	6 digits without symbolic number, user ID no.	
40406	0405		
40407	0406	Reset value; The weight value corresponding to the floating zero point saved by the power-on automatic zeroing and restart function.	
40408	0407		
The following items are byte read only. (read code: 0x03)			

49001	9000	Version no.	If display10024, formatXX XXXX,main version no., hardware no., software no..So main version no.01, hardware no. 00,software no. 24
49002	9001		
49003	9002	Develop time	If display 141024, means 24 th Oct., 2014
49004	9003		
The following items are byte read only. (read code: 0 x 0 1)			
00001	0000	0: unstable; 1: stable	
00002	0001	0: normal; 1: OFL	
00003	0002	0: non-zero; 1: zero	
00004	0003	0: +; 1: -	
00005	0004	Reserved	
00006	0005	Reserved	
The following item are available to read and write (read code: 0x01, writing code: 0x05)			
00007	0006	Automatically zeroing when power on (0: OFF; 1: ON)	
00008	0007	Reserved	

00009	0008	Reserved	
00010	0009	Reset all	
00011	0010	Reset calibration	
00012	0011	Reset paramaters	
00013	0012	Reset I/O	
00014	0013	Reserved	
00015	0014	Reserved	
00016	0015	I/O testing switch	
00017	0016	Set point 1 status	Only read: 0:invalid, 1:valid
00018	0017	Set point 2 status	
00019	0018	Set point 3 status	
00020	0019	Set point 4 status	
00021	0020	Zero calibration (Set on, and then write ON to start calibration.)	
00022	0021	Zero (Zeroing when write ON)	
00023	0022	Clear tare (Clearing tare when write ON)	
00024	0023	Add tare (Adding tare when write ON)	
00025	0024	Gross/Net change (Only read 0: gross weight; 1: net weight)	
00026~	0025~	Reserved	

00032	0031	
-------	------	--

6.8PT650D protocol

When PT650D protocol is selected for work item F2.3, the data frame format (F2.4) is automatically adjusted to 7-E-1, and the baud rate (F2.2) is automatically adjusted to 9600 (and only 2400, 4800, 9600 and 19200 are optional).

In this protocol, the data is output in ASCII code, and the data format is as follows:
Returns the data frame format description

No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
	0	L	,	N	T	,	-	1	2	3	4	.	5	7	k	g	c	L

No.1, 2——state 1:

OL: overload; ST: Stable display; US: Instable display

No.3——“,” 2C (HEX)

No.4, 5——state 2:

NT: net weight; GS: Gross weight

No.6——“,” 2C (HEX)

No.7——polarity: “+”: positive; “-”: Negative

No.8-14——weight value: If there is No decimal point, print a space at No.8; the read value of overflow state is 999999

No.15-16——Unit: kg, t (Fixed output of this indicator kg)

No.17-18——control code: CRLF

6.9 Yh protocol

When Yh protocol is selected for work item F2.3, the data frame format (F2.4) is automatically adjusted to 8-n-1, and the baud rate (F2.2) is automatically adjusted to 1200.Communication interval (F2.6) is automatically adjusted to 50ms.

In this protocol, the data is output in ASCII code, and each frame consists of 9 groups (including decimal point).Data is transmitted from low position to high position, and there is a set of delimiter "=" between each frame of data. The sent data is gross weight, such as the current gross weight of 70.15, 51.0700=51.0700.....

Such as: 123.9

Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7	Bit8
=	9	.	3	2	1	0	0	0

High no enough to fill 0, decimal point occupies 1 byte, negative Bit8 for the negative sign "-".

6.10WI-125 Protocol

When the WI-125 protocol is selected for work item F2.3, the baud rate (F2.2) is automatically adjusted to 9600. The supported baud rates are: 2400/4800/9600/19200.Data frame format:

STX	Mode	Weight	Space	Unit	Space	CR	LF
-----	------	--------	-------	------	-------	----	----

20H	Gross/Net	8 bytes	20H		20H	OD	OA
------------	------------------	----------------	------------	--	------------	-----------	-----------

Among them:

Start character -- **0x20**

Status -- **1** byte, **G** (gross weight): **47H**; **N** (net weight): **4EH**

Display weight value - **8** bytes, including plus or minus sign and decimal point, the first sign is plus or minus sign, plus sign is not displayed, positive number is **20H**; -- : **2DH**;

Space -- **0x20**

Units -- **2** bytes, **kg**: **6B 67**; **lb**: **6C 62**;

CR - **1** byte, **0DH**

LF -- **1** byte, **0AH**

Eg: **78.1**

No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
		G		0	0	0	7	8	.	1		k	g		CR	LF

The decimal point occupies one byte. When it is a negative number, No.3 is the negative sign "-".

7 Password Input and Setting, Reset

7.1 Password Input


- (1) Indicator calibration and working paraters setting default password: **000000**.
- (2) According to relevant national standards, calibration parameters are password-protected, and the calibration password must be entered before calibration.
- (3) User can set password in parameters when **F4.1** is“**ON**”.
- (4) When display is “PASS”, need to input correct password to enter parameters.

Note:

- (1) When input password, if first time wrong, it will go to the second chance for password input(display from  turn to ).
- (2) If second input wrong, it will enter into interface for inputting password the third time
(Display change from  to ).
- (3) If Input wrong for three times, main display show “Error4” and self-lock, but user can operate when power on again.

7.2 Password Setting


- (1) User can set password in parameters when **F4.1** is "ON".
- (2) User must input same new password twice in setting password, If not same, main display show "**Error**" one second and return to **PASS** again.




7.3 Factory Reset

Note: Factory reset is only for special technicians, which will reset all of parameters and will maybe cause not working.

Take reset all for example:





1) In **F SEt** interface, press $\frac{W/A}{ENTER}$ ● to reset working parameters, enter into reset calibration parameters interface.

2) In **F SEt** interface, press **MODE** ►, not to make working parameter reset, enter into calibration parameter reset interface.

1) In **F CAL** interface, press $\frac{W/A}{ENTER}$ ● to reset calibration parameter., enter into reset all interface.


2) In **F CAL** interface, press **MODE** ►, not to make calibration parameter reset, enter into reset all interface.

1) In **F ALL** interface, press $\frac{ZERO}{ESC}$ ■ to make reset all of the parameters (including working parameter., calibration parameter., I/O etc..)

Note: In all reset interfaces, press $\frac{ZERO}{ESC}$ ■ to exit and return to weighing interface.

8 Display Testing

The following flow chart is to test lights on main-display and status lights.



9 Errors and Alarm Messages

Error ① Input error.

② wrong data beyond parameter range.

Error 2 The present weight value is out of zeroing range.

Error 3 Scale platform is not stable when zeroing.

Error 4 Input wrong password more than 3 times.

Error 5 The present weight value is overlimit when clearing tare.

Error 6 The present weight value showed is unstable when clearing tare.

OFL Weighing value is positive overflow.

-OFL Weighing value is negative overflow.

10 Indicator model user-defined function

The custom model of the indicator displayed after the indicator is powered on. Through the relevant operation of the indicator, you can customize the model content displayed on the indicator. Steps are as follows:

1. When power on,

Flash twice 8 after power on, and then display model, display model 3s turn to main display interface, long press MODE key under the menu interface display after the "LOGO" press Enter into custom Settings interface model, under the current interface, press MODE key to choose, the OPTION button to adjust a particular character values, save the change, indicator boot will show the changed model; If no changes are made to the indicator model, the indicator will default to GMT-P1.(note: reset out of position indicator model)

2. After entering the model user-defined interface, the 6-bit main display character can be defined. MODE key can be used to adjust and select a certain character. Characters can be adjusted by using the OPTION key. The sequence of character changes is space, -, 0~9, A~Z (according to the display character comparison table, as

shown in the appendix), and press Enter to save the current modified value.



Displays character comparison table

a	b	c	d	e	f	g	h	i	j	k	l	m
A	b	C	d	E	F	G	H	I	J	K	L	M
n	o	p	q	r	s	t	u	v	w	x	y	z
n	o	P	q	r	S	t	U	v	W	X	Y	Z

11 Dimension of Indicator

The GMT-P1 is available in two types of models: the panel-mounted aluminum model and the desktop stainless steel model.

Dimension of rear panel: **92×45(mm)** ⇒



⇐ Dimension of front panel: **105×57(mm)**

Panel cutout dimension: **93×46(mm)** ⇒



Desktop instrument dimensions

